

USE AND MAINTENANCE MANUAL

EN H-11A

YEAR OF MANUFACTURE: _____



®



CEDECLARATIONOFCONFORMITY
(UndersectionCEE2006/42/CE,MachineDirective,supplementIIA)

The manufacturer: **MEP(SUZHOU)CO.LTD**
(PR.CHINA)

Hereby declare that the bandsawing machine:

Machine Type: **Sawing machine**

Band Saw Model: **H-11A**

Serial Number:

Year of Manufacture:

is in specification with the following directives:

MACHINE DIRECTIVE CEE2006/42/CE
DIRECTIVE 2006/95/CE "LVD"
DIRECTIVE 2004/108/CE "EMC"

Responsible for T.C.F.: 
(Walter Di Giovanni)
(Italy)

Managing Director: 
(Michele D'Angelo)
(China)

Date: _____

MEPGROUP

ITALY: MEPSPA, SEGATRICI, Via Enzo Magnani, 1, 61045 Pergola (PU) ITALIA. (T) 0721 73721 (F) 0721 734533

CANADA: 1079 Parkinson Road, Woodstock, Ontario, N4S0A9, (p) 519-537-2103 (f) 519-539-5843

CHINA: Building 6, Fu Min Industrial Park, No. 318 Suwang Road, Wuzhong District, 215104 Suzhou, China


Introduction and technical specifications	1- 1
Foreword	1- 1
Machine presentation	1- 1
Machine specification	1- 2
Technical data general table	1- 3
Dimensions	1- 6
Functional parts	2- 1
H- 11A model	2- 1
Cutting bow (Cutting head)	2- 2
Cutting vice	2- 3
Control Panel	2- 3
Base	2- 4
Hydraulic control unit	2- 5
Feeder	2- 6
Safety and accident prevention	3- 1
Use of the machine	3- 1
General recommendations	3- 1
Recommendations to the operator	3- 2
Machine safety devices	3- 5
Reference standards	3- 5
Protection against accidental contact with the blade ..	3- 5
Electrical equipment	3- 6
Emergency devices	3- 6
Noise level of the machine	3- 7
Noise level measurement	3- 7
Noise level values	3- 8
Vibration emission	3- 8
Electromagnetic compatibility	3- 8
Machine installation	4- 1
Packaging and storage	4- 1
Levelling and anchoring the machine	4- 4
Auger set up	4- 5
Minimum requirements	4- 7
Check list	4- 8
Connection to the power supply	4- 9
Description of machine operation	5- 1
Description of the control panel	5- 1

Basic instructions for carrying out a cutting operation cycle	5- 2
Blade tension	5- 2
Moving the cutting head up and down	5- 4
Manoeuvring the feeder	5- 4
Symbol key	5- 5
Operating parameters	5- 6
Cutting cycles	5- 8
Cutting stroke setting	5- 9
Width of cut	5- 10
Preliminary check list for cutting operation	5- 10
Manual operating cycle	5- 11
Automatic mode single job	5- 15
Automatic mode queue	5- 18
Diagrams, exploded views and replacement parts	6- 1
Exploded views	6- 88
Base assembly	6- 88
Cutting mobile head group	6- 90
Idler pulley unit	6- 92
Driving pulley unit	6- 94
Cradle unit	6- 96
Protection group	6- 98
Feeder group	6- 100
Feed carriage unit	6- 102
Feeder vertical vice	6- 104
Cutting vertical vice	6- 106
Fixed vice group	6- 108
Vertical rolls group	6- 110
Control board	6- 112
Hydraulic unit	6- 114
Adjustments	7- 1
Displaying and editing the set- up parameters	7- 1
Setup parameters	7- 3
Software update procedure through USB - H- 11A ..	7- 9
Hydraulic systems	7- 11
Machine working pressures	7- 11
Mechanical systems	7- 12
Blade tensioner slide play adjustment	7- 12

Cutting head stroke	7- 13
Blade guide components	7- 14
Blade guide heads	7- 14
Blade- pressing tang	7- 14
Blade guide plates	7- 14
Blade	7- 16
Tool changeover	7- 16
Blade perpendicularity	7- 17
Blade orthogonality	7- 18
Rotation axis control	7- 20
Feeder	7- 20
Maintenance and choice of consumables	8- 1
The role of the operator	8- 1
Maintenance requirements	8- 1
General maintenance	8- 2
Daily	8- 2
Weekly	8- 2
Monthly	8- 2
Maintenance of working parts	8- 3
Consumable materials	8- 3
Oils for hydraulic circuit	8- 3
Oils for lubricant/coolant fluid	8- 3
Oils for worm reduction gear	8- 3
Oils for spray mist system (optional)	8- 4
Cutting speed and choice of tools	9- 1
Cutting speed	9- 1
Standard machine	9- 1
Choice of blade	9- 2
Saw tooth pitch	9- 2
Cutting speed and downstroke speed	9- 2
Types of swarf:	9- 3
Lubricant/coolant fluid	9- 3
Blade structure	9- 4
Blade types	9- 4
Conventional rake	9- 5
Positive rake	9- 5
Variable pitch	9- 5

Variable pitch blades with 0° cutting angle	9- 6
Variable pitch with positive rake (from 9 to 10 degrees)	9- 6
Set:	9- 6
Standard or splayed set	9- 6
Undulated set	9- 6
Alternating grouped sets	9- 7
Alternating set	9- 7
Blade selection table relating to cutting speed and downstroke speed	9- 8
Classification of steels	9- 9
Classification of steels	9- 10
Troubleshooting	10- 1
Troubleshooting blade and cutting problems	10- 1
Troubleshooting	10- 8
Machine alarms and warning messages	10- 14
Accessory Installation	11- 1
Blade	11- 1
Roller table	11- 1
Installation of the roller plane, loading side	11- 2
Installation of the roller plane, unloading side	11- 3
Installation of couple of vertical rollers for roller plane	11- 3
Installation of the hydraulic vertical vices	11- 3
Can of emulsible oil	11- 3
Minimal lubrication system	11- 4
Warranty	11- 5

Introduction and technical specifications



Foreword

For decades we have been committed to construction of the very best in metal cutting saws. With all our experience, technological know how for the latest in product and design, Hyd- Mech is able to offer customers specific solutions to all cutting needs and requirements.

In response to modern production technologies **Hyd- Mech** has developed this new band saw. **H- 11A** .

This work tool has been designed as a simple and reliable answer to the wide range of cutting needs of the modern workshop.

Sturdy structure, silent and safe operation it can cut with minimal waste and is extremely versatile, ideal for cutting stainless steel, light alloys, aluminium, copper and bronze offering exceptional speed and precision.

Its high cutting capacity enables it to handle both single workpieces and bundles, making this machine the ideal solution for satisfying the wide range of cutting needs of machine shops, turneries, structural steel shops and engineering workshops.

Congratulations for having chosen this product which, **by following the instructions contained in this user and maintenance handbook** will guarantee years of dependable service.


This band saw has been exclusively designed to cut metals.

Warning









Machine presentation

La **H- 11A** is a hydraulic electro- mechanical cutting saw for solid and section cutting of metals. Machine operation is either SEMIAUTOMATIC or AUTOMATIC.

In the Semiautomatic cycle, after setting the bow cutting sequence from the control panel and the speed of the descent cutting head, the operator closes the vice by pushing the button from the control panel and pushes the start key to start up the belt. Then:



In the Automatic cycle, after setting the bow cutting sequence from the control panel and the speed of the descent cutting head, the operator closes the vice by pushing the key from the control panel and pushes the start key to start the belt. Then:




1. The cutter vice closes	2. The head lowers until the cut is made (FCTA)	3. The head returns to start position (FCTI)	4. The feed vice closes
			
5. The cutting vice opens	6. The cutting material is fed	7. The cutting vice closes	8. The feeder vice opens and the cutting cycle starts again
			

Attention

Before starting any of the work cycles, consult Chapter 5, where all the work phases are explained in detail.

Machine specification

The anodised aluminium name plate is riveted on the side of the machine; the same data are reproduced on the declaration of conformity included with this use and maintenance manual.

		 www.HYDMECH.COM			
model	HYD MECH			HP	
serial					
1 PH 60 Hz	V	FLA	3 PH 60 Hz	V	FLA
S/C RATING 5KA @			V	kg/lbm	

N.B. When communicating with the Technical Service department, the model, serial number and year of manufacture of the machine must be quoted.

Technical data general table

CUTTING SPEEDS		
Blade rotation speed	mt/min ft/min	15 ÷ 115 49 ÷ 377

BAND SAW		
Nominal dimensions	mm in	4500 x 34 x 1,1 177.16x1.34x0.04
Development	mm in	4500 ± 40 177.16 ± 1.57
Blade height	mm in	34 1.34
Blade thickness	mm in	1,1 0.04
Blade tension	kg lbs	1600 3520

Attention

When choosing the cutting tool, if its dimensions do not correspond to those included in the "Rated size" section, check that the dimensions at least fall within the admissible max/min specifications.

RATED ELECTRICAL POWER		
Head spindle motor	kW hp	4 5.36
VFD	kW hp	5,5 7.37
Electric coolant pump motor	kW hp	0,12 0.16
Power pack motor M1	kW hp	1,3 1.74
Feed step motor	kW hp	0,44 0.59
Max. installed electrical power	kW hp	7,36 9.86

FULL LOAD AMPERAGE		
FLA (230 V)	Amps	25
FLA (480 V)	Amps	16

WORKING PRESSURE		
Head working pressure during descent/ascent	bar psi	25 362.56
Vice working pressure during opening/closure phase	bar psi	25 362.56
Hydraulic control unit working pressure	bar psi	38 551.14

MATERIAL FEEDER		
Feeder stroke	mm in	460 18.11
Max weight capacity	kg lbs	1500 3300
Bar feed force	N	6000



LUBRICANT/COOLANT FLUID AND OIL		
Oil for monobloc hydraulic power pack	capacity lt	36
Lubricant/coolant fluid (5- 6% oil concentration)	capacity lt	200

CUTTING AND FEED VICES		
Vice max. opening	mm in	345 13.58


SPINDLE MOTOR					
4- pole, three- phase, asynchronous;					
No.of poles	Frequency (Hz)	Current (Volts)	Absorption (Amps)	Power (kW) (hp)	rpm
4	60	133/230	25,1/4,5	4 5.36	1730
4	60	278/480	12/6,97	4 5.36	1730
Stator wound with enamelled copper wire, class H 200° C.					
Class F insulation (limit temperature TL 155° C).					
Protection rating IP 54.					
Conforming to CEI norms, publication: IEC 34 of 01/07/1985.					

HYDRAULIC POWER PACK MOTOR SPECIFICATIONS M1				
4- pole, three- phase, asynchronous; Frequency 60 Hz.				
No.of poles	Current (Volts)	Absorption (Amps)	Power (kW) (hp)	rpm
4	240/480	5,0/2,5	1,3 1.74	1660
Protection rating IP 55.				
Conforming to CEI norms, publication: IEC 34 of 01/07/1985.				

ELECTROPUMP MOTOR Single phase; Frequency 60 Hz.					
Voltage (Volts)	Absorption (Amps)	Power (kW) (hp)	rpm	Delivery rate lt/min	Head (mt.) (ft)
240	0,58	0,12 0.16	2800	50	6 19.68
Protection rating IP 55.					
Conforming to CEI norms, publication: IEC 34 of 01/07/1985.					




CUTTING CAPACITY		
Section		
0°	280 11.02	280x280 11.02x11.02
Remnant length: 40 mm / 1.57 in		

PACKED WEIGHT		
Wooden cage and pallet	kg lbs	300 660
Wooden pallet	kg lbs	150 330



Dimensions

MACHINE INSTALLED		
Work table height	mm in	860 33.86
Weight	kg lbs	2600 5720




Functional parts

2

H-11A model

In order for the user to move towards a full understanding of how the machine works, which is described in detail in the chapter 5, this chapter deals with the main units and their locations.




Cutting bow (Cutting head)

The operating head is the cutting component and is made up of a bow from cast iron on which the following elements are installed: band, band guide components, band tensioning unit, worm screw reducer and spindle motor.


The cutting bow slides on linear guides, with ball - recirculation slides, installed on columns for getting a better cutting stability and longer blade life. Feeding is by a hydraulic cylinder on linear guides with ball - recirculating slides.

The machine is equipped with a laser system to position the bar accurately to carry out non--standard or facing cuts.




Cutting vice

The vice is the unit that clamps the workpiece during cutting; it consists of a vice support, commonly known as a “lead nut” fixed to the work table on which a mobile jaw is mounted. The opening or closing movement is carried out through the relevant keys on the console.




Control Panel

The control panel has a protection rating of IP 54 and contains the electronic equipment. Access to the control panel is protected by a safety panel mounted on hinges and fastened with screws, specially designed to prevent tampering. The control panel swivels on two articulated joints so that it can be positioned by the operator for greater ease- of- use and safety.



Base


This unit features a large coolant collection surface which conveys the coolant to the rear tank via the tank cover, and a swarf collection drawer. The electric pump seated inside the tray sucks the clean liquid from the progressive filter system and makes it circulate again to ensure an efficient flowing of the processing residues and the lube- refrigeration of the cutting tool.



The coolant gun is on the right of the cutting plane. On the front right of the base there is a chip tray that can be replaced with an optional chip extractor. The hydraulic control unit and the electric board are located in the right rear side.


Hydraulic control unit

The hydraulic control unit operates the cutting vice and the feeding vice and balances the weight of the cutting bow. It is located in the machine rear part under the metal protection. The oil exchange in the circuits is operated by solenoid valves driven by the machine controller.




Feeder

The material is fed by the feeding shuttle which clamps the material with the hydraulic vice and draws the cutting material by sliding on ground guides. The numeric control very accurately drives the stepper motor of the feeding shuttle, thus enabling the operator to set 24 sequences of 50 programs each chosen among max. 300 cutting programs, with different quantity and length, on the same bar.



The stepper motor and the power supply structure, can supply power to bars up to 3000 Kg (6600 lbs) even when sheared, because they are equipped with a self- aligned vice.

Safety and accident prevention



The **H- 11A** has been designed and produced in accordance with European standards. For the correct use of the machine we recommend that the instructions contained in this chapter are carefully followed.

Use of the machine

The **H- 11A** band saw cutting machine is intended exclusively for cutting metallic materials, ferrous or non- ferrous, in section or solid. Other types of material and machining are not compatible with the specific characteristics of the saw. The employer is responsible for instructing the personnel who, in turn, are obliged to inform the operator of any accident risks, safety devices, noise emission and accident prevention regulations provided for by international standards and national laws regarding the use of the machine. The operator must be perfectly aware of the position and function of all the machine's controls. The instructions, warnings and accident prevention standards in this manual must be respected without question by all those concerned. The following definitions are those provided for by **EEC MACHINES DIRECTIVE 2006/42/CE** :

- “Danger zone”: any zone in and/or around a machine in which the presence of a person constitutes a risk for the safety and health of that person.
- “Person exposed”: any person finding himself either completely or partly in a danger zone.
- “Operator”: the person or persons given the responsibility of installing, operating, adjusting, maintaining, cleaning, repairing or transporting the machine.

Attention

The manufacturer declines any responsibility whatsoever, either civil or criminal, should there be unauthorised interference or replacement of one or more parts or assemblies on the machine, or if accessories, tools and consumable materials are used that are different from those recommended by the manufacturer itself or if the machine is employed in a plant system and its proper function is thereby altered.

General recommendations

LIGHTING

Insufficient lighting for the types of operation envisaged could constitute a safety hazard for the persons concerned. For this reason, the machine user must provide lighting in the working area sufficient to eliminate all shadowy areas while also avoiding any blinding light concentrations. (Reference standard ISO 8995- 89 “Lighting in work environments”).

CONNECTIONS


Check that the power supply cables and pneumatic feed systems comply with the maximum machine absorption values listed in the “Machine Specification” tables; replace if necessary.

EARTHING


The installation of the earthing system must comply with the requirements set out in **NORMA EN 60204- 1:2010**.

OPERATOR POSITION

The position of the operator controlling machine operations must be as shown in the diagram below.



Recommendations to the operator



Always wear proper goggles or protective glasses.



Do not use the machine without the guards in position. Replace the polycarbonate windows , if subject to corrosion.



Do not allow hands or arms to encroach on the cutting zone while the machine is in operation.




Do not wear oversize clothing with long sleeves, oversize gloves, bracelets, necklaces or any other object that may become entangled in the machine during working; long hair must be tied back and bunched.



Always disconnect the power supply to the machine before carrying out any maintenance work whatsoever, including in the case of abnormal operation of the machine.



Before cutting, suitably support the material on both machines sides, using the standard bar supporting arm, or optional accessories such as the load and unload roller ways as shown in the drawing here below. Before removing the material supporting and driving devices, lock the material with the machine clamping devices or other suitable tools. If the unloading table is not available, position a basket for collecting the cut pieces close to the sawing machine on the unloading side.



Any maintenance work on the hydraulic or pneumatic systems must be carried out only after the pressure in the system has been released.








The operator must not perform any risky operations or operations not required for the machining operation under way (e.g. remove swarf or metal shavings from the machine while cutting).



Remove equipment, tools or any other objects from the cutting zone; always keep the working area as clean as possible.



Before starting any cutting operations, ensure that the workpiece is securely held in the vice and the machine has been set correctly. A number of examples of how to clamp different profiles correctly in our machines are shown below.



Do not use the machine to cut pieces that exceed the capacity of the machine as listed in the machine specifications.



Never move the machine while it is cutting.



Do not use blades of different sizes to those recommended in the machine specifications.



When cutting very short pieces, make sure that they are not dragged behind the support shoulder, where they could jam in the blade.



When using the pneumatic vice (MA version) check that the jaws move right up to and effectively clamp the workpiece, as the maximum travel is only 8 mm, (0.31 in) and check that the clamping procedure is correct.



When working on the band saw, wear gloves only when handling materials and for tool changing or adjustment operations. Only perform one operation at a time and do not hold more than one item or operate more than one device simultaneously. Keep hands as clean as possible.



Warning: if the blade jams in the cut, press the emergency stop push- button immediately. If this does not free the blade, slowly loosen the vice, remove the piece and check the blade or blade teeth for breakage. Replace the blade if necessary.



Before carrying out any repair work on the machine, consult the Hyd-Mech Technical Assistance Service: this can be done through a representative in the country of use of the machine.



Adjustment of the blade- guide head must only be carried out with the machine at a standstill.

Machine safety devices

This use and maintenance manual is not intended as purely a guide for the use of the machine in a strictly productive environment, it is instead an instrument providing information on how to use the machine correctly and safely. The following standards are those specified by the EEC Committee in the directives regarding safety of machinery, health and safety at work, personal protection and safeguarding of the environment. These standards have been applied to the

H- 11A band saw.

Reference standards

MACHINE SAFETY

- EEC MACHINES DIRECTIVE 2006/42/CE ;
- EEC directive no. 89/336 "EMC - Electromagnetic Compatibility";
- EEC Directive No. 2006/95/CE known as "Low voltage directive".
- EN 13898:2003+A1:2009 Machine tools - Safety - Sawing machines for cold metal

HEALTH AND SAFETY AT WORK

- EEC Directive No. 80/1107; 83/477;86/188;88/188; 88/642 for the protection of workers against risks caused by exposure to physical, chemical and biological agents during working;
- EEC Directive No. 89/391 and Special EEC Directives No. 89/654 and No. 89/655 for improvements in health and safety at work;
- EEC Directive No. 90/394 for the protection of workers against risks deriving from exposure at work to carcinogenic substances;
- EEC Directive No. 77/576 and No. 79/640 on safety signs at work.

PERSONAL PROTECTION

- EEC Directive No. 89/656 and No. 89/686 on the use of personal protection devices.


ENVIRONMENTAL PROTECTION

- EEC Directive No. 75/442 on waste disposal;
- EEC Directive No. 75/439 on the disposal of used oil.
- Directive 2002/95/EC on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS).

Protection against accidental contact with the blade

1. front head sliding support: when the head is at maximum aperture, the support ensures that the blade is covered, leaving free only the part of the blade engaged in the actual cutting, in accordance with Presidential Decree no. 547/55, art. 108;
2. front protection doors, with electric limit switches, to enable the access to the cutting area only with stopped machine;
3. the cutting vice is started up by hydraulic devices, and the blocking of the piece occurs through a control panel key;

4. enclosure on the whole machine perimeter.



Electrical equipment

In accordance with Italian standard [CEI EN 60204- 1:2010](#), derived from European Standard [EN 60204- 1:2010](#):

- Access to electrical control panel limited by screws and panel- lock device, allowing panel to be opened only after the electricity supply has been turned off;
- 24 Vac Control voltage for actuators, in accordance with chapter 6 or European Standard "Control and indication circuits", paragraph 2 "Control Circuits" sub- section 1 "Preferential voltage values for control circuits";
- plant short- circuit protection by means of rapid fuses, earthing of all plant parts connected with work as well as all foreseeable accidental contact; a thermal- magnetic overload cutout switch shuts down the motor;
- protection from accidental start- up by a minimum voltage relay in case of power failure.

Emergency devices


In accordance with Standard [EN 60204- 1: 2010](#):

- **Chapter 5 Section 6 Sub- section 1 "Emergency stop device"**: «the emergency stop device immediately stops all the dangerous and other functions of the machine»;
- **chapter 6 Section 2 Sub- section 4 Point 7 "Protective guards"**: «the removal of protective guards designed to prevent access to dangerous parts or zones causes the machine to stop immediately; replacing the guards does not restart the functions, which must be reset».

...Emergency devices applicable to the H- 11A :

1. **Emergency stop**: a non- return mushroom- head pushbutton, colour red on yellow background, is located on the control panel of the machine. To release the pushbutton, the actuator must be rotated 45°. After the emergency situation has been resolved, the machine must be reset.
2. **Automatic thermal- magnetic cutout switch with thermal- magnetic relay**: the machine auto switch, has two protection systems against voltage drops. In the case of a voltage drop, all electrical components are disengaged, the machine stops immediately, and automatic restart when the power supply returns is inhibited. Another function is that of resetting the thermal relay provided to protect against overcurrents.
3. **Loading cell for band tensioning detection**: the machine stops immediately if the blade breaks or pressure in the tensioning cylinder drops.

4. **Blade guard** a coded- key micro- switch trips if the blade guard is inadvertently or intentionally opened during the machine operating cycle, causing the machine to shut down immediately.



Noise level of the machine

Noise can cause hearing damage and represents one of the problems faced by many countries who adopt their own standards. In accordance with the **EEC MACHINES DIRECTIVE 2006/42/CE**, we are listing the standards that specify noise levels for machine tools.

The following paragraph explains the modes and the detected sound power and pressure values released by the sawing machine.

These values comply with norm EN 13898:2003 + A1:2009, EN ISO 12001:2010 and EN ISO 4871:2009, concerning the rules for drawing and presenting a procedure for noise tests and the declaration and check of sound emission values by machines and equipment.

Noise level measurement

Noise levels are measured using an instrument known as an Integrator noise- meter which registers the equivalent continuous acoustic pressure level at the work station. The damage caused by noise depends on three parameters: level, frequency and duration. The equivalent level concept L_{eq} combines the three parameters and supplies just one indication. The L_{eq} is based on the principle of equal energy, and represents the continuous stationary level containing the same amount of energy, expressed in dBA, as that actually fluctuating over the same period of time. This calculation is made automatically by the integrator noise- meter. The measurements are taken every 60 seconds, in order to obtain a stabilised value. The reading stays on the display for a sufficient time to enable a reading to be taken by the operator. Measurements are taken by holding the instrument at approximately 1 metre from the machine at a height of 1.60 metres above the platform at the operator's work station. Two measurements are taken: the first while the machine operates without cutting anything, the second while cutting in manual mode.

Noise level values

Identification		
Machine type	Band saw for metal applications	
Model	H- 11A	
Reference standard	ISO 3746	
Results		
Test 1st	Description	Steel cut C40 - tube thickness Ø 250 s10 mm bi- metal blade 4500x34x1.1 mm
	Results	Mean sound level (Leq) 72,45 dB (A) Environmental correction (K) 3,84 dB(A) Peak sound power (Lw) 83,60 dB(A)
Test 2nd	Descriprion	Steel cut Fe37 - IPE 240 x 120 mm bi- metal blade 4500x34x1.1 mm
	Results	Mean sound level (Leq) 70,33 dB(A) Environmental correction (K) 3,84 dB(A) Peak sound power (Lw) 81,48 dB(A)
Test 3rd	Description	Ø 150 mm (5.90 in) solid tube in chromed stainless steel bi- metal blade 4500x34x1.1 mm
	Results	Mean sound level (Leq) 71,95 dB(A) Environmental correction (K) 3,84 dB(A) Peak sound power (Lw) 83,11 dB(A)

Vibration emission

This sawing machine complies with the norms EN1299 and EN1033, as the machine vibration emission on the devices controlled by the operator does not exceed the threshold of 2.5 m/s²

Electromagnetic compatibility

As from 1 January 1996 all electrical and electronic appliances bearing the CE marking that are sold on the European market must conform to Directive [CEE 2004/108/CE](#) e [2006/95/CE](#) and **EEC MACHINES DIRECTIVE 2006/42/CE** . The prescriptions regard two specific aspects in particular:

1. “EMISSIONS: during its operation, the appliance or system must not emit spurious electromagnetic signals of such magnitude as to contaminate the surrounding electromagnetic environment beyond clearly prescribed limits”;
2. “IMMUNITY: the appliance or system must be able to operate correctly even when it is placed in an electromagnetic environment that is contaminated by disturbances of defined magnitude”.

The following text contains a list of the applied standards and the results of the electromagnetic compatibility testing of machine model **H- 11A** ; Test report no. 011200.

Emissions

- CEI EN 61000- 6- 4 (2002): Electromagnetic Compatibility (EMC) - Part 6-4 Generic standard regarding emissions - Industrial Environment.
- EN 55011 (1999) Industrial, scientific, and medical radio frequency appliances (ISM). Characteristics of radio frequency disturbance - Limits and methods of measurement.
- EN 55014- 1 (2002) Electromagnetic Compatibility - Prescriptions for domestic appliances, electric power tools, and similar equipment. Part 1: Standard Emission in relation to product family.

CONDUCTED EMISSIONS				
Gate A	Freq. (MHz)	Q- peak limit (dBuV)	Mean value limit (dBuV)	Result
A.C. power supply input	0.15 - 0.5	79 - 73 (linear reduction with log of frequency)	66 - 60 (linear reduction with log of frequency)	Complies
	0.5 - 5	73	60	
	5 - 30	73	60	

IRRADIATED EMISSIONS			
Gate	Freq. (MHz)	Q- peak limit (10 m) (dBuV/m)	Result
Enclosure	30 - 230	40	Complies
	230 - 1000	47	

Immunity

- EN 50082-2 (1995) Electromagnetic Compatibility (EMC) - Part 6-2: Generic standard on immunity - Industrial Environment.
- EN 61000-4-2 + A1 (1996-1999) Electromagnetic Compatibility (EMC) - Part 4: Test and measurement techniques - Section 2: Electrostatic discharge immunity tests - Basic publication.
- EN 61000-4-3 Electromagnetic Compatibility (EMC) - Part 4: Test and measurement techniques. Section 3: Radiated, radio- frequency, electromagnetic field immunity test.
- EN 61000-4-4 (1996) Electromagnetic Compatibility (EMC) - Part 4: Test and measurement techniques - Section 4: Fast transients/bursts immunity tests - Basic publication.
- EN 61000-4-5 (1997) Electromagnetic Compatibility (EMC) - Part 4: Test and measurement techniques - Section 5: Surge immunity test.
- EN 61000-4-6 (1995) Electromagnetic Compatibility (EMC) - Part 4: Test and measurement techniques - Section 6: Immunity to conducted interference, induced by radio frequency fields.
- EN 61000-4-11 (1977) Electromagnetic Compatibility (EMC) - Part 4: Test and measurement techniques - Section 11: Voltage dips, short interruptions and voltage variations immunity tests.

IMMUNITY TO ELECTROSTATIC DISCHARGES			
Gate	Test levels	Evaluation criterion	Result
Enclosure	contact 4 kV steel plate 4 kV in air 8 kV	B	Complies

IMMUNITY TO VOLTAGE (BURSTS)			
Gate	Test levels	Evaluation criterion	Result
A.C. power supply input	2 kV	B	Complies


IMMUNITY TO HIGH VOLTAGE PULSES (Surge)			
Gate	Test levels	Evaluation criterion	Result
A.C. power supply input	1 kV (Phase - phase) 2 kV (Phase - earth)	B	Complies

IMMUNITY TO DIPS AND SHORT VOLTAGE INTERRUPTIONS (PQT)			
Gate	Test levels	Evaluation criterion	Result
A.C. power supply input	70% per 0.5 periods	B	Complies
	0% per 0.5 periods 40% per 5 periods 40% per 50 periods	B	

IMMUNITY TO CONDUCTED ELECTROMAGNETIC FIELDS			
Gate	Test levels	Evaluation criterion	Result
A.C. power supply input	10V	A	Complies

IMMUNITY TO IRRADIATED ELECTROMAGNETIC FIELDS			
Gate	Test levels	Evaluation criterion	Result
Enclosure	10 V/m	A	Complies


Machine installation



Packaging and storage

HYDMECH use packing materials that guarantee the integrity and protection of the machine during its transport to the customer.

The type of packing differs according to the size, weight and destination. Therefore the customer will receive the machine in one of two following ways:



5. on a pallet with straps and heat- shrink plastic;
6. on a pallet with straps, heat- shrink plastic and a wooden crate.

Warning


In both cases, for correct balancing the machine must be handled using a fork- lift truck, inserting the tines at the points indicated by the arrows, using the reference marks on the crate itself. The pallet length dimension is 110" (2794 mm). A minimum fork length of 48" (1219 mm) is recommended to safely lift the pallet.

Attention


Before carrying out lifting operations, make sure that the weight of the machine, as indicated on the crating or other packaging, is within the forklift truck load limit.

Attention

Do not handle the packed machine using slings.

**Attention**

When storing, machines palletized and shrink-wrapped must not be stacked two high, and machines palletized and crated must not be stacked two high.




To install the machine, first remove the packing, paying particular attention not to cut any electric wires or hydraulic hoses; if necessary use pliers, a hammer and a cutter.

Open crate in the illustrated order:

1. Remove the wrapping from around the saw.
2. Complete the inspection for signs of damage.



3. Remove the four lag bolts that hold the saw to the pallet (these will be used when anchoring the machine). The larger diameter hole is used for retaining during shipping and for use with concrete floor anchors. The smaller diameter, threaded holes are used for leveling the saw.



4. The machine should be lifted from the each side high enough to place some blocks under each corner. The machine can then be lifted off of the pallet from the front side using **FORK EXTENSIONS - 72"** (1829 mm).



To locate the machine in the workplace, **the machine dimensions** and necessary operator working space, including **the spaces laid down** in safety standards, **must be taken into account.**


Levelling and anchoring the machine

Use the bolts provided to level the machine after it is taken off the skid. Levelling bolts have been used to mount machine to skid. The two back bolts were replaced with lags.



The base of the machine is anchored to the floor by two permanent studs located on the sides of the base. The studs are screwed into nuts previously sunk into the


concrete, and tightened from above with lock nuts. The schematic specifications set out in Chapter 1 should be taken into account when positioning the machine.



Auger set up

The Auger motor has been taken off of the auger trough for shipping purposes; it must be reassembled to the auger and trough as follows.

- Remove through bolt from chip screw and remove 4 bolt from auger support




- Re-insert the shaft of the motor- reducer and tighten through bolt, orient motor in the vertical position, use the 4, 10 mm headed cap screws (in end of trough) to attach motor to trough).



- Auger assembly must be slid into machine and held in place by allen headed bolts provided.



- Power and control plugs have different alignment tabs and different terminal configurations, as shown in the following photographs. They must be inserted in the proper location.



Minimum requirements

For the machine to function correctly, the room in which it is to be installed must satisfy the following requirements:

- power supply voltage/frequency: refer to the values on the rating plate;
- temperature of machine location: from - 10 to + 50 °C;
- relative humidity: not more than 90%
- lighting: not less than 500 Lux.

Warning

The machine is already protected against voltage variations, but will only run trouble-free if the variations do not exceed $\pm 10\%$.

Check list

Before starting installation, check that all the accessories, whether standard or optional, supplied with the machine are present. The basic version of the **H- 11A** machine is supplied complete with:

CHARACTERISTICS	STANDARD	OPTIONAL
The bow is made from alloy cast iron to give more stability to the machine and also for longer blade duration	✓	
Bow runs on linear guides with ball- bearing slides	✓	
Bow movement with hydraulic cylinder on linear guides with ball- recirculating slides	✓	
Protection from contact with the machine's moving parts (see drawing with overall dimensions)	✓	
Blade 4500 x 34 x 1,1 mm (177.16x1.34x0.04 in)	✓	
Hydraulic vertical vice*		✓
Cabinet for electrical and electronic equipment with totally identifiable cabling	✓	
Control and enabling system protected from electrical or electromechanical hazard at input and output	✓	
Simplified touchscreen control panel managed by next- generation Hyd- Mech controlled designed exclusively for Hyd- Mech sawing machines	✓	
Programmable head travel limit via control panel according to dimensions of bars to be cut	✓	
Software to control, assess and correct in real time the shearing stress, the shearing torque and the blade tensioning.	✓	
M50 controller with EC Windows operating system	✓	
Laser projector to position the bar accurately to carry out non- standard or facing cuts and lamp for lighting the cutting area	✓	
Control keyboard to reach positions from which the operator can perform operations with safety and maintain visual control	✓	
Control from keyboard to move the pulley for belt substitution	✓	
Pneumatic control unit for self- registering forward	✓	
Emergency with signalling of open blade door with interlocked safety limit switches	✓	
Electro- mechanical actuator and dynamic control for the blade tightening	✓	
Inverter for continuous blade speed regulation single range from 15 to 115 m/min (49÷377 ft/min)	✓	
Motor- driven chip ejector	✓	
Vertical roller table pair		✓
Great quantities of cutting liquid (230 lt/min)	✓	
Steel blade- guiding cutting heads, with rollers and recordable hard metal slides, can be open for easier blade substitution, with prepared nozzles for traditional lubrication and minimal lubrication (optional)	✓	
Automatic adjustment of the front blade- guide head according to the dimensions of the bars to be cut to make the blade as stable as possible and to protect its section not involved in the cutting	✓	
Brush for cleaning the blade	✓	
Band rotation control with immediate stop system in case of tool blockage	✓	
Feed roller table K110HD		✓
Discharge roller table K110HD		✓
Acoustic signal and flashing light device for machine- stop	✓	
Feed device with recirculating ball/lead screw with 600 mm (23.62 in)	✓	

CHARACTERISTICS	STANDARD	OPTIONAL
Maximum non- feedable bar waste 120 mm (4.72 in)	✓	
Self- aligning feed vice for bar feed (Including deformed bars)	✓	
Work table spray gun	✓	
Coolant tank incorporated in pedestal	✓	
Pair of electric pumps for the band lubrication and cooling.	✓	
Coolant flow for conveying chips	✓	
Cutting oil 5 lt		✓
Jaws to reduce scraps to max. 20 mm (0.79 in)*		✓
Blade deviation control*		✓
Vice pressure adjustment		✓
Special vertical clamps complete with jaws for reducing scrap		✓
Software update and changes through USB: insert in the suitable port on the control console	✓	
Min. lubrication system		✓
Machine preset for being handled by lift truck	✓	
Bi- metal blade for section and solid cuts		✓
Wrenches, Instruction Manual, complete with spare parts order form in corresponding user language	✓	

*ACCESSORIES AVAILABLE ON REQUEST

The bag of accessories is enclosed in the machine before being packed and contains:

- hex wrenches 3/4/5/6/10 mm (0.12/0.16/0.20/0.24/0.39 in)
- 10 mm (0.39 in) socket wrench;
- 36 mm (1.42 in) wrench;
- blade cleaning brushes;
- use and Maintenance manual, including order form for parts in relevant user language.


Connection to the power supply

Before connecting the machine to the power supply, check that the socket is not connected in series with other machines. This requirement is fundamental for the good operation of the machine.


To connect the machine to the power supply, proceed as follows:

- connect the power supply cable of the machine to a plug which matches the socket to be used. (EN 60204- 1; par. 5.3.2)

CONNECTION FOR "5-CORE" WIRE SYSTEMS WITH NEUTRAL



CONNECTION FOR "4-CORE" WIRE SYSTEMS WITH NEUTRAL




Attention

When using systems with a neutral wire, special care must be taken when connecting the **blue** neutral wire, in that if it is connected to a phase wire it will discharge the **phase voltage** to the equipment connected for **voltage: phase-neutral**.


- Insert the plug in the socket, ensuring that the mains voltage is the same as that for which the machine has been setup.

VOLT ?

VOLT ?




- Power the machine, rotating the main switch on the console left side (the control console lights up).



Attention

Ensure that the blade moves in the correct direction as shown in the above figure. If it does not, simply reverse two of the phase wires on the machine power supply input.



The sawing machine is now ready to start the work for which it was designed. Chapter 5 provides a detailed description of the various functions of the machine and its operating cycles.

Description of machine operation




This chapter analyses all the machine functions. We begin with a description of the pushbuttons and other components on the control panel.

Description of the control panel


The control console is housed inside the control panel, a tamperproof IP 54 protection class housing sealed against dust and moisture. The control panel swivels on two articulated joints so that it can be positioned as required by the operator for greater ease- of- use and safety. The control board of the **H- 11A** is shown in the picture below:




Key of control console keyboard




RESET:
Press to reactivate machine functions after an alarm.




EMERGENCY STOP:
This button will stop both the hydraulic and blade motors. The head motion will cease. The vises remain as they are, but if closed, they will lose gripping force. For this reason all long stock should be supported so that it will not fall. To reset the button, simply rotate through 45°.




ENABLE COMMANDS:
Hold pressed to enable machine commands.




JOYSTICK:
is enabled to move the head upwards and downwards and to move the feeder forwards and backwards, when the control enabling button is pressed.




FEED RATE POTENTIOMETER:
Adjusts the head feeding speed.



FEED FORCE POTENTIOMETER:
Potentiometer for adjusting the blade motor max. absorption.



BLADE SPEED POTENTIOMETER:
Potentiometer for the continuous adjustment (inverter) of the band rotation speed.



FAST ADVANCE:
key for the fast advancing of the head and of the feeder.



USB PORT:
Communication port for the software update and the machine diagnostics

THERMAL - MAGNETIC CIRCUIT - BREAKER WITH UNDERVOLTAGE COIL

On the left side of the control board, the machine is equipped with a main switch that, when set ON (1), powers the machine.

The main switch is fitted with three power failure protection systems. In fact, in the event of a power failure, this switch disconnects all the electrical devices, causing the machine to immediately shut down, and prevents it from automatically starting up again when power is restored. This device also resets the thermal relay fitted to protect against current overloads.


Basic instructions for carrying out a cutting operation cycle

Blade tension


To increase blade life it is recommended to tension the blade at the beginning of the work shift and to detension it at the end.

The saw machine cannot work if the blade tensioning value is not within 600 and 1250 kg (1320- 2750 lbs) range (default values within machine parameters).

- Open the door on the left side of the machine.




- Turn the hand wheel clockwise to increase the tension of the blade and check the value in kg on the display (the optimal value during the working phase is 1250 kg / 2750 lbs).




To check the blade tensioning value it is necessary to get in the second working screen:

- From the first working screen, touch the green arrow on the display to get in the second working screen.


Next page






Moving the cutting head up and down

The feeding head can be moved upwards and downwards using the joystick; if you hold the fast advance key pressed at the same time the cutting head moves faster.




Manoeuvring the feeder

The feeder can be moved using the joystick, only if the head is completely up. If you hold the fast advance key pressed at the same time the feeder moves faster.




Symbol key

The key for the symbols used on the display follows.



Pressing the “Next page” key, you can display the second machining screen:




Operating parameters

During the machining cycle, by pressing the box in the figure, it is possible to check the machine operating parameters:

FF = Feed Force, value of the cutting force that can be set through the potentiometer from the control board.

FR = Feed Rate, value of the cutting head lowering speed that can be set through the potentiometer from the control board.

BS = Blade Speed, value of the band rotation speed that can be set through the potentiometer from the control board.



Pressing the arrow key shown in the figure the second page of the operating parameters can be displayed:

Kerf = blade thickness


Blade deviation = deviation blade

Act BT = Actual Blade Tension, current value of blade tension;


Act AMP = Actual Ampere, current value of motor absorption;

PCT = Partial Cutting Time;

TCT = Total Cutting Time.




N.B. Pressing the key shown in the figure the decimal metric measuring system or the Imperial measuring system can be set. After making the change of measurement system, you still need to set again the values of Set-up machine as indicated in Chapter 7.



Warning


The machine is provided of "Blade deviation control" that allows to monitoring in real time the blade flexion, showing an alarm over the display. The diagram shows the left and right range of the blade deviation, green when the deviation is within +/- 5 and yellow when it is within +/- 10. If the value exceeds the range, the diagram shows a red color and the machine stops. It is recommended to check the blade tension, blade speed based on the hardness of the material, the blade wear and the blade guides wear, or the setting of the blade guide components.



Excessive deviation

Strong deviation

Moderate deviation





To enable or disable the control deviation blade must enter SET-UP and set the operation in "BLADE DEVIATION" as indicated in Chapter 7.

Cutting cycles

This sawing machine can carry out single or series cuts stored in max. 10 programs, that can even be repeated, to be ordered in a preset sequence.

- After the initialization of the sawing machine the display shows the following screen. Press the box shown in the figure until the symbol of the wished cycle is displayed.



The available machining cycles are: manual, automatic with single program and automatic with continuous program.


In the manual cycle the cutting only involves the setting of the rear head limit switches (RHLS) and forward head limit switches (FHLS); then, after having positioned the material at the wished cutting length, start by the Cut start key (F7).

As for the automatic cycle, it can operate with single or automatic program.


Cutting stroke setting

To set the cutting stroke it is necessary to determine the RHLS (rear head limit switch) and FHLS (forward head limit switch) points.


- To set the RHLS point just press the cycle start key (F7), after having pressed the band rotation enabling key (F6), to start the band rotation and the head lowering: in this way the RHLS (rear head limit switch) point is automatically stored and determines the head start position when the cycle is started.



- To set the FHLS after having set the RHLS point, delete the existing FHLS point lowering the head using the joystick; the FHLS setting box (F2) starts flashing to indicate that the FHLS point has been deleted.




- When the head reaches the wished cutting end point, press the FHLS setting key (F2) shown in the figure, the corresponding box lights up to indicate that it has been set.




Width of cut

The machine is fitted with protections that protect the entire blade stroke leaving only the part of the blade required to make the cut itself exposed. This includes the rear (fixed) head and the front (mobile) head, as required by current standards.

The cutting width is automatically adapted with the positioning of the cutting vice on the loading side.



N.B. The machine is equipped with a lamp for lighting the working table and with a laser projector to aid the machine positioning under the blade vertical. These options can be selected by pressing once or more times the same key (F1) on the icon left.



Preliminary check list for cutting operation


To guarantee complete safety during cutting cycles, the operator should work through a check list of the entire apparatus, checking:

- ▶ blade tension;
- ▶ that the work piece is properly clamped in place;
- ▶ that the blade teeth are correct for the job to be begun;
- ▶ that the speed selected is right for the kind of piece to be cut;
- ▶ that all protections are in place and correctly locked;
- ▶ the level of lubricant/coolant and that the electropump is activated;


Manual operating cycle

The operation sequence for running a manual cutting cycle:


- ▶ power up the machine by turning the main switch;
- ▶ Tap on the box with the on symbol on the touchscreen.




- ▶ press reset and release the emergency mushroom button if pressed, the head rises completely
- ▶ Zero the feeder by pressing the key shown in figure (F5).




- ▶ Position the material inside the feeding vice.
- ▶ Close the feeding vice by pressing the relevant key on the console.




- ▶ Feed the material being machined and move it using the joystick. The machine is equipped with a lamp for lighting the working table and with a laser projector to aid the machine positioning under the blade vertical.



- Close the front vice by holding down the corresponding key from the control panel.




- Select the manual machining mode, pressing the box shown in the figure on the touch screen.




- Set the cutting parameters, previously shown, using the following adjusters.




- Set the fluid jet by pressing the button shown in the figure (F2). The box will light up to indicate that it is selected. Adjust the amount using the valves on the blade guide head. Press the button repeatedly to select the dispensing mode (automatic or manual).



- Position the head at approximately 10 mm (0.39 in) from the workpiece.
- Press the band rotation enabling key (F6).




- Press the cycle start key (F7) to start the band rotation and the head lowering at the set speeds. The RHLS point is automatically stored in this way, as explained before.




N.B. If the existing FHLS point is to be deleted now, follow the operations described above.


- When the head reaches the FHLS point the band stops and the head returns to the set RHLS point, ready to make a new cutting cycle.
- Open both vices by holding the open vices button. Then feed the workpiece, as already explained, and finally close the front vice by holding down the corresponding key from the control panel.




- Enable the band rotation by pressing the key shown in the figure (F6), the box lights on to indicate it has been selected.



- Start the cutting cycle pressing the key shown in the figure (F7), the band starts turning and the machine cuts. At the cut end, the head rises again, ready for a new machining cycle.




N.B. Tap on the touchscreen box shown in the figure to see problems during operation. The box will turn blue to indicate caution and red to indicate a machine alarm. See chapter 10 for a complete list of alarms.




Automatic mode single job

The operation sequence for running in automatic mode and single job:


- ▶ power up the machine by turning the main switch;
- ▶ tap on the box with the on symbol on the touchscreen;




- ▶ press reset and release the emergency mushroom button if pressed, the head rises completely.
- ▶ Zero the feeder by pressing the key shown in figure (F5).




- ▶ Position the material inside the feeding vice.
- ▶ Close the feeding vice by pressing the relevant key on the console.




- ▶ Position the workpiece, moving it by the joystick.




- Close the front vice by holding down the corresponding key from the control panel.



- Select the automatic machining mode with single program, pressing the box shown in the figure on the touch screen.




- Set the wished length and the wished number of cuts pressing the boxes shown in the figure and entering the values on the keypad that pops up automatically.




- Set the cutting parameters, previously shown, using the following adjusters.



- Set the fluid jet by pressing the button shown in the figure (F2). The box will light up to indicate that it is selected. Adjust the amount using the valves on the blade guide head. Press the button repeatedly to select the dispensing mode (automatic or manual).




- Position the head at approximately 10 mm (0.39 in) from the workpiece.
- Press the band rotation enabling key (F6).



- Press the cycle start key (F7) to start the band rotation and the head lowering at the set speeds. The RHLS point is automatically stored in this way, as explained before.

N.B. If the existing FHLS point is to be deleted now, follow the operations described above.




The sawing machine makes the programmed cuts. At the end, the head rises again and the band motor stops.

Automatic mode queue


The operation sequence for running in automatic mode queue:

- ▶ power up the machine by turning the main switch;
- ▶ tap on the box with the on symbol on the touchscreen;




- ▶ press reset and release the emergency mushroom button if pressed, the head rises completely.


N.B. If previous machinings have been made already and the feeder has not been zeroed, zero it pressing the key shown in the figure.




- ▶ Position the material inside the feeding vice.
- ▶ Close the feeding vice by pressing the relevant key on the console.




- ▶ Position the workpiece, moving it by the joystick.




- Close the front vice by holding down the corresponding key from the control panel.




- Select the automatic machining mode with continuous program, pressing the box shown in the figure on the touch screen.




- Press the RUN/PROG key to access the programming page for the automatic operation with continuous program.




- The display shows the following screen listing all programs (max. 10). Press the program number to select the one to be set.



- Press to edit all values of “Part Number” (company identification code), “Length” (piece length), and “Nr. Pieces” (number of pieces) using the keypad.




- In the end choose to activate or deactivate the selected by “Enable” (Yes / No).




N.B. Press the F1 key to zero the program queue.
Press the F5 key to zero the piece number.

Before returning to the machining screen, press the data saving key and then the green arrow shown in the figure.




- Set the fluid jet by pressing the button shown in the figure. The box will light up to indicate that it is selected. Adjust the amount using the valves on the blade guide head. Press the button repeatedly to select the dispensing mode (automatic or manual).



- Set the cutting parameters, previously shown, using the following adjusters.




- Position the head at about 10 mm (0.39 in) from the material being machined, moving it with the joystick.
- Press the band rotation enabling key (F6).




- Press the F7 cycle start key to start the band rotation and the head lowering. The RHLS point is automatically stored in this way, as explained before. At the end, the band stops and the head rises again.

N.B. If the existing FHLS point is to be deleted now, follow the operations described above.



The sawing machine then feeds new material performing all the program cuts and continues with the set sequence. If the machining cycle must be stopped, press F8 Cycle Stop. To start it again, press F7 Cycle Start.



































Diagrams, exploded views and replacement parts



This chapter contains functional diagrams and exploded views of the **H- 11A** . This document is intended to help in identifying the location of the various components making up the machine, giving information useful in carrying out repair and maintenance operations; This chapter will also enable the user to order replacement parts with no risk of misunderstanding, as all parts are given codes.



[illegible]


REV	MODIFICA	DATA	FRME	Dis. N. H11A	Impianto/Plant	Ordine/Requisition	Foglio/Page
				CAD SPAC	Schematic H-11A_480/60Hz	Commessa/Order	2
				File	Denominazione/Title	H-11A	Segue/follow
				H11A\1.dwg	INDICE CONTENUTI	Esecutore/Executor	3
				Data	Content index	Solfanelli	Ultimo/Last
				28/01/2015			211


0	1	2	3	4	5	6	7	8	9
Sim.\Sym.	File	Descrizione\Description	Sim.\Sym.	File	Descrizione\Description	Sim.\Sym.	File	Descrizione\Description	
	H5	Lampada Lamp		S7	Comando a pedale NO Control pedal NO		BLK13	Azionamento (potenzal) Drive (power)	
	H11	LED Led		S13C	Fine corsa comandato a camma libero NC Limit switch free NC		BLK14	Inverter (ausiliari) Inverter (auxiliary)	
	M2	Motore asincrono trifase Three-phase inductor motor		S14C	Fine corsa comandato a camma azionato NC Limit switch actuated NC		BLK15	Azionamento (ausiliari) Drive (auxiliary)	
	M9	Motore corrente alternata monofase Single-phase inductor motor		S15C	Comandato dal livello di un fluido (livellostatol) NC Water gauge NC		BLK21	Motore passo-passo Stepper motor	
	Q1360	Int. automatico magnetotermico sezionatore tripolare Three-phase automatic switch		T2	Trasformatore per ausiliari con schermo Transformer for auxiliary white shield		BLK41	Raccordo SX Connector SX	
	R1	Resistore Resistor		Y1	Elettrovalvola (A) Solenoid valve (A)		BLK42	Raccordo DX Connector DX	
	R6	Potenzimetro Potentiometer		Y1A	Elettrovalvola (B) Solenoid valve (B)		BLK43	Tubo corrugato Corrugated pipe	
	R60	Potenzimetro Potentiometer		KA1	Bobina rele' Aux Auxiliary relay coil		BLK44	Riduzione PG PG adapter	
	S2	Comando a Pulsante NO Push button NO		KM1	Bobina contattore Contactor coil		BLK51	Dado PG PG nut	
	S4C	Pulsante di emergenza NC Emergency push button NC		BLK11	Trasformatore per ausiliari con schermo Transformer for auxiliary white shield		BLK56	Terminale a puntale Terminal	
	S5	Comando rotativo a due posizioni NO Rotary selector two position		BLK12	Inverter (potenzal) Inverter (power)		BLK57	Filo unipolare Wire	
REV.	MODIFICA	DATA	FIRME	Dis. N. H11A CAD SPAC File H11A\1.dwg Data 28/01/2015	Impianto/Plant Schematic H- 11A_480/60Hz Denominazione/Title LEGENDA SIMBOLI Symbol Key	Ordine/Requisition Commissa/Order H- 11A Esecutore/Executor Solfanelli	 Foglio/Page 3 Segue/Follow 4 Ultimo/Last 211		

[illegible]








REV.	MODIFICA	DATA	FIRME	Dis. N. H11A	Impianto/Plant	Schematic H-11A_480/60Hz		Ordine/Requisition		Foglio/Page 6
						CAD SPAC	Commissa/Order H-11A			
						File H11A\1.dwg	Denominazione/Title ALIMENTAZIONE MOTORI 480V			
						Data 28/01/2015	Executor/Executor Solfanelli			
							Motor Power Supply 480V			





Foglio/Page 11		Segue/Follow 12		Ultimo/Last 211	
Ordine/Requisition		Commissa/Order H-11A		Esecutore/Executor Solfanelli	
Impianto/Plant		Schematic H-11A_480/60Hz		Denominazione/Title RELE SICUREZZA EMERGENZA Emergency safety relay	
Dis. N. H11A		CAD SPAC		File H11A\1.dwg	
REV.		MODIFICA		DATA 28/01/2015	




REV.	MODIFICA	DATA	FIRME	Dis. N. H11A	Impianto/Plant	Schematic H-11A_480/60Hz	Ordine/Requisition		Foglio/Page
									12
									Segue/Follow
									13
									Ultimo/Last
211									










QgCv - -XQG1


QgCv - -XQG2


SCATOLA DI GIUNZIONE 1

SCATOLA DI GIUNZIONE 2




0	1	2	3	4	5	6	7	8	9		
CAVI ESTERNI \ EXTERNAL CABLES											
QUADRO \ BOARD		ID SUL CAVO ID IN CABLE		CAVO CABLE	LUNGHEZZA LENGHT [m']	DISTURBO NOISE LEVEL	ID SUL CAVO ID IN CABLE	DESTINAZIONE \ LOCATION			
QUADRO BOARD	FOGLIO SHEET	NR. MORSETTO TERMINAL NO.	NR. FILO CONDUCTOR NO.					NR. MORSETTO TERMINAL NO.	NR. FILO CONDUCTOR NO.	FOGLIO SHEET	QUADRO BOARD
=QgCv - XQG4	18/7	049	049				BK	CN3	049	18/7	OUT05
=QgCv - XQG4	18/7	055	055				BN	CN3	055	18/7	OUT06
=QgCv - XQG4	11/1	360	360				GY	2	360	11/1	OUT15
=QgCv - F19	19/8		352				BU	CN5	352	19/8	
							GN				
=QgCv - XQG4	18/6	048	048				YE		048	18/6	OUT04
=QgCv - XQG4	17/3	051	051		1,5Mt		WH	O 051	051	16/6	=QgCv - XQG2
=QgCv - XQG4	11/2	0360	0360		Output controller cable		VT	1	0360	11/1	
=QgCv - XQG2	13/7	052	052				RD	O 052	052	16/3	=QgCv - XQG2
=QgCv - F18	19/7		351				OG	CN5	351	19/7	OUT14
							RD-BU				
							WH-BU				
							Sch				
=QgCv - XQG4	16/7	036	036				BK		036		IN06
=QgCv - XQG4	16/6	0393	0393				BN	CN15	0393	16/7	IN05
=QgCv - XQG4	16/2	031	031				GY	CN15	031	16/6	IN00
=QgCv - XQG4	17/3	051	051				BU	051	051	16/2	
=QgCv - XQG4	17/4	333	333				GN	CN18	333	17/9	IN11
							YE			17/4	
=QgCv - XQG4	17/4	0391	0391		1,5Mt		WH	CN18	0391	17/4	IN10
					Input-output cable		VT				
=QgCv - XQG4	17/3	052	052				RD	CN17	052	17/1	24VCC
=QgCv - XQG4	16/3	033	033				OG	CN15	033	16/3	IN01
							RD-BU				
							WH-BU				
							Sch				
		Dis. N. H11A		Impianto/Plant		Ordine/Requisition		Foglio/Page			
		CAD SPAC		Schematic H- 11A_480/60Hz		Commissa/Order		29			
		File H11A\1.dwg		Denominazione/Title		H- 11A		Segue/Follow			
		Data 28/01/2015		RIASSUNTIVO CAVI		Esecutore/Executor		211			
		DATA		Cable Summary		Solfanelli		Ultimo/Last			
REV.	MODIFICA	FIRME									






0	1	2	3	4	5	6	7	8	9
CAVI ESTERNI \ EXTERNAL CABLES									
QUADRO \ BOARD		ID SUL CAVO ID IN CABLE		CAVO CABLE		LUNGHEZZA LENGHT [m]		DISTURBO NOISE LEVEL	
QUADRO BOARD	FOGLIO SHEET	NR. MORSETTO TERMINAL NO.	NR. FILO CONDUCTOR NO.	ID SUL CAVO ID IN CABLE		CAVO CABLE		LUNGHEZZA LENGHT [m]	
DESTINAZIONE \ LOCATION		NR. MORSETTO TERMINAL NO.		NR. FILO CONDUCTOR NO.		FOGLIO SHEET		QUADRO BOARD	
=QgCv -XQG4		19/7	044	BK	044	3.00Mt		19/7	
=QgCv -XQG2		19/3	60	BK2	60	SV head down cable		19/7	
=QgCv -XQG4		18/8	050	BK	050	4.00Mt		18/8	
=QgCv -XQG2		10/3	60	BK2	60	Minimal lubrication cable		18/8	
=QgCv -X100		6/2	124	BK1	124	5.00Mt		6/1	
=QgCv -X100		6/2	126	BK2	126	-W2 022.1983		6/1	
=QgCv -X100		6/3	128	BK3	128	Blade motor cable		6/1	
=QgCv -XQGPE		6/2	PE	GNVE	PE	Sch		6/1	
=QgCv -X100		6/2	PE	Sch	PE	Sch		6/1	
=QgCv -XQGPE		5/4	PE	GN-RD	PE	7.00Mt		21/7	
=QgCv -XQG2		13/7	052	BN-BU	052	-W20 022.1905		21/7	
0V		21/7	051	WH-BK	051	Strain gauge cable		21/7	
=QgCv -XQGPE		21/8	027	YE-OG	027	Sch		21/8	
=QgCv -XQGPE		5/4	PE	Sch	PE	Sch		21/7	
=QgMep -XR0		20/3	sh	GN-RD	sh	3.00Mt		20/4	
=QgMep -XR0		20/2	023	BN-BU	023	-W21 022.1905		20/1	
=QgMep -XR0		20/2	025	WH-BK	025	Head potentiometer cable		20/2	
=QgMep -XR0		20/2	024	YE-OG	024	Sch		20/3	
=QgMep -XR0		20/3	sh	Sch	sh	Sch		20/4	
=BmMep -S0		16/2	052	BN	052	10.00Mt		16/2	
=QgCv -XQG4		16/2	031	BK	031	-W27 022.04.22		4	
=BmMep -S0		16/2	3	BU	051	Blade proximity cable		4	
=SaCv		22/1	314	GN-RD	314	3.00Mt		22/1	
=SaCv		22/2	311	BN-BU	311	-W28 022.1905		22/3	
=SaCv		22/2	312	WH-BK	312	Stepper head cable		22/3	
=SaCv		22/1	313	YE-OG	313	Sch		22/2	
SCH		22/1	SCR	Sch	SCR	Sch		22/2	

Foglio/Page 31		Ordine/Requisition		Impianto/Plant Schematic H- 11A_480/60Hz		Dis. N. H11A		Foglio/Page 32	
Segue/Follow 211		Commissa/Order H- 11A		Denominazione/Title RIASSUNTIVO CAVI		CAD SPAC		Ultimo/Last 211	
		Esecutore/Executor Solfaelli		Cable Summary		File H11A\1.dwg			
REV.		MODIFICA		DATA		FIRME			




0	1	2	3	4	5	6	7	8	9
CAVI ESTERNI \ EXTERNAL CABLES									
QUADRO \ BOARD		ID SUL CAVO		CAVO	LUNGHEZZA	DISTURBO	ID SUL CAVO	DESTINAZIONE \ LOCATION	
QUADRO BOARD	FOLGIO SHEET	NR. MORSETTO TERMINAL NO.	NR. FILO CONDUCTOR NO.	CAVO CABLE	LUNGHEZZA LENGHT (m f)	DISTURBO NOISE LEVEL	ID SUL CAVO ID IN CABLE	NR. MORSETTO TERMINAL NO.	QUADRO BOARD
=QgCv -U10	9/3	A1	221				BK	221	
=QgCv -U10	9/3	A1	222				BK1	222	=BmMep -M8
=QgCv -U10	9/3	B1	223	-W29 022.1979	5.00Mt		BK2	223	=BmMep -M8
=QgCv -U10	9/3	B2	224	Power stepper motor cable			BK3	224	=BmMep -M8
=QgCv -XQGPE	9/2	5_9	PE				GNYE	PE	=BmMep -M8
=QgCv	14/2	14	0314				GN-RD		
=QgCv	14/2	20	0320	-W29/1 022.1905	2.00Mt		BN-BU	0314	ST+
=QgCv	14/2	15	0315	Drive step motor cable			WH-BK	0320	SCH
SCH	22/5	CN8	U8-SHIELD				YE-06	0315	DR+
=QgCv -JB	14/5	010	010				GN-RD		
=QgCv -JB	14/5	011	011	-W29/2 022.1905	2.00Mt		BN-BU	010	
=QgCv -JB	14/5	012	012	Powered conveyor cable			WH-BK	011	14/2
=QgCv -JB	14/5	PE	T3				YE-06	012	14/2
24 VDC	18/4	CN2	261				BK	261	
=QgCv -K6	18/5	21	1055	-W30 022.1980	4.00Mt		BK2	1055	=QgMep -S23
=QgCv -XQG2	13/7	052_2	052				BN	052	
A13a	21/5	CN26	028	-W32 022.0355	5.00Mt		BK	028	=BmMep -B1
0V	21/4	CN26	051	Blade deviation sensor cable			BU	051	=BmMep -B1
=QgCv -XQG4	18/4	053	053				BK	053	
=QgCv -XQG2	10/3	60_2	60	-W37 022.1980	5.00Mt		BK2	60	=BmMep -H3
=QgCv -Q-K4	6/4	T1	015				BK1	015	
=QgCv -Q-K4	6/4	T2	016	-W4 022.1981	5.00Mt		BK2	016	=BmMep -M2
=QgCv -Q-K4	6/4	T3	017	Coolant pump cable			BK3	017	=BmMep -M2
=QgCv -XQGPE	6/5	5_4	PE				GNYE	PE	=BmMep -M2


Foglio/Page		32	
Segue/Follow		33	
Ultimo/Last		211	
REV.		MODIFICA	
DATA		FRYE	
Dis. N. H11A		CAD [SPAC]	
File		H11A\1.dwg	
Data		28/01/2015	
Impianto/Plant		Schematic H-11A_480/60Hz	
Ordine/Requisition		Commissa/Order	
Commissa/Order		H-11A	
Esecutore/Executor		Solfanelli	
Denominazione/Title		RIASSUNTIVO CAVI	
Cable Summary			



0	1	2	3	4	5	6	7	8	9																
CAVI ESTERNI \ EXTERNAL CABLES																									
QUADRO \ BOARD				ID SUL CAVO ID IN CABLE			CAVO CABLE			LUNGHEZZA LENGHT [m]		DISTURBO NOISE LEVEL		ID SUL CAVO ID IN CABLE		NR. FILO CONDUCTOR NO.		DESTINAZIONE \ LOCATION		NR. MORSETTO TERMINAL NO.		FOGLIO SHEET		QUADRO BOARD	
QUADRO BOARD	FOGLIO SHEET	NR. MORSETTO TERMINAL NO.	NR. FILO CONDUCTOR NO.	ID SUL CAVO ID IN CABLE		CAVO CABLE		LUNGHEZZA LENGHT [m]		DISTURBO NOISE LEVEL		ID SUL CAVO ID IN CABLE		NR. FILO CONDUCTOR NO.		DESTINAZIONE \ LOCATION		NR. MORSETTO TERMINAL NO.		FOGLIO SHEET		QUADRO BOARD			
=QgCv -XQG2	10/3	60_2	60	GN-RD	GN-RD	-W56 022..1905 FC right guard cable	5.00Mt	GN-RD	GN-RD	60	11	12/0	=BmMep -S1												
=QgCv -XQG4	12/1	661	661	BN-BU	BN-BU			661	22	12/1	=BmMep -S1														
=QgCv -XQG4	12/0	660	660	WH-BK	WH-BK			660	12	12/0	=BmMep -S1														
=QgCv -XQG2	10/3	1	261	YE-OG	YE-OG			261	21	12/1	=BmMep -S1														
				Sch	Sch																				
=QgCv -XQG4	12/1	1660	1660	GN-RD	GN-RD	-W57 022..1905 FC left guard cable	5.00Mt	GN-RD	GN-RD	1660	12	12/0	=BmMep -S2												
=QgCv -XQG4	12/1	661	661	BN-BU	BN-BU			661	21	12/1	=BmMep -S2														
=QgCv -XQG4	12/0	660	660	WH-BK	WH-BK			660	11	12/0	=BmMep -S2														
=QgCv -XQG4	12/1	1661	1661	YE-OG	YE-OG			1661	22	12/1	=BmMep -S2														
				Sch	Sch																				
=QgCv -XQG4	12/1	1660	1660	GN-RD	GN-RD	-W58 022..1905 FC blade tens. guard cable	5.00Mt	GN-RD	GN-RD	1660	22	12/2	-S3												
=QgCv -XQG4	12/2	2661	2661	BN-BU	BN-BU			2661	11	12/2	=BmMep -S8														
=QgCv -XQG4	12/2	2660	2660	WH-BK	WH-BK			2660	21	12/2	-S3														
=QgCv -XQG4	12/1	1661	1661	YE-OG	YE-OG			1661	12	12/2	=BmMep -S8														
				Sch	Sch																				
=QgCv -R-S2	12/5	CS AR-24	3660	GN-RD	GN-RD	-W58/2 022..1905 FC shuttle guard cable	5.00Mt	GN-RD	GN-RD	3660	21	12/2	-S1												
=QgCv -XQG4	12/2	2661	2661	BN-BU	BN-BU			2661	12	12/2	=BmMep -S9														
=QgCv -XQG4	12/2	2660	2660	WH-BK	WH-BK			2660	22	12/2	-S1														
=QgCv -R-S2	12/5	CS AR-24	3661	YE-OG	YE-OG			3661	11	12/2	=BmMep -S9														
				Sch	Sch																				
=QgCv -XQG4	17/4	0391	0391	BN	BN	-W59 022.04.22 Bar in infeed vice limit switch	5.00Mt	BN	BN	0391		17/4	=BmMep -S10												
=QgCv -XQG4	17/3	052	052	BK	BK			052		17/4	=BmMep -S10														
				BU	BU																				
				WH	WH																				
=QgCv -XQG4	19/5	044/0	54	BK	BK	-W65 022.1980 S.V Block head	5.00Mt	BK	BK	54	1	19/5	=QgCv -X40												
=QgCv -XQG2	19/3	1	60	BK2	BK2			60	2	19/5	=QgCv -X40														
REV.	MODIFICA			DATA	FIRME																				
Impianto/Plant				Schematic H- 11A_480/60Hz				Ordine/Requisition				Foglio/Page													
Dis. N. H11A				CAD [SPAC]				Commissa/Order				Segue/Follow													
File H11A\1.dwg				Denominazione/Title				Esecutore/Executor				Ultimo/Last													
Data 28/01/2015				RIASSUNTIVO CAVI				Solfanelli				211													
				Cable Summary																					



0	1	2	3	4	5	6	7	8	9
CAVI ESTERNI \ EXTERNAL CABLES									
QUADRO \ BOARD		ID SUL CAVO ID IN CABLE		CAVO CABLE	LUNGHEZZA LENGHT [mt]	DISTURBO NOISE LEVEL	ID SUL CAVO ID IN CABLE	DESTINAZIONE \ LOCATION	
QUADRO BOARD	FOLIO SHEET	NR. MORSETTO TERMINAL NO.	NR. FILO CONDUCTOR NO.					NR. MORSETTO TERMINAL NO.	QUADRO BOARD
=QgCv -XFET	7/3	1 C	1021				BK1	1021	
=QgCv -XFET	7/3	2 C	1022	-W7 022.1981	5.00Mt		BK2	1022	7/3 =QgCv -Q-K6R
=QgCv -XFET	7/3	3 C	1023	Chip conveyour cable			BK3	1023	7/3 =QgCv -Q-K6R
=QgCv -XFET	7/3	PE C	7				GNVE	7	7/4 =QgCv -XQGPE
=QgEMep XMET	7/3	1 C	1024				BK1	1024	
=QgEMep XMET	7/3	2 C	1025	-W7/1 022.1981	2.00Mt		BK2	1025	7/3 =QgEMep -M5
=QgEMep XMET	7/3	3 C	1026	Chip conveyour cable			BK3	1026	7/3 =QgEMep -M5
=QgEMep XMET	7/3	PE C	7				GNVE	7	7/3 =QgEMep -M5
=QgCv -XQG4	19/2	042 O	042	-W90 022.1980	3.00Mt		BK	042	
=QgCv -XQG2	10/3	60 2 O	60	SV cutting vice closing cable			BK2	60	19/2 =QgCv -X009 19/3 =QgCv -X009
=QgCv -XQG4	19/4	047 O	047	-W91 022.1980	3.00Mt		BK	047	
=QgCv -XQG2	19/3	1 O	60	SV shuttle vice closing cable			BK2	60	19/4 =QgCv -X011 19/4 =QgCv -X011
=QgCv -XQG4	19/2	041 O	041	-W92 022.1980	3.00Mt		BK	041	
=QgCv -XQG2	19/3	1 O	60	SV cutting vice opening cable			BK2	60	19/2 =QgCv -X008 19/1 =QgCv -X008
=QgCv -XQG4	19/3	046 O	046	-W93 022.1980	3.00Mt		BK	046	
=QgCv -XQG2	19/3	1 O	60	SV shuttle vice opening cable			BK2	60	19/3 =QgCv -X010 19/3 =QgCv -X010
=QgCv -F19	19/8	1 O	1352	-W95 022.1980	5.00Mt		BK	1352	
=QgCv -XQG2	19/8	1 O	60	Work zone lamp cable			BK2	60	19/8 =BmMep -H2 19/8 =BmMep -H2
=QgCv -XTL	19/7	3 C	1351	-W96 022.1980	5.00Mt		BK	1351	
=QgCv -XTL	19/7	1 C	60	Laser cable			BK2	60	19/7 =QgCv -F18 19/8 =QgCv -XQG2

									Foglio/Page 34
									Segue/Follow 35
									Ultimo/Last 211
REV.	MODIFICA	DATA	FRME	Dis. N. H11A	Impianto/Plant	Ordine/Requisition			
				CAD [SPAC]	Schematic H-11A_480/60Hz	Commissa/Order H-11A			
				File H11A\1.dwg	Denominazione/Title RIASSUNTIVO CAVI	Esecutore/Executor Solfanelli			
				Data 28/01/2015	Cable Summary				

[illegible]

Nome/ Name	Mep_Ita- ly_code	Mep_Chin a_code	Description EN	Quadro/ Board	Fg/Sh	Q.ta/Q.ty	Costrutto- re/Sup- plier
-OLM	090.1601	A000069	Spray mist oil system for Shark	=BmLmCv	25	1	Mep
-K27		E001002	Hydraulic electrovalve 4/3 close center CETOP3 24Vdc	=BmMep	19	1	Mep
-K29		E001002	Hydraulic electrovalve 4/3 close center CETOP3 24Vdc	=BmMep	19	1	Mep
-K31		E001002	Hydraulic electrovalve 4/3 close center CETOP3 24Vdc	=BmMep	19	1	Mep
-K40		H000026	Hydraulic electrovalve 2/2 NC 1/4"G 24Vdc	=BmMep	19	1	Mep
-M1		P00002-4 80	Motor 4.0KW, 277/480V, 12/6,97A	=BmMep	6	1	Mep
-M2		P00003-4 80	Electropump 120W, V=2800rpm, 480V/60Hz	=BmMep	6	1	Mep
-M5		P000008	Motor 0,37KW, 240/480V, 1,77/0,89A	=QgEt- Mep	7	1	Mep
-M20		P000004- 480	Motor oil unit 1.3KW, 240/480V, 5,0/2,5A	=BmMep	6	1	Mep
-M8	019.3408	P000001	Stepper Motor 21Nm 13A 1,8° FL110STH150-1304A-H-1	=BmMep	9	1	FULLING
-M9	019.3555	P000007	Stepper motor 1,9Nmt 2,8A 1,8°	=BmMep	22	1	FULLING
-XEV		E000400	Fixed connector ILME (CK03VS + CKF04) 5 poles	=BmMep		1	ILME
-XEV1		E000399	Mobile connector ILME (CK03VS + CKM04) 5 poles	=BmMep		1	ILME
-S0		E000013	Proximity PNP (long) with connec- tor M12	=BmMep	16	1	Mep
-S52		E000013	Proximity PNP (long) with connec- tor M12	=BmMep	16	1	Mep
-B1		E000015	Inductive sensor 0-16mA / 1-2,5mm	=BmMep	21	1	Mep
-S10		E000004	Limit Switch with roll 1NO+1NC	=BmMep	17	1	Mep
-S47		E000004	Limit Switch with roll 1NO+1NC	=BmMep	17	1	Mep
-S1		E000018	Limit Switch with fork 2NC	=BmMep	12	1	EATON
-S2		E000018	Limit Switch with fork 2NC	=BmMep	12	1	EATON
-S8		E000018	Limit Switch with fork 2NC	=BmMep	12	1	EATON
-S9		E000018	Limit Switch with fork 2NC	=BmMep	12	1	EATON
-V1		E000011	Laser Line Sign	=BmMep	19	1	Mep
-R5		E000003	Linear potentiometer 500mm	=BmMep	20	1	NOVO- TECNICK
-H3		E000012	Flashing 24Vac x SH NC	=BmMep	18	1	Mep
-H2		E000010	Led Lamp	=BmMep	19	1	Mep
-Q0		E003053- 480	Disconnect switch three-poles 20A	=QgCv	5	1	Mep
-QD1		A000048	Carpentry general electric panel	=QgCv	27	1	Mep
-R10		E001000	Resistor 1W 680ohm	=QgCv	21	1	RS
-X100		E000014- 480	Variable frequency drive DELTA 5.5KW, 400-480V	=QgCv	6	1	DELTA
-Z1		E002903	Ferrites Toroids N30 r40	=QgCv	23	1	RS
-R-M20	010.3749	E003749	Anthracite Knob with HydMech Icon	=QgCv	24	1	Mep
-R-M21	010.3749	E003749	Anthracite Knob with HydMech Icon	=QgCv	24	1	Mep
-R-M25	010.3753	E003753	Silver Knob with HydMech Icon	=QgCv	21	1	Mep
-M7		M000080	Support for driver fan cooler	=QgCv	10	1	Mep
-M6		E005220	Cover for fan cooler 120x120	=QgCv	10	1	Mep
-M7		E005221	Cover for fan cooler 80x80	=QgCv	10	1	Mep
-M6		E005220	Fan cooling 120x120 24Vdc	=QgCv	10	1	Mep
-M7		E005221	Fan cooling 80x80 - 24Vdc	=QgCv	10	1	Mep
-FS1		E000226	Plastic clamp 140x3,5	=QgCv	27	1	Mep
-R-M25		E001816	Potentiometer 10K single turn	=QgCv	21	1	Mep
-FL1		E000133	Single wire AWG20 CSA (0.5mmq)	=QgCv	27	1	Mep
-FL2		E000134	Single wire AWG16 CSA (1.5mmq)	=QgCv	27	1	Mep
-XFET		E004001	Fixed connector ILME (CK03VS + CKF03) 4 poles	=QgCv		1	ILME
-NM1		E000290	Cable maker and wire	=QgCv	27	1	Mep
-NM2		E000290	Cable maker and wire	=QgCv	27	1	Mep
-CC1		E000218	Wire Terminal Connection Red	=QgCv	27	1	Mep
-CC2		E000214	Wire Terminal Connection Red	=QgCv	27	1	Mep
-PT1		E000394	Wire Terminal Connection White	=QgCv	27	1	Mep
-PT3		E000395	Wire Terminal Connection Black	=QgCv	27	1	Mep
-XTL	022.0376		Connector F303N5000	=QgCv		1	Mep
-X008		E000429	Connector for solenoid valve DC	=QgCv	19	1	Mep


-X009		E000429	Connector for solenoid valve DC	=QgCv	19	1	Mep
-X010		E000429	Connector for solenoid valve DC	=QgCv	19	1	Mep
-X011		E000429	Connector for solenoid valve DC	=QgCv	19	1	Mep
-X012		E000429	Connector for solenoid valve DC	=QgCv	19	1	Mep
-X014		E000429	Connector for solenoid valve DC	=QgCv	19	1	Mep
-X40		E000429	Connector for solenoid valve DC	=QgCv	19	1	Mep
-BR1		E000222	Omega guide	=QgCv	27	1	Mep
-CN1		E000157	Cable holding plastic channel	=QgCv	27	1	Mep
-CN2		E000157	Cable holding plastic channel	=QgCv	27	1	Mep
-G1	022.0908	E000016	Switching power supply Vi 240-400-500VAC Vu 24Vcc 14A	=QgCv	8	1	Adelsys-tem
-S3		E000911	Carrier for pushbutton	=QgCv	17	1	Mep
-S4		E000911	Carrier for pushbutton	=QgCv	11	1	Mep
-S18		E000911	Carrier for pushbutton	=QgCv	17	1	Mep
-S54		E000932	Normally open contact	=QgCv	17	4	Mep
-S4		E000936	Normally close contact	=QgCv	11	3	Mep
-S3		E000937	Normally open contact	=QgCv	17	4	Mep
-S18		E000937	Normally open contact	=QgCv	17	1	Mep
-KRES		E002393	Relay 24 VCC - 2 exchange con- tacts + base	=QgCv	12	1	FINDER
-S4		E001245	Emergency push button	=QgCv	11	1	Mep
-R-M20	022.1322	E001322	Panel encoder Mep 50	=QgCv	24	1	Mep
-R-M21	022.1322	E001322	Panel encoder Mep 50	=QgCv	24	1	Mep
-U10	022.1330	E001230	Driver for step motor (60VAC.10A) + modbus	=QgCv	9	1	SHS
-S18		E001405	Black push button	=QgCv	17	1	Mep
-S3		E001408	Blue push button	=QgCv	17	1	Mep
-T2		E000020-	Transformer UL/CSA 500VA, Vin 480 0-240-480/ Vout 0-60,0-220V	=QgCv	8	1	Mep
-FL3		E001995	Cable 1AWG12 NERO	=QgCv	27	1	Mep
-FL2		E001996	Cable 1AWG12 GN/YE	=QgCv	27	1	Mep
-R0		E000005	Electronic tensioner 3,5T (strain gauge)	=QgCv	21	1	DELTA-TECK
-AL		E000229	Terminal 6mmq for 3 wires - PHOENIX	=QgCv		4	Mep
-F5 -F6		E002239	Fuse holding terminal 3 x (10,3x38) 690V 32A	=QgCv	6	1	BUSS-MANN
-F7		E002239	Fuse holding terminal 3 x (10,3x38) 690V 32A	=QgCv	6	1	BUSS-MANN
-F20		E002239	Fuse holding terminal 3 x (10,3x38) 690V 32A	=QgCv	6	1	BUSS-MANN
-F21 -F22		E002240	Fuse holding terminal 2 x (10,3x38) 690V 32A	=QgCv	8	1	BUSS-MANN
-F1 -F2		E002240	Fuse holding terminal 2 x (10,3x38) 690V 32A	=QgCv	8	1	BUSS-MANN
-F3 -F4		E002240	Fuse holding terminal 2 x (10,3x38) 690V 32A	=QgCv	8	1	BUSS-MANN
-XQG2		E000144	Terminal 2,5mmq for 4 wires - PHOENIX	=QgCv		13	Mep
-F14		E000139	Fuse holding terminal 1 x (10,3x38) 690V 32A	=QgCv	8	1	BUSS-MANN
-F15		E000139	Fuse holding terminal 1 x (10,3x38) 690V 32A	=QgCv	8	1	BUSS-MANN
-F16		E000139	Fuse holding terminal 1 x (10,3x38) 690V 32A	=QgCv	8	1	BUSS-MANN
-F17		E000139	Fuse holding terminal 1 x (10,3x38) 690V 32A	=QgCv	8	1	BUSS-MANN
-F18		E000139	Fuse holding terminal 1 x (10,3x38) 690V 32A	=QgCv	19	1	BUSS-MANN
-F19		E000139	Fuse holding terminal 1 x (10,3x38) 690V 32A	=QgCv	19	1	BUSS-MANN
-JB		E000142	Single pole spring terminal ST 2.5	=QgCv		10	PHOENIX
-XQG1		E000229	Triple pole spring terminal ST4	=QgCv		6	PHOENIX
-XQG4		E000142	Single pole spring terminal ST 2.5	=QgCv		29	PHOENIX
-XQPE		E000146	Double pole spring terminal 4,0mmq PE	=QgCv		4	PHOENIX
-XQPE		E002263	Quadruple pole spring PE terminal 6,0mmq	=QgCv		3	PHOENIX
-XQG4		E002270	Closure plate single-terminal	=QgCv		1	PHOENIX
-XQG1		E000147	Closure plate double-terminal	=QgCv		1	PHOENIX
-JB		E000149	Closure plate single-terminal	=QgCv		1	PHOENIX
-XQG2		E000149	Closure plate quadruple-terminal	=QgCv		1	PHOENIX
-CU1	022.2825	E000002	Controller Mep50C	=QgCv	15	1	ISAC
-K6		E003011	Contacteur 3KW NC (24 V Dc)	=QgCv	18	1	Shilhin electric
-K6R		E003011	Contacteur 3KW NC (24 V Dc)	=QgCv	18	1	Shilhin electric
-K4		E003012	Contacteur 3KW NO (24 V Dc)	=QgCv	18	1	Shilhin electric

-K65		E003012	Contactor 3KW NO (24 V Dc)	=QgCv	18	1	Shilhin electric
-R- S1	022.3811	E000009	Safety relay 4NO, 1NC cat.3	=QgCv	11	1	PIZZATO
-R-S2	022.3811	E000009	Safety relay 4NO, 1NC cat.3	=QgCv	12	1	PIZZATO
-Q-K65		E002541	Termal overload 2,5-4.1A	=QgCv	6	1	Shilhin electric
-Q-K6R		E000610	Termal overload 0.7-1.1A	=QgCv	7	1	Shilhin electric
-Q-K4		E000406	Termal overload 0.3-0.5A	=QgCv	6	1	Shilhin electric
-S54		E003920	Joystic 4 positions unstable with unlocking	=QgCv	17	1	ABB
-K6R		E003924	Kit for contactor reversing	=QgCv	18	1	Mep
-CU1	022.4091	E004091	Cable USB for command panel with connector	=QgCv	15	1	EATON
-R-M20		E000235	Ring 'NI-18-25-4.5	=QgCv	24	1	Mep
-R-M21		E000235	Ring 'NI-18-25-4.5	=QgCv	24	1	Mep
-R-M25		E000235	Ring 'NI-18-25-4.5	=QgCv	21	1	Mep
-TF2		E000209	Control panel gasket	=QgCv	27	1	Mep
-M6		E005220	Fan filter 120x120	=QgCv	10	1	Mep
-TF1	031.2622		Replace fuse adhesive sign	=QgCv	27	1	Mep
-M6		E005220	Fan filter 120x120	=QgCv	10	1	Mep
-M6		E005220	Base for fan cooling 120x120	=QgCv	10	1	Mep
-F3 -F4		E004538	Fuse Time delay 10.3x38 - 5A UL/CSA	=QgCv	8	2	Mep
-F5 -F6 -F7		E004538	Fuse Time delay 10.3x38 - 5A UL/CSA	=QgCv	6	3	Mep
-F15		E004538	Fuse Time delay 10.3x38 - 5A UL/CSA	=QgCv	8	1	Mep
-F16		E004538	Fuse Time delay 10.3x38 - 5A UL/CSA	=QgCv	8	1	Mep
-F18		E004659	Fuse Time delay 10.3x38 - 0.5A UL/CSA	=QgCv	19	1	Mep
-F14		E004664	Fuse Time delay 10.3x38 - 7.5A UL/CSA	=QgCv	8	1	Mep
-F17		E004673	Fuse Time delay 10.3x38- 1A UL/CSA	=QgCv	8	1	Mep
-F19		E004675	Fuse Time delay 10.3x38 - 2A UL/CSA	=QgCv	19	1	Mep
-F1 -F2		E004676	Fuse Time delay 10.3x38 - 3.5A UL/CSA	=QgCv	8	2	Mep
-F20 -F21 -F22		E004677	Fuse Time delay 10.3x38 - 20A UL/CSA	=QgCv	6	3	Mep
XMET		E004002	Mobile connector ILME (CK03VS + CKM03) 4 poles	=QgEt-Mep		1	ILME
-XR0		E000369	Connector 3 poles for strain gauge	=QgMep		1	Mep
-XS7		E000369	Connector 3 poles for strain gauge	=QgMep		1	Mep
-S23		E000911	Carrier for pushbutton	=QgMep	18	1	Mep
-S23		E000937	Normally open contact	=QgMep	18	1	Mep
-S23		E001405	Black push button	=QgMep	18	1	Mep
-PT1		E000150	Bridge for 2 terminals	=QgCv		6	Mep
-PT1		E000151	Bridge for 3 terminals	=QgCv		2	Mep
-W7/B1		E001397	Cable with M12 90° connector: lenght 5Mt	=BmCv		2	MEP
-W120		E001905	Cable shielded 4x2 Awg24 CSA	=BmCv		2.5	MEP
-W118		E001906	Cable shielded 6x2 Awg24 CSA	=QgCv		3	MEP
-W7/1		E001981	Cable 4G AWG18 OIL RESISTANT UL 2587 CSA	=BmCv		2	MEP
-W20		E001905	Cable shielded 4x2StA-wg24(0.20mmq) UL 2587 CSA	=QgCv		7	MEP
-W28		E001905	Cable shielded 4x2StA-wg24(0.20mmq) UL 2587 CSA	=QgCv		3	MEP
-W29/1		E001905	Cable shielded 4x2StA-wg24(0.20mmq) UL 2587 CSA	=QgCv		2	MEP
-W29/2		E001905	Cable shielded 4x2StA-wg24(0.20mmq) UL 2587 CSA	=QgCv		2	MEP
-W56		E001905	Cable shielded 4x2StA-wg24(0.20mmq) UL 2587 CSA	=QgCv		5	MEP
-W57		E001905	Cable shielded 4x2StA-wg24(0.20mmq) UL 2587 CSA	=QgCv		5	MEP
-W58		E001905	Cable shielded 4x2StA-wg24(0.20mmq) UL 2587 CSA	=QgCv		5	MEP


































-W58/2		E001905	Cable shielded 4x25 AWG24(0.20mmq) UL 2587 CSA	=QgCv		5	MEP
-W32		E000393	Cable with straight connector M8. L=5Mt	=QgCv		5	MEP
-W121		E000398	Straight connector M12 10MT cable 4x0.34mmq	=QgCv		10	MEP
-W27		E000397	Cable with M12 90° connector; Length: 10Mt	=QgCv		10	MEP
-W59		E000397	Cable with M12 90° connector; Length: 10Mt	=QgCv		10	MEP
-W117		E001906	Cable shielded 6x2 AWG24 CSA	=QgCv		1	MEP
-W117/1		E001906	Cable shielded 6x2 AWG24 CSA	=QgCv		1	MEP
-W119		E001906	Cable shielded 6x2 AWG24 CSA	=QgCv		3	MEP
-WS12		E001906	Cable shielded 6x2 AWG24 CSA	=QgCv		4	MEP
-W29		E001979	Cable 5G AWG16 UL 2587 CSA	=QgCv		5	MEP
-W30		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		4	MEP
-W37		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		5	MEP
-W39		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		5	MEP
-W65		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		5	MEP
-W90		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		3	MEP
-W91		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		3	MEP
-W92		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		3	MEP
-W93		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		3	MEP
-W95		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		5	MEP
-W96		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		5	MEP
-W122		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		5	MEP
-W123		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		3	MEP
-W124		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		3	MEP
-W125		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		4	MEP
-W4		E001981	Cable 4G AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		5	MEP
-W7		E001981	Cable 4G AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		5	MEP
-W11		E001981	Cable 4G AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		4	MEP
-W7/B		E001982	Cable 3xAWG18ST OIL RESISTANT UL 2587 CSA	=QgCv		5	MEP
-W1		E001983	Cable 4G X AWG12 shielded	=QgCv		5	MEP
-W2		E001983	Cable 4G X AWG12 shielded	=QgCv		5	MEP
FL1		E000133	Single pole wire AWG20 CSA	=QgCv		33	MEP
FL2		E000134	Single pole wire AWG16 CSA	=QgCv		15	MEP
FL3		E001995	Single pole wire AWG12 CSA	=QgCv		15	MEP

0	1	2	3	4	5	6	7	8	9
LISTA FOGLI \ INDEX									
Foglio Sheet	Descrizione Description	Revisione \ Revision							
		0	1	2	3	4	5	6	7
		8	9						
1	INDICE CONTENUTI								
	Content Index								
2	INDICE CONTENUTI								
	Content Index								
3	LEGENDA SIMBOLI								
	Symbol Key								
4	LEGENDA SIMBOLI								
	Symbol Key								
5	ALIMENTAZIONE								
	Power Supply								
6	ALIMENTAZIONE MOTORI 480V								
	Motor Power Supply 480V								
7	ALIMENTAZIONE MOTORI 480V								
	Motor Power Supply 480V								
8	ALIMENTAZIONE TRASFORMATORI								
	Transformer Power Supply								
9	ALIMENTAZIONE MOTORE STEPPER								
	Stepper Motor Power Supply								
10	ALIMENTAZIONE AUSILIARI								
	Auxiliary Circuit Power Supply								
11	RELE SICUREZZA EMERGENZA								
	Emergency safety relay								
12	RELE SICUREZZA RIPARI								
	Machine Guard Safety Relay								
13	AUSILIARI INVERTER								
	Inverter Auxiliary Circuits								
Note :									

REV.	MODIFICA	DATA	FIRME	Dis. N. H11A	Impianto/Plant	Ordine/Requisition	Foglio/Page		
				CAD	Schematic H-11A_240/60Hz	Commissa/Order	1		
				File	Denominazione/Title	H-11A	Segue/Follow		
				Data	INDICE CONTENUTI	Esecutore/Executor	2		
				07/02/2015	Content Index	Solfanelli	Ultimo/Last		
							211		





0	1	2	3	4	5	6	7	8	9
LISTA FOGLI \ INDEX									
Foglio Sheet	Descrizione Description	Revisione \ Revision							
		0	1	2	3	4	5	6	7
		8	9						
27	INTERNO QUADRO								
	Board inside								
28	RIASSUNTIVO CAVI								
	Cable summary								
29	RIASSUNTIVO CAVI								
	Cable Summary								
30	RIASSUNTIVO CAVI								
	Cable Summary								
31	RIASSUNTIVO CAVI								
	Cable Summary								
32	RIASSUNTIVO CAVI								
	Cable Summary								
33	RIASSUNTIVO CAVI								
	Cable Summary								
34	RIASSUNTIVO CAVI								
	Cable Summary								
35	RIASSUNTIVO CAVI								
	Cable Summary								
36	RIASSUNTIVO CAVI								
37	DISTINTA MATERIALI								
	Material List								
38	DISTINTA MATERIALI								
	Material List								
39	DISTINTA MATERIALI								
	Material List								
Note :									
		Dis. N. H11A		Impianto/Plant		Ordine/Requisition		Foglio/Page	
		CAD		Schematic H- 11A_240/60Hz		Commissa/Order		2	
		File H11A\1.dwg		Denominazione/Title		H- 11A		Segue/Follow	
		Data 07/02/2015		INDICE CONTENUTI		Esecutore/Executor		Ultimo/Last	
REV.		MODIFICA		Content Index		Solfanelli		211	


0	1	2	3	4	5	6	7	8	9
Sim.\Sym.	File	Descrizione\Description	Sim.\Sym.	File	Descrizione\Description	Sim.\Sym.	File	Descrizione\Description	
	H5	Lampada <i>Lamp</i>		S7	Comando a pedale NO <i>Control pedal NO</i>		BLK13	Azionamento (potenza) <i>Drive (power)</i>	
	H11	LED <i>Led</i>		S13C	Fine corsa comandato a camma libero NC <i>Limit switch free NC</i>		BLK14	Inverter (ausiliari) <i>Inverter (auxiliary)</i>	
	M2	Motore asincrono trifase <i>Three-phase inductor motor</i>		S14C	Fine corsa comandato a camma azionato NC <i>Limit switch actuated NC</i>		BLK15	Azionamento (ausiliari) <i>Drive (auxiliary)</i>	
	M9	Motore corrente alternata monofase <i>Single-phase inductor motor</i>		S15C	Comandato dal livello di un fluido (livellostat) NC <i>Water gauge NC</i>		BLK21	Motore passo-passo <i>Stepper motor</i>	
	Q1360	Int. automatico magnetotermico sezionatore tripolare <i>Three-phase automatic switch</i>		T2	Trasformatore per ausiliari con schermo <i>Transformer for auxiliary white shield</i>		BLK41	Raccordo SX <i>Connector SX</i>	
	R1	Resistore <i>Resistor</i>		Y1	Elettrovalvola (A) <i>Solenoid valve (A)</i>		BLK42	Raccordo DX <i>Connector DX</i>	
	R6	Potenzionetro <i>Potentiometer</i>		Y1A	Elettrovalvola (B) <i>Solenoid valve (B)</i>		BLK43	Tubo corrugato <i>Corrugated pipe</i>	
	R60	Potenzionetro <i>Potentiometer</i>		KA1	Bobina rele' Aux <i>Auxiliary relay coil</i>		BLK44	Riduzione PG <i>PG adapter</i>	
	S2	Comando a Pulsante NO <i>Push button NO</i>		KM1	Bobina contattore <i>Contact coil</i>		BLK51	Dado PG <i>PG nut</i>	
	S4C	Pulsante di emergenza NC <i>Emergency push button NC</i>		BLK11	Trasformatore per ausiliari con schermo <i>Transformer for auxiliary white shield</i>		BLK56	Terminale a puntale <i>Terminal</i>	
	S5	Comando rotativo a due posizioni NO <i>Rotary selector two position</i>		BLK12	Inverter (potenza) <i>Inverter (power)</i>		BLK57	Filo unipolare <i>Wire</i>	


REV.	MODIFICA	DATA	FIRME	Dis. N. H11A	Impianto/Plant	Ordine/Requisition	Foglio/Page
				CAD [SPAC]	Schematic H-11A_240/60Hz	Commissa/Order H-11A	3
				File H11A\1.dwg	Denominazione/Title	Esecutore/Executor	Segue/Follow 4
				Data 07/02/2015	LEGENDA SIMBOLI Symbol Key	Solfanelli	Ultimo/Last 211


[illegible]












⊗ 1 COLLEGARE I MORSETTI (450-470 e 451-471) SE NON SONO PRESENTI RULLIERE IN ALIMENTAZIONE
WITHOUT POWERED CONVEYOR IN CONTACT CONNECT (450-470 and 451-471) TERMINALS




Schematic H-11A_240/60Hz
RELE SICUREZZA EMERGENZA
Emergency safety relay


Dis. N. H11A
CAD [SPAC]
File H11A\1.dwg
Data 07/02/2015


DATA


FIRME


MODIFICA


















REV.	MODIFICA	DATA	FIRME	07/02/2015	Data	H11A\1.dwg	File	SPAC	CAD	H11A	Dis. N.	Impianto/Plant			Schematic H-11A_240/60Hz	Ordine/Requisition		 Commessa/Order H- 11A Esecutore/Executor Solfanelli	Foglio/Page
																22			
																Segue/Follow			
																23			
																Ultimo/Last			
																	211		



[illegible]





[illegible]





0	1	2	3	4	5	6	7	8	9					
CAVI ESTERNI \ EXTERNAL CABLES														
QUADRO \ BOARD				DESTINAZIONE \ LOCATION										
QUADRO BOARD	FOGLIO SHEET	NR. MORSETTO TERMINAL NO.	NR. FILO CONDUCTOR NO.	ID SUL CAVO ID IN CABLE	CAVO CABLE	LUNGHEZZA LENGHT (m)	DISTURBO NOISE LEVEL	ID SUL CAVO ID IN CABLE	NR. MORSETTO TERMINAL NO.	FOGLIO SHEET	QUADRO BOARD			
=QgCv -U10	9/3	A1	221	BK	-W29_022.1979 Power stepper motor cable	5.00Mt		BK	221	9/3	=BmMep -M8			
=QgCv -U10	9/3	A1	222	BK1				BK1	222	BIA/GIA	9/3	=BmMep -M8		
=QgCv -U10	9/3	B1	223	BK2				BK2	223	GIALLO	9/4	=BmMep -M8		
=QgCv -U10	9/3	B2	224	BK3				BK3	224	ARANCIO	9/4	=BmMep -M8		
=QgCv -XQGPE	9/2	5_9	PE	GNVE				GNVE	PE	BIA/ARA	9/4	=BmMep -M8		
=QgCv	14/2	14	0314	GN-RD	-W29/1_022.1905 Drive step motor cable	2.00Mt		GN-RD	0314	22/8	ST+			
=QgCv	14/2	20	0320	BN-BU				BN-BU	0320	CN8	22/5	SCH		
=QgCv	14/2	15	0315	WH-BK				WH-BK	0315	CN8	22/7	DR+		
SCH	22/5	CN8	U8-SHIELD	Sch				Sch						
=QgCv -JB	14/5	010	010	GN-RD	-W29/2_022.1905 Powered conveyor cable	2.00Mt		GN-RD	010	14/2	=QgCv			
=QgCv -JB	14/5	011	011	BN-BU				BN-BU	011	10	14/2	=QgCv		
=QgCv -JB	14/5	012	012	WH-BK				WH-BK	012	11	14/2	=QgCv		
=QgCv -JB	14/5	012	13	YE-OG				YE-OG	13	12	14/2	=QgCv		
	14/5	PE	PE	Sch				Sch						
24VDC	18/4	CN2	261	BK	-W30_022.1980 Reverse run clip-conveyor cable	4.00Mt		BK	261	18/5	=QgMep -S23			
=QgCv -K6	18/5	21	1055	BK2				BK2	1055	3	18/5	=QgMep -S23		
=QgCv -XQG2	13/7	052_2	052	BN				-W32_022.0355 Blade deviation sensor cable	5.00Mt		BN	052	21/4	=BmMep -B1
A13a	21/5	CN26	028	BK							BK	028	4	21/5
0V	21/4	CN26	051	BU	BU	051	3				21/5	=BmMep -B1		
=QgCv -XQG4	18/4	053	053	BK	-W37_022.1980 Flashing cable	5.00Mt					BK	053	18/4	=BmMep -H3
=QgCv -XQG2	10/3	60_2	60	BK2				BK2	60		18/4	=BmMep -H3		
=QgCv -Q-K4	6/4	T1	015	BK1				-W4_022.1981 Coolant pump cable	5.00Mt		BK1	015	6/4	=BmMep -M2
=QgCv -Q-K4	6/4	T2	016	BK2							BK2	016	U	6/4
=QgCv -Q-K4	6/4	T3	017	BK3	BK3	017	V				6/4	=BmMep -M2		
=QgCv -XQGPE	6/5	5_4	PE	GNVE	GNVE	PE	W				6/4	=BmMep -M2		
							PE				6/4	=BmMep -M2		


REV.	MODIFICA	DATA	FIRME	Data	07/02/2015	Denominazione/Title RIASSUNTIVO CAVI Cable Summary	Impianto/Plant Schematic H-11A_240/60Hz	Ordine/Requisition	Foglio/Page
								Compresso/Order	32
								H-11A	Segue/follow
								33	
								Ultimo/Last	211



REV.	MODIFICA	DATA	FIRME	07/02/2015	Denominazione/Title RIASSUNTIVO CAVI Cable Summary	Impianto/Plant Schematic H- 11A_240/60Hz	Ordine/Requisition				Foglio/Page 32
							Commissa/Order H- 11A				
							Esecutore/Executor Solfanelli				
							Dis. N. H11A				Segue/Follow 33
							CAD	SPAC			
							File	H11A\1.dwg			
							Data				
											Ultimo/Last 211







Nome/ Name	Mep_Ita- ly_code	Mep_Chin a_code	Description EN	Quadro/ Board	Fg/Sh	Q.ta/Q.ty	Costruttore/ Supplier
-OLM	090.1601	A000069	Spray mist oil system for Shark	=BmLmCv	25	1	Mep
-K27		E001002	Hydraulic electrovalve 4/3 close center CETOP3 24Vdc	=BmMep	19	1	Mep
-K29		E001002	Hydraulic electrovalve 4/3 close center CETOP3 24Vdc	=BmMep	19	1	Mep
-K31		E001002	Hydraulic electrovalve 4/3 close center CETOP3 24Vdc	=BmMep	19	1	Mep
-K40		H000026	Hydraulic electrovalve 2/2 NC 1/4"G 24Vdc	=BmMep	19	1	Mep
-M1		P00002-2	Motor 4.0KW, 133/240V, 25,1/14,5A	=BmMep	6	1	Mep
-M2		P00003-2	Electropump 120W, V=2800rpm, 240V/60Hz	=BmMep	6	1	Mep
-M5		P000008	Motor 0,37KW, 240/480V, 1,77/0,89A	=QgEt-Mep	7	1	Mep
-M20		P000004-240	Motor oil unit 1.3KW, 240/480V, 5,0/2,5A	=BmMep	6	1	Mep
-M8	019.3408	P000001	Stepper Motor 21Nm 13A 1,8° FL110STH150-1304A-H-1	=BmMep	9	1	FULLING
-M9	019.3555	P000007	Stepper motor 1,9Nmt 2,8A 1,8°	=BmMep	22	1	FULLING
-XEV		E000400	Fixed connector ILME (CK03VS + CKF04) 5 poles	=BmMep		1	ILME
-XEV1		E000399	Mobile connector ILME (CK03VS + CKM04) 5 poles	=BmMep		1	ILME
-S0		E000013	Proximity PNP (long) with connector M12	=BmMep	16	1	Mep
-S52		E000013	Proximity PNP (long) with connector M12	=BmMep	16	1	Mep
-B1		E000015	Inductive sensor 0-16mA / 1-2,5mm	=BmMep	21	1	Mep
-S10		E000004	Limit Switch with roll 1NO+1NC	=BmMep	17	1	Mep
-S47		E000004	Limit Switch with roll 1NO+1NC	=BmMep	17	1	Mep
-S1		E000018	Limit Switch with fork 2NC	=BmMep	12	1	EATON
-S2		E000018	Limit Switch with fork 2NC	=BmMep	12	1	EATON
-S8		E000018	Limit Switch with fork 2NC	=BmMep	12	1	EATON
-S9		E000018	Limit Switch with fork 2NC	=BmMep	12	1	EATON
-V1		E000011	Laser Line Sign	=BmMep	19	1	Mep
-R5		E000003	Linear potentiometer 500mm	=BmMep	20	1	NOVO-TECNIK
-H3		E000012	Flashing 24Vac x SH NC	=BmMep	18	1	Mep
-H2		E000010	Led Lamp 24Vcc	=BmMep	19	1	Mep
-Q0		E003053-240	Disconnect switch three-poles 50A	=QgCv	5	1	Mep
-QD1		A000048	Carpentry general electric panel	=QgCv	27	1	Mep
-R10		E001000	Resistor 1W 680ohm	=QgCv	21	1	RS
-X100		E000014-240	Variable frequency drive DELTA 5.5KW,200-240V	=QgCv	6		DELTA
-Z1		E002903	Ferrites Toroids N30 r40	=QgCv	23	1	RS
-R-M20	010.3749	E003749	Anthracite Knob with HydMech Icon	=QgCv	24	1	Mep
-R-M21	010.3749	E003749	Anthracite Knob with HydMech Icon	=QgCv	24	1	Mep
-R-M25	010.3753	E003753	Silver Knob with HydMech Icon	=QgCv	21	1	Mep
-M7		M000080	Support for driver fan cooler	=QgCv	10	1	Mep
-M6		E005220	Cover for fan cooler 120x120	=QgCv	10	1	Mep
-M7		E005221	Cover for fan cooler 80x80	=QgCv	10	1	Mep
-M6		E005220	Fan cooling 120x120 24Vdc	=QgCv	10	1	Mep
-M7		E005221	Fan cooling 80x80 - 24Vdc	=QgCv	10	1	Mep
-FS1		E000226	Plastic clamp 140x3,5	=QgCv	27	1	Mep
-R-M25		E001816	Potentiometer 10K single turn	=QgCv	21	1	Mep
-FL1		E000133	Single wire AWG20 CSA (0.5mmq)	=QgCv	27	1	Mep
-FL2		E000134	Single wire AWG16 CSA (1.5mmq)	=QgCv	27	1	Mep
-XFET		E004001	Fixed connector ILME (CK03VS + CKF03) 4 poles	=QgCv		1	ILME
-NM1		E000290	Cable maker and wire	=QgCv	27	1	Mep
-NM2		E000290	Cable maker and wire	=QgCv	27	1	Mep
-CC1		E000218	Wire Terminal Connection Red	=QgCv	27	1	Mep
-CC2		E000214	Wire Terminal Connection Red	=QgCv	27	1	Mep
-PT1		E000394	Wire Terminal Connection White	=QgCv	27	1	Mep
-PT3		E000395	Wire Terminal Connection Black	=QgCv	27	1	Mep
-XTL	022.0376		Connettore F303N5000	=QgCv		1	Mep
-X008		E000429	Connector for solenoid valve DC	=QgCv	19	1	Mep

-X009		E000429	Connector for solenoid valve DC	=QgCv	19	1	Mep
-X010		E000429	Connector for solenoid valve DC	=QgCv	19	1	Mep
-X011		E000429	Connector for solenoid valve DC	=QgCv	19	1	Mep
-X012		E000429	Connector for solenoid valve DC	=QgCv	19	1	Mep
-X014		E000429	Connector for solenoid valve DC	=QgCv	19	1	Mep
-X40		E000429	Connector for solenoid valve DC	=QgCv	19	1	Mep
-BR1		E000222	Omega guide	=QgCv	27	1	Mep
-CN1		E000157	Cable holding plastic channel	=QgCv	27	1	Mep
-CN2		E000157	Cable holding plastic channel	=QgCv	27	1	Mep
-G1	022.0908	E000016	Switching power supply Vi 240-400-500VAC Vu 24Vcc 14A	=QgCv	8	1	Adelsy- stem
-S3		E000911	Carrier for pushbutton	=QgCv	17	1	Mep
-S4		E000911	Carrier for pushbutton	=QgCv	11	1	Mep
-S18		E000911	Carrier for pushbutton	=QgCv	17	1	Mep
-S54		E000932	Normally open contact	=QgCv	17	4	Mep
-S4		E000936	Normally close contact	=QgCv	11	3	Mep
-S3		E000937	Normally open contact	=QgCv	17	4	Mep
-S18		E000937	Normally open contact	=QgCv	17	1	Mep
-KRES		E002393	Relay 24 VCC - 2 exchange contacts + base	=QgCv	12	1	FINDER
-S4		E001245	Emergency push button	=QgCv	11	1	Mep
-R-M20	022.1322	E001322	Panel encoder Mep 50	=QgCv	24	1	Mep
-R-M21	022.1322	E001322	Panel encoder Mep 50	=QgCv	24	1	Mep
-U10	022.1330	E001230	Driver for step motor (60VAC.10A) + modbus	=QgCv	9	1	SHS
-S18		E001405	Black push button	=QgCv	17	1	Mep
-S3		E001408	Blue push button	=QgCv	17	1	Mep
-T2		E000020-	Transformer UL/CSA 500VA, Vin 240 0-240-480/ Vout 0-60,0-220V	=QgCv	8	1	Mep
-FL3		E001995	Cable 1AWG12 NERO	=QgCv	27	1	Mep
-FL2		E001996	Cable 1AWG12 GN/YE	=QgCv	27	1	Mep
-R0		E000005	Electronic tensioner 3,5T (strain gauge)	=QgCv	21	1	DELTA- TECK Mep
-AL		E000229	Terminal 6mmq for 3 wires - PHOENIX	=QgCv			
-F5 -F6		E002239	Fuse holding terminal 3 x (10,3x38) 690V 32A	=QgCv	6	1	BUSS- MANN
-F8 -F9		E002239	Fuse holding terminal 3 x (10,3x38) 690V 32A	=QgCv	6	1	BUSS- MANN
-F10							
-F20	022.2228	E002228	Fuse holding terminal 3 x (14x51) - 690V 50A	=QgCv	6	1	BUSS- MANN
-F21 -F22		E002240	Fuse holding terminal 2 x (10,3x38) 690V 32A	=QgCv	8	1	BUSS- MANN
-F1 -F2							
-F3 -F4		E002240	Fuse holding terminal 2 x (10,3x38) 690V 32A	=QgCv	8	1	BUSS- MANN
-XQG2		E000144	Terminal 2,5mmq for 4 wires - PHOENIX	=QgCv			Mep
-F14		E000139	Fuse holding terminal 1 x (10,3x38) 690V 32A	=QgCv	8	1	BUSS- MANN
-F15		E000139	Fuse holding terminal 1 x (10,3x38) 690V 32A	=QgCv	8	1	BUSS- MANN
-F16		E000139	Fuse holding terminal 1 x (10,3x38) 690V 32A	=QgCv	8	1	BUSS- MANN
-F17		E000139	Fuse holding terminal 1 x (10,3x38) 690V 32A	=QgCv	8	1	BUSS- MANN
-F18		E000139	Fuse holding terminal 1 x (10,3x38) 690V 32A	=QgCv	19	1	BUSS- MANN
-F19		E000139	Fuse holding terminal 1 x (10,3x38) 690V 32A	=QgCv	19	1	BUSS- MANN
-JB		E000142	Single pole spring terminal ST 2.5	=QgCv			PHOENIX
-XQG1		E000229	Triple pole spring terminal ST4	=QgCv			PHOENIX
-XQG4		E000142	Single pole spring terminal ST 2.5	=QgCv			PHOENIX
-XQPE		E000146	Double pole spring terminal 4,0mmq PE	=QgCv			PHOENIX
-XQPE		E002263	Quadruple pole spring PE terminal 6,0mmq	=QgCv		3	PHOENIX
-XQG4		E002270	Closure plate single-terminal	=QgCv			PHOENIX
-JB		E002270	Closure plate single-terminal	=QgCv			PHOENIX
-XQG1		E000147	Closure plate triple-terminal	=QgCv			PHOENIX
-XQG2		E000149	Closure plate quadruple-terminal	=QgCv		1	PHOENIX
-CU1	022.2825	E000002	Controller Mep50C	=QgCv	15	1	ISAC
-K6		E003011	Contactor 3KW NC (24 V Dc)	=QgCv	18	1	Shilhin electric
-K6R		E003011	Contactor 3KW NC (24 V Dc)	=QgCv	18	1	Shilhin electric

-K4		E003012	Contactor 3KW NO (24 V Dc)	=QgCv	18	1	Shilhin electric
-K65		E003012	Contactor 3KW NO (24 V Dc)	=QgCv	18	1	Shilhin electric
-R- S1	022.3811	E000009	Safety relay 4NO, 1NC cat.3	=QgCv	11	1	PIZZATO
-R-S2	022.3811	E000009	Safety relay 4NO, 1NC cat.3	=QgCv	12	1	PIZZATO
-Q-K65		E002542	Termal overload 5-8A	=QgCv	6	1	Shilhin electric
-Q-K6R		E000612	Termal overload 1,6-2,6A	=QgCv	7	1	Shilhin electric
-Q-K4		E000610	Termal overload 0.7-1,1A	=QgCv	6	1	Shilhin electric
-S54		E003920	Joystic 4 positions unstable with unlocking	=QgCv	17	1	Mep
-K6R		E003924	Kit for contactor reversing	=QgCv	18	1	Shilhin electric
-CU1	022.4091	E004091	Cable USB for command panel with connector	=QgCv	15	1	EATON
-R-M20		E000235	Ring 'NI-18-25-4.5	=QgCv	24	1	Mep
-R-M21		E000235	Ring 'NI-18-25-4.5	=QgCv	24	1	Mep
-R-M25		E000235	Ring 'NI-18-25-4.5	=QgCv	21	1	Mep
-TF2		E000209	Control panel gasket	=QgCv	27	1	Mep
-M6		E005220	Fan filter 120x120	=QgCv	10	1	Mep
-TF1	031.2622		Replace fuse adhesive sign	=QgCv	27	1	Mep
-M6		E005220	Fan filter 120x120	=QgCv	10	1	Mep
-M6		E005220	Base for fan cooling 120x120	=QgCv	10	1	Mep
-F1 -F2		E004538	Fuse Time delay 10.3x38 - 5A UL/CSA	=QgCv	8	2	Mep
-F5 -F6 -F7		E004538	Fuse Time delay 10.3x38 - 5A UL/CSA	=QgCv	6	3	Mep
-F15		E004538	Fuse Time delay 10.3x38 - 5A UL/CSA	=QgCv	8	1	Mep
-F16		E004538	Fuse Time delay 10.3x38 - 5A UL/CSA	=QgCv	8	1	Mep
-F18		E004659	Fuse Time delay 10.3x38 - 0.5A UL/CSA	=QgCv	19	1	Mep
-F14		E004664	Fuse Time delay 10.3x38 - 7.5A UL/CSA	=QgCv	8	1	Mep
-F17		E004673	Fuse Time delay 10.3x38- 1A UL/CSA	=QgCv	8	1	Mep
-F19		E004675	Fuse Time delay 10.3x38 - 2A UL/CSA	=QgCv	19	1	Mep
-F3 -F4		E004663	Fuse Time delay 10.3x38 - 7A UL/CSA	=QgCv	8	2	Mep
-F8 -F9 -F10		E004663	Fuse Time delay 10.3x38 - 7A UL/CSA	=QgCv	8	3	Mep
-F20 -F21 -F22		E004678	Fuse Fast act. 10.3x38 - 50A UL/CSA	=QgCv	6	3	Mep
XMET		E004002	Mobile connector ILME (CK03VS + CKM03) 4 poles	=QgEt-Mep		1	ILME
-XR0		E000369	Connector 3 poles for strain gauge	=QgMep		1	Mep
-XS7		E000369	Connector 3 poles for strain gauge	=QgMep		1	Mep
-S23		E000911	Carrier for pushbutton	=QgMep	18	1	Mep
-S23		E000937	Normally open contact	=QgMep	18	1	Mep
-PT1		E001405	Black push button	=QgMep	18	1	Mep
-PT1		E000150	Bridge for 2 terminals	=QgCv		6	Mep
-PT1		E000151	Bridge for 3 terminals	=QgCv		2	Mep
-W7/B1		E001397	Cable with M12 90° connector: lenght 5Mt	=BmCv		2	Mep
-W120		E001905	Cable shielded 4x2 Awg24 CSA	=BmCv		2.5	Mep
-W118		E001906	Cable shielded 6x2 Awg24 CSA	=QgCv			Mep
-W7/1		E001981	Cable 4G AWG18 OIL RESISTANT UL 2587 CSA	=BmCv		2	Mep
-W20		E001905	Cable shielded 4x2StA-wg24(0.20mmq) UL 2587 CSA	=QgCv		7	Mep
-W28		E001905	Cable shielded 4x2StA-wg24(0.20mmq) UL 2587 CSA	=QgCv		3	Mep
-W29/1		E001905	Cable shielded 4x2StA-wg24(0.20mmq) UL 2587 CSA	=QgCv		2	Mep
-W29/2		E001905	Cable shielded 4x2StA-wg24(0.20mmq) UL 2587 CSA	=QgCv		2	Mep
-W56		E001905	Cable shielded 4x2StA-wg24(0.20mmq) UL 2587 CSA	=QgCv		5	Mep

-W57		E001905	Cable shielded 4x2StA- wg24(0.20mmq) UL 2587 CSA	=QgCv		5	Mep
-W58		E001905	Cable shielded 4x2StA- wg24(0.20mmq) UL 2587 CSA	=QgCv		5	Mep
-W58/2		E001905	Cable shielded 4x2StA- wg24(0.20mmq) UL 2587 CSA	=QgCv		5	Mep
-W32		E000393	Cable with straight connector M8. L=5Mt	=QgCv		5	Mep
-W121		E000398	Straight connector M12 10MT cab- le 4x0.34mmq	=QgCv		10	Mep
-W27		E000397	Cable with M12 90° connector; Lenght: 10Mt	=QgCv		10	Mep
-W59		E000397	Cable with M12 90° connector; Lenght: 10Mt	=QgCv			Mep
-W117		E001906	Cable shielded 6x2 Awg24 CSA	=QgCv		1	Mep
-W117/1		E001906	Cable shielded 6x2 Awg24 CSA	=QgCv		1	Mep
-W119		E001906	Cable shielded 6x2 Awg24 CSA	=QgCv		3	Mep
-WS12		E001906	Cable shielded 6x2 Awg24 CSA	=QgCv		4	Mep
-W29		E001979	Cable 5G AWG16 UL 2587 CSA	=QgCv		5	Mep
-W30		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		4	Mep
-W37		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		5	Mep
-W39		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		5	Mep
-W65		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		5	Mep
-W90		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		3	Mep
-W91		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		3	Mep
-W92		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		3	Mep
-W93		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		3	Mep
-W95		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		5	Mep
-W96		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		5	Mep
-W122		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		5	Mep
-W123		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		3	Mep
-W124		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		3	Mep
-W125		E001980	Cable 2X AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		4	Mep
-W4		E001981	Cable 4G AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		5	Mep
-W7		E001981	Cable 4G AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		5	Mep
-W11		E001981	Cable 4G AWG18 OIL RESISTANT UL 2587 CSA	=QgCv		4	Mep
-W7/B		E001982	Cable 3xAWG18ST OIL RESISTANT UL 2587 CSA	=QgCv		5	Mep
-W1		E001983	Cable 4G X AWG10	=QgCv		5	Mep
-W2		E001983	Cable 4G X AWG10	=QgCv		5	Mep
FL1		E000133	Single pole wire Awg20 CSA	=QgCv			Mep
FL2		E000134	Single pole wire Awg16 CSA	=QgCv			Mep
FL3		E001995	Single pole wire Awg12 CSA	=QgCv			Mep
FL4		E001963	Single pole wire Awg10 CSA	=QgCv			Mep

0	1	2	3	4	5	6	7	8	9
Sim.\Sym.	File	Descrizione\Description	Sim.\Sym.	File	Descrizione\Description	Sim.\Sym.	File	Descrizione\Description	
	BLK106	Raccordo Union		CIL-VERT	Cilindro a doppio effetto				
	FFLH53	Valvola di massima Maximum valve		FIL TROID	Filtro				
	FFLH97	Valvola direz. 4/3 centri chiusi Maximum valve		POMPAID	Pompa idraulica				
	FFLP40	Valvola di esclusione Maximum valve		REG-IDM	Blocco controllo pressione e flusso				
	FFLP42	Manometro Maximum valve							
	FFLP53	Motore elettrica Maximum valve							
	FFLP54	Valvola controllo flusso Maximum valve							
	FFLP62A	Valvola unidirezionale Maximum valve							
	FFLP62B	Valvola apertura reg. Maximum valve							
	FFLP75A	Cilindro a doppio effetto Maximum valve							
	FFLP154	Elettrovalvola 2/2 ritorno a molla meccanica Maximum valve							
REV.	MODIFICA	DATA	FIRME	Data	13-07-2015	LEGENDA SIMBOLI SYMBOL KEY			
			Dis. N.	H11 A	Impianto	H 11 A			
			CAD	SPAC		Ordine			
			File	H 11A\2.dwg	Denominazione	Commissio H11A			
						Esecutore Anedano			
						Foglio			
						100			
						SEGUE			
						101			
						ULTIMO			
						211			

0	1	2	3	4	5	6	7	8	9
Nome/Item	Tipo/Type	Descrizione IT (Db)		Descrizione EN (Db)			Codice Interno	Quadro/Board	Fg/Sh
-C1	A000029	Cilindro Testa Ø=50mm, C=295mm, S=35mm		head cylinder Ø=50mm, C=295mm, S=35mm			A000029	=CIBmMep	101
-C2	H000004	Cilindro Morsa di Taglio/Alimentatore Ø=50mm, C=360mm, S=30mm		vise cylinder cutting/feeder Ø=50mm, C=360mm, S=30mm			H000004	=CIBmMep	102
-C3	H000004	Cilindro Morsa di Taglio/Alimentatore Ø=50mm, C=360mm, S=30mm		vise cylinder cutting/feeder Ø=50mm, C=360mm, S=30mm			H000004	=CIBmMep	102
-CU10	H000041	Raccordo a Curva		90° fitting			H000041	=CIBmMep	101
-CU20	H000041	Raccordo a Curva		90° fitting			H000041	=CIBmMep	102
-CU21	H000041	Raccordo a Curva		90° fitting			H000041	=CIBmMep	102
-CU30	H000041	Raccordo a Curva		90° fitting			H000041	=CIBmMep	102
-CU31	H000041	Raccordo a Curva		90° fitting			H000041	=CIBmMep	102
-GIR1	H000039	Raccordo girevole 1/4		alive fitting 1/4			H000039	=CIBmMep	101
-GIR10	H000039	Raccordo girevole 1/4		alive fitting 1/4			H000039	=CIBmMep	101
-GR3	H000039	Raccordo girevole 1/4		alive fitting 1/4			H000039	=CIBmMep	102
-MF6								=CIBmMep	102
-MN3	H000031	Manometro		gauge			H000031	=CIBmMep	102
-NY5A	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	102
	H000043	Raccordo 3/8 - 1/4		fitting 3/8 - 1/4			H000043	=CIBmMep	102
-NY6A	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	102
-NY7A	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	102
-NY7B	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	102
-NY7C	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	102
-NY73	H000043	Raccordo 3/8 - 1/4		fitting 3/8 - 1/4			H000043	=CIBmMep	101
-NY76	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	101
-NY78	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	101
-NY22	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	102
-NY23	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	102
-NY26	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	102
-NY27	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	102
-NY32	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	102
-NY33	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	102
-NY36	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	102
-NY37	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	102
-RD10	H000043	Raccordo 3/8 - 1/4		fitting 3/8 - 1/4			H000043	=CIBmMep	101
-RD20	H000043	Raccordo 3/8 - 1/4		fitting 3/8 - 1/4			H000043	=CIBmMep	102
-RD21	H000043	Raccordo 3/8 - 1/4		fitting 3/8 - 1/4			H000043	=CIBmMep	102
-RD30	H000043	Raccordo 3/8 - 1/4		fitting 3/8 - 1/4			H000043	=CIBmMep	102
-RD31	H000043	Raccordo 3/8 - 1/4		fitting 3/8 - 1/4			H000043	=CIBmMep	102
-RP2								=CIBmMep	102
-RPP11	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	101
	H000040	Manicotto 1/4		long fitting			H000040	=CIBmMep	101
-RPP12	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	101
	H000040	Manicotto 1/4		long fitting			H000040	=CIBmMep	101
-RPP20	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	102
	H000040	Manicotto 1/4		long fitting			H000040	=CIBmMep	102
-RPP21	H000052	Raccordo Nippio Idraulico 1/4		fitting 1/4			H000052	=CIBmMep	102
	H000040	Manicotto 1/4		long fitting			H000040	=CIBmMep	102
-T3	H000006	Idraulic pipe 400 D-G					H000006	=CIBmMep	102

--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

0	1	2	3	4	5	6	7	8	9
Nome/Item	Tipo/Type	Descrizione IT (Db)		Descrizione EN (Db)			Codice Interno	Qty	Fg/Sh
-T5	H000024	Tubo Idraulico 3700 D-G		Idraulic pipe 3700 D-G			H000024	1	=CIBmMep 102
-T6	H000024	Tubo Idraulico 3700 D-G		Idraulic pipe 3700 D-G			H000024	1	=CIBmMep 102
-T7	H000024	Tubo Idraulico 3700 D-G		Idraulic pipe 3700 D-G			H000024	1	=CIBmMep 102
-T11	H000025	Tubo Idraulico 1900 G-G		Idraulic pipe 1900 G-G			H000025	1	=CIBmMep 101
-T12	H000025	Tubo Idraulico 1900 G-G		Idraulic pipe 1900 G-G			H000025	1	=CIBmMep 101
-T13	H000014	Tubo Idraulico 600 D-G		Idraulic pipe 600 D-G			H000014	1	=CIBmMep 101
-T14	H000013	Tubo Idraulico 1000 D-G		Idraulic pipe 1000 D-G			H000013	1	=CIBmMep 101
-T20	H000005	Tubo Idraulico 2700 G-G		Idraulic pipe 2700 G-G			H000005	1	=CIBmMep 102
-T21	H000005	Tubo Idraulico 2700 G-G		Idraulic pipe 2700 G-G			H000005	1	=CIBmMep 102
-T24	H000006	Idraulic pipe 400 D-G					H000006	1	=CIBmMep 102
-T25	H000006	Idraulic pipe 400 D-G					H000006	1	=CIBmMep 102
-T30	H000007	Tubo Idraulico 3600 D-G		Idraulic pipe 3600 D-G			H000007	1	=CIBmMep 102
-T31	H000008	Tubo Idraulico 3100 D-G		Idraulic pipe 3100 D-G			H000008	1	=CIBmMep 102
-T120	H000037	Raccordo a "T"		3 way fitting			H000037	1	=CIBmMep 102
-T121	H000037	Raccordo a "T"		3 way fitting			H000037	1	=CIBmMep 102
-T130	H000037	Raccordo a "T"		3 way fitting			H000037	1	=CIBmMep 102
-T131	H000037	Raccordo a "T"		3 way fitting			H000037	1	=CIBmMep 102
-YVB	H000026	Elettrovalvola idraulica 2/2 NC 1/4"G 24Vdc		Hydraulic solenoid valve 2/2 NC 1/4"G 24Vdc			H000037	1	=CIBmMep 101

				Dis. N.	H11 A	Impianto	H 11 A	Ordine		FOGLIO
				CAD	[SPAC]			Commissa	H11A	105
				File	H 11A\2.dwg	Denominazione	Disintra Materiali	Esecutore	Arnedano	106
REV.	MODIFICA	DATA	FRME	Data	13-07-2015		Bill of Material			ULTIMO
										211

0	1	2	3	4	5	6	7	8	9
Nome/Item	Tipo/Type	Descrizione IT (Db)		Descrizione EN (Db)			Codice Interno	Quadro/Board	Fg/Sh
-BRF1	H000029	Valvola Proporzionale		flow control valve			H000029	=C1v	101
-FT1	H000034	Filtro		Strainer			H000034	=C1v	101
-M9	P000007	Motore strepper 1.9Nm, 2.8A, 18°		Strepper motor 1.9Nm, 2.8A, 18°			019.3555	=C1v	101
-M20	P000004-480	Motore centralina idraulica 1.3KW, 240V/480V.60Hz, 5.0/2.5A		Motor oil unit 1.3KW, 240V/480V.60Hz, 5.0/2.5A			P000004-480	=C1v	101
-MF1	H000045	blocco in alluminio valvola archetto		bow block			H000045	=C1v	101
-MF4	H000046	blocco in alluminio valvola morsa di taglio		cutting vice block			H000046	=C1v	102
-MF5	H000047	blocco in alluminio valvola morsa alimentazione		feeder valve			H000047	=C1v	102
-MN1	H000031	Manometro		gauge			H000031	=C1v	101
-MN2	H000031	Manometro		gauge			H000031	=C1v	101
-NY5	H000043	Raccordo 3/8 - 1/4		fitting 3/8 - 1/4			H000043	=C1v	102
-NY6	H000043	Raccordo 3/8 - 1/4		fitting 3/8 - 1/4			H000043	=C1v	102
-NY7	H000043	Raccordo 3/8 - 1/4		fitting 3/8 - 1/4			H000043	=C1v	102
-NY10	H000043	Raccordo 3/8 - 1/4		fitting 3/8 - 1/4			H000043	=C1v	101
-NY11	H000043	Raccordo 3/8 - 1/4		fitting 3/8 - 1/4			H000043	=C1v	101
-NY12	H000052	Raccordo Nipplo Idraulico 1/4		fitting 1/4			H000052	=C1v	101
-NY20	H000043	Raccordo 3/8 - 1/4		fitting 3/8 - 1/4			H000043	=C1v	102
-NY21	H000043	Raccordo 3/8 - 1/4		fitting 3/8 - 1/4			H000043	=C1v	102
-NY30	H000043	Raccordo 3/8 - 1/4		fitting 3/8 - 1/4			H000043	=C1v	102
-NY31	H000043	Raccordo 3/8 - 1/4		fitting 3/8 - 1/4			H000043	=C1v	102
-P1	H000032	Pompa		oil pump			H000032	=C1v	101
-RG10	H000039	Raccordo girevole 1/4		alive fitting 1/4			H000039	=C1v	101
-RNY10	H000052	Raccordo Nipplo Idraulico 1/4		fitting 1/4			H000052	=C1v	101
-RP1	H000038	Valvola di Regolazione Pressione discesa archetto		Adjust pressure valve for the bow			H000038	=C1v	101
-RPC	H000042	Valvola di Massima		system adjust pressure valve			H000042	=C1v	101
-SB1	H000033	Serbatoio		oil Tank			H000033	=C1v	101
-TP1	H000035	Tappo 1/4		fitting stop cap 1/4			H000035	=C1v	101
-TP2	H000036	Tappo livello olio 1/4		oil level fitting window			H000036	=C1v	101
-TP3	H000035	Tappo 1/4		fitting stop cap 1/4			H000035	=C1v	101
-VB1								=C1v	101
-YV1	H000048	valvola archetto		bow valve			H000048	=C1v	101
-YV2	H000050	valvola morsa di taglio		cutting valve			H000050	=C1v	102
-YV3	H000049	valvola alimentatore		feeder valve			H000049	=C1v	102


0	1	2	3	4	5	6	7	8	9
Nome/Item	Tipo/Type	Descrizione IT (Db)		Descrizione EN (Db)			Codice Interno	Q.tà/Qty	Quadro/Board
-C2V	H000003	Cilindro Morse Verticali Ø=40mm, C=400mm, S=25mm		vertical vice cylinder cutting/feeder Ø=40mm, C=400mm, S=25mm			H000003	1	=C1MvBm 103
-C3V	H000003	Cilindro Morse Verticali Ø=40mm, C=400mm, S=25mm		vertical vice cylinder cutting/feeder Ø=40mm, C=400mm, S=25mm			H000003	1	=C1MvBm 103
-CU20A	H000041	Raccordo a Curva		90° fitting			H000041	1	=C1MvBm 103
-CU30A	H000041	Raccordo a Curva		90° fitting			H000041	1	=C1MvBm 103
-GR21A	H000039	Raccordo girevole 1/4		alive fitting 1/4			H000039	1	=C1MvBm 103
-GR22A	H000039	Raccordo girevole 1/4		alive fitting 1/4			H000039	1	=C1MvBm 103
-GR23A	H000039	Raccordo girevole 1/4		alive fitting 1/4			H000039	1	=C1MvBm 103
-GR31A	H000039	Raccordo girevole 1/4		alive fitting 1/4			H000039	1	=C1MvBm 103
-GR32A	H000039	Raccordo girevole 1/4		alive fitting 1/4			H000039	1	=C1MvBm 103
-IRF20								1	=C1MvBm 103
-IRF21								1	=C1MvBm 103
-IRF30								1	=C1MvBm 103
-IRF31								1	=C1MvBm 103
-IRW20								1	=C1MvBm 103
-IRW21								1	=C1MvBm 103
-IRW30								1	=C1MvBm 103
-IRW31								1	=C1MvBm 103
-NY20A	H000052	Raccordo Nipplo Idraulico 1/4		fitting 1/4			H000052	1	=C1MvBm 103
-NY21A	H000052	Raccordo Nipplo Idraulico 1/4		fitting 1/4			H000052	1	=C1MvBm 103
-NY26A	H000052	Raccordo Nipplo Idraulico 1/4		fitting 1/4			H000052	1	=C1MvBm 103
-NY27A	H000052	Raccordo Nipplo Idraulico 1/4		fitting 1/4			H000052	1	=C1MvBm 103
-NY30A	H000052	Raccordo Nipplo Idraulico 1/4		fitting 1/4			H000052	1	=C1MvBm 103
-NY31A	H000052	Raccordo Nipplo Idraulico 1/4		fitting 1/4			H000052	1	=C1MvBm 103
-NY32A	H000052	Raccordo Nipplo Idraulico 1/4		fitting 1/4			H000052	1	=C1MvBm 103
-NY33A	H000052	Raccordo Nipplo Idraulico 1/4		fitting 1/4			H000052	1	=C1MvBm 103
-NY36A	H000052	Raccordo Nipplo Idraulico 1/4		fitting 1/4			H000052	1	=C1MvBm 103
-NY37A	H000052	Raccordo Nipplo Idraulico 1/4		fitting 1/4			H000052	1	=C1MvBm 103
-RF20								1	=C1MvBm 103
-RF20A								1	=C1MvBm 103
-RF21A								1	=C1MvBm 103
-RF30								1	=C1MvBm 103
-RF30A								1	=C1MvBm 103
-RF31A								1	=C1MvBm 103
-T24A	H000015	Tubo Idraulico 1800 D-G		Idraulic pipe 1800 D-G			H000015	1	=C1MvBm 103
-T25A	H000016	Tubo Idraulico 1300 D-G		Idraulic pipe 1300 D-G			H000016	1	=C1MvBm 103
-T33A	H000014	Tubo Idraulico 600 D-G		Idraulic pipe 600 D-G			H000014	1	=C1MvBm 103
-T34A	H000013	Tubo Idraulico 1000 D-G		Idraulic pipe 1000 D-G			H000013	1	=C1MvBm 103

				Dis. N.	H11 A	Impianto	H 11 A	Ordine	Foglio
				CAD	SPAC			Commissa	107
				File H 11A\2.dwg		Denominazione	Distinta Materiali	Esecutore	SEGUE
REV.	MODIFICA	DATA	FIRME	Data	13-07-2015		Bill of Material	Arnedano	ULTIMO
									211

Exploded views


This part of the manual contains detailed exploded views of the machine which can help to gain a deeper knowledge of how it is made.

Base assembly




Code	Ref.	Description	Description	Q.ty
	M000103	STAFFA- PER- LUBRIFICATORE- MIN- H1	STAFFA- PER- LUBRIFICATORE- MIN- H2	1.0000
034.1107	V000028	VOLANTINO- DIAM30M6X20	O 30 M6 X 20 HANDWHEEL	2.0000
010.7951	N000030	M6X20- TE	TE 6 X 20 SCREW (010.7951)	4.0000
010.7603	N000045	ROSETTA- 6_4X12_5	O 6 WASHER (010.7603)	4.0000
010.7871	N000053	M6X20- TCEI	TCEI 6 X 20 SCREW (010.7871)	4.0000
	G000002	RIDUTTORE- EVC- TRUC- H11	RIDUTTORE- EVC- TRUC- H12	1.0000
	T000080	ALBERO- EVAC- TRUCIOLI- H11	ALBERO- EVAC- TRUCIOLI- H12	1.0000
	T000081	IR_20X25X30_2_03	IR_20X25X30_2_04	2.0000
	T000082	DISTANZIALE- RIDUT- FRIZ- EVAC- H11	DISTANZIALE- RIDUT- FRIZ- EVAC- H12	1.0000
	R000019	CUSCINETTO- ASSIALE- H11	CUSCINETTO- ASSIALE- H12	2.0000
	V000059	SUPPORTO- MOLLA- FRIZ- EVAC- H11	SUPPORTO- MOLLA- FRIZ- EVAC- H12	2.0000
010.0915	V000003	MOLLA- A- TAZZA- 18- 50- 3	BELLEVILLE SPRING WASHERS 50X18,4X3 SH	4.0000
010.7616	N000010	ROSETTA- 21X37	O 21 WASHER	1.0000
010.7208	N000066	DADO- M16	M16 SCREW NUT (010.7208)	2.0000
	M000094	CARTER- FRIZIONE- EVACUATORE- H11	CARTER- FRIZIONE- EVACUATORE- H12	1.0000
	E000013	PROXIMITY- H11	PROXIMITY- H12	1.0000

Cutting mobile head group




Code	Ref.	Description	Description	Q.ty
010.7861	N000050	VITE TCEI 5 X 20 (010.7861)	TCEI 5 X 20 SCREW (010.7861)	6.0000
025.0963	R000015	CUSCINETTO 6204 2Z	BEARING 6204 2Z	1.0000
010.4308	T000018	STAFFA REGOLAZIONE TESTINE GUIDALAMA	BANDGUIDE REGUL.BRACKET	2.0000
010.7872	N000042	VITE TCEI 6 X 25 (010.7872)	TCEI 6 X 25 SCREW (010.7872)	20.0000
010.7896	N000041	VITE TCEI 8 X 35	TCEI 8 X 35 SCREW	16.0000
010.7894	N000022	VITE TCEI 8 X 25 (010.7894)	TCEI 8 X 25 SCREW (010.7894)	6.0000
010.7912	N000001	VITE TCEI 10 X 35	TCEI 10 X 35 SCREW	8.0000
010.7832	N000040	VITE BUTON 6 X 12	BUTON SCREW 6 X 12	4.0000
	T000077	STAFFA- SUPPORTO- LASER- LAMP	STAFFA- SUPPORTO- LASER- LAMP	1.0000
	T000076	SUPPORTO- LASER- LAMPADA- H12	SUPPORTO- LASER- LAMPADA- H13	1.0000
	E000010	LAMPADA- CINA	LAMPADA- CINA	1.0000
	E000011	EMETTITORE- LASER- ELM63- 05A	EMETTITORE- LASER- ELM63- 05A	1.0000
010.1731	V000014	CHIAVETTA PREMILAMA TESTINA	CARBIDE PAD KEY SH 500- 310- H- 14A	2.0000
010.1726	V000020	GUIDALAMA DUE INSERTI ANTERIORE FISSACON SMUSSO	2 INSERTS FIXING FRONT BAND GUIDE	1.0000
010.1724	V000021	PLACCHETTA GUIDALAMA ANTERIORE MOBILECON SMUSSO	MOVING FRONT BAND GUIDE	1.0000
043.0196	V000018	RACCORDO A GOMITO MF 8X1/4 CL 1020	MF 8X1/4 CL 1020 ELBOW JOINT	2.0000
044.0651	V000015	PROLUNGA 1/4' M.F. ESAGONALE 25MM.	1/4" M.F. EXTENSION 20 MM	2.0000
044.0552	V000016	RACCORDO A GOMITO IDRAULICO MF 1/4 ALTAPRESSIONE	HYDR. ELBOW JOINT M/F 1/4 HIGH PRESSURE	2.0000
043.0652	V000019	RUBINETTO 1/4 F.M.	1/4 F. M. TAP	2.0000
028.0130		RACCORDO 1/4- 9 CL 2601	JOINT 1/4- 9 CL 2601	2.0000
010.7891	N000048	VITE TCEI 8 X 16 (010.7891)	TCEI 8 X 16 SCREW (010.7891)	4.0000
010.7467	N000047	GRANO VCE PUNTA PIANA 6 X 12	6 X 12 FLAT POINT VCE GRUB SCREW	10.0000
010.9106	N000049	GRANO VCE PUNTA PIANA 4 X 16	4X 16 FLAT POINT GRUB SCREW	4.0000
010.7466	N000046	GRANO VCE PUNTA PIANA 6 X 16	6 X 16 FLAT POINT VCE GRUB SCREW	8.0000
010.0860	T000022	SUPPORTO PERNI ECCENTRICI TESTINA GUID.	ECCENTRIC PIN HEAD BAND GUIDE SUP.	2.0000
010.3734	T000020	PERNO ECCENTRICO CUSCINETTI PREMILAMA	BLADEPUSHER BEARING ECCENTRIC PIN	4.0000
025.0087	R000018	CUSCINETTO 6202 2Z	BEARING 6202 2Z PH 100	8.0000
010.0859	T000021	RULLO PREMILAMA	BAND PUSHER ROLLER	4.0000
010.7603	N000045	RONDELLA 0 6 (010.7603)	0 6 WASHER (010.7603)	4.0000
010.7452	N000044	GRANO VCE PUNTA CONICA 6 X 16	6 X 16 CONICAL POINT VCE GRUB SCREW	4.0000
010.7870	N000043	VITE TCEI 6 X 16 (010.7870)	TCEI 6 X 16 SCREW (010.7870)	4.0000
010.7606	N000015	RONDELLA 0 12 (010.7606)	0 12 WASHER (010.7606)	4.0000
010.1723	V000013	PLACCHETTA GUIDALAMA POSTERIORE MOBILECON SMUSSO	MOVING REAR BAND GUIDE SH 400	1.0000
010.1725	V000012	GUIDALAMA DUE INSERTI POSTERIORE FISSACON SMUSSO	2 INSERTS FIXING REAR BAND GUIDE	1.0000
010.0902	V000010	MOLLA PUNTO FISSO TESTA MOD. 95	HEAD FIXED POINT SPRING	1.0000
010.4758	T000064	STAFFA FISSAGGIO SENSORE DEVIAZIONE LAMA	DEFLECTION BAND SENSOR FIX BRACKET	1.0000
022.0537	E000007	SENSORE INDUTTIVO DCALX/4919B	INDUCTIVE SENSOR DCALX/4919B	1.0000
010.7603	N000045	RONDELLA 0 6 (010.7603)	0 6 WASHER (010.7603)	1.0000
010.7226	N000082	DADO AUTOBLOCCANTE M6 (010.7226)	M6 SELF- LOCKING SCREW NUT	1.0000
010.7470	N000083	GRANO VCE PUNTA PIANA 6 X 35	6X35 FLAT POINT VCE GRUB SCREW	1.0000
010.1721	T000062	PREMILAMA	TOP CARBIDE	1.0000
010.7993	-	VITE TSPEI 5 X 12 (010.7993)	TSPEI 5 X 12 SCREW (010.7993)	2.0000
010.7996	-	VITE TSPEI 6 X 30 (010.7996)	TSPEI 6 X 30 SCREW (010.7996)	1.0000
010.7850	-	VITE TCEI 4 X 8 (010.7850)	TCEI 4 X 8 SCREW	2.0000

Idler pulley unit




Code	Ref.	Description	Description	Q.ty
001.4412	C000006	SLITTA TENDILAMA SH 400- 420- 422	BAND TENSION SLIDE *	1.0000
025.0275	R000011	ANELLO DI PROTEZIONE NILOS 32009X	NILOS GUARD RING 32009X	2.0000
025.0075	R000008	CUSCINETTO 32009X	BEARING 32009X	2.0000
010.0356	V000001	GHIERA AUTOBLOCCANTE 45X1,5 SH	SELF- LOCKING RING NUT 45X1,5 SH	1.0000
010.1201	N000011	VITERIA E BULLONERIA	SCREWS AND BOLTS	4.0000
010.7642	N000013	RONDELLA GROOVER M16	WASHER GROOVER M16	8.0000
010.7972	N000012	VITE TE 16X60	TE 16 X 60 SCREW	8.0000
010.7461	N000024	GRANO VCE PUNTA PIANA 6 X 25	6 X 25 FLAT POINT VCE GRUB SCREW	6.0000
010.8152	N000023	DADO M6 BASSO	M16 NUT	6.0000
010.7894	N000022	VITE TCEI 8 X 25 (010.7894)	TCEI 8 X 25 SCREW (010.7894)	8.0000
010.7964	N000021	VITE TE 8 X 30	TE 8 X 30 SCREW	4.0000
010.1204	V000007	INGRASSATORE M 6	M 6 LUBRICATOR	1.0000
010.7480	N000020	GRANO VCE PUNTA PIANA 8 X 30	8 X 30 FLAT POINT VCE GRUB SCREW	1.0000
	E000013	PROXIMITY- H12	PROXIMITY- H13	1.0000
010.0915	V000003	MOLLA A TAZZA 50X18,4X3 SH	BELLEVILLE SPRING WASHERS 50X18,4X3	4.0000
025.0084	R000010	RALLA GS 81104	WASHER GS 81104	2.0000
025.0934	R000009	GABBIA ASSIALE K81104	AXIAL CAGE K81104	1.0000
034.0212	V000004	VOLANTINO TENSIONAMENTO LAMA S 20 3 BRACCI D.220 CON INSERTO M18X1,5	BLADE TENSIONING HANDWHEEL	1.0000
010.8905	N000026	VITE TE 10 X 65	10 X65 TE SCREW	2.0000
010.7205	N000025	DADO M10 (010.7205)	M10 SCREW NUT (010.7205)	2.0000
022.2152	E000001	TENSIONATORE ELETTRONICO TR- SA/3T.00	ELECTRONIC TENSIONER TRSA/3T.00	1.0000
022.0369	E000005	CONNETTORE PER BOBINA U2 E TEN- SIONATORE TRSA/3T.00	CONNECTOR F.U2 COIL AND TEN- SIONER	1.0000

Driving pulley unit




Code	Ref.	Description	Description	Q.ty
007.6607	T000015	TAMPONE RIDUTTORE	BUFFER REDUCTER	1.0000
010.7923	N000019	VITE TCEI 10 X 25 (010.7923)	TCEI 10 X 25 SCREW (010.7923)	4.0000
025.0979	R000012	CUSCINETTO 32011 CEMENTATO	TAPERED ROLLER BEARING 32011	2.0000
025.0276	R000013	ANELLO DI PROTEZIONE NILOS 32011	NILOS GUARD RING 32011	2.0000
010.0360	V000005	GHIERA BLOCC.ALBERO RIDUTTORE	DRIVE SHAFT LOCKNUT	1.0000
010.7451	N000018	GRANO VCE PUNTA CONICA 6 X 12	6 X 12 CONICAL POINT VCE GRUB SC-REW	3.0000
010.7117	N000017	CHIAVETTA 10 X 8 X 35 (010.7117)	10 X 8 X 35 KEY (010.7117)	2.0000
010.2326	T000011	FLANGIA AGGANCIO RIDUTTORE-FCDPK85 FIXED STAR	REDUC.FLANGE COUPLE FCDPK85 FIX.STAR	1.0000
010.7942	N000016	VITE TCEI 12 X 40 (010.7942)	TCEI 12 X 40 SCREW	4.0000
025.0770	G000001	RIDUTTORE FCPDKO 85 FC IEC 112B14	GEARBOX	1.0000
010.7606	N000015	RONDELLA 0 12 (010.7606)	0 12 WASHER (010.7606)	4.0000
010.7986	N000014	VITE TE 12 X 35 (010.7986)	TE 12 X 35 SCREW (010.7986)	4.0000
010.7642	N000013	RONDELLA GROOVER M16	WASHER GROOVER M16	8.0000
010.7972	N000012	VITE TE 16X60	TE 16 X 60 SCREW	8.0000
025.0863	A000015	CALETTATORE TLK 130 50X80 SH 400 / H- 14A	LOCKING SET TLK 130 50X80 SH 400 / H- 14A	1.0000
010.1204	V000007	INGRASSATORE M 6	M 6 LUBRICATOR	1.0000
019.2002	P000002	KW 4 4P.B.14 GR112 S6 60% V.230- 400/240- 415/265- 460.60/277- 480.60	KW 4 4P.B.14 GR112 S6 60% V.230- 400/240-	1.0000
010.1201	N000011	VITERIA E BULLONERIA	SCREWS AND BOLTS	4.0000
010.7616	N000010	RONDELLA 0 21	0 21 WASHER	4.0000
010.8111	N000009	DADO AUTOBLOCCANTE M20	SELF BLOCKING NUT M 20	4.0000
010.7911	N000008	VITE TCEI 10 X 20 (010.7911)	TCEI 10 X 20 SCREW (010.7911)	2.0000
010.7912	N000001	VITE TCEI 10 X 35	TCEI 10 X 35 SCREW	3.0000
	M000087	CARTER- LAMA- TRAVE- ARCH- H12	CARTER- LAMA- TRAVE- ARCH- H13	1.0000
025.0088	R000014	CUSCINETTO 6001 2Z PH 100	BEARING 6001 2Z PH 100	2.0000
025.0555	V000011	SPAZZOLA PULILAMA 3103 0 100	BAND BRUSH 3103 0 100 SH 400 / H- 14A	1.0000
010.7674	N000007	RONDELLA SPESSORE DIAM. 10,5 X 30	THICKNESS WASHER DIAM. 10,5 X 30	1.0000
010.7230	N000006	DADO AUTOBLOCCANTE M10	M10 SELF- LOCKING SCREW NUT	1.0000
010.7607	N000005	RONDELLA 0 16 (010.7607)	0 16 WASHER (010.7607)	1.0000
010.7233	N000004	DADO AUTOBLOCCANTE M16	M16 SELF- LOCKING SCREW NUT	1.0000
007.6635	A000017	PIASTRINO REGISTRAZIONE SPAZZO-LAPULILAMA	BRUSH REGULATING PLATE	1.0000
025.0802	V000008	BOCCOLA GRAFITATA L. 15 DIAM. 10	GRAPHITIZED BUSHING L. 15 DIA M. 10	2.0000
010.0902	V000010	MOLLA PUNTO FISSO TESTA MOD. 95	HEAD FIXED POINT SPRING	2.0000
010.7932	N000003	VITE TCEI 10 X 110	TCEI 10 X 110 SCREW	2.0000
010.8160	N000002	DADO M10 ALTO	M10 HIGH NUT	2.0000
010.7912	N000001	VITE TCEI 10 X 35	TCEI 10 X 35 SCREW	1.0000

Cradle unit




Code	Ref.	Description	Description	Q.ty
010.1201	N000073	M24X70- TCEI	M24X70- TCEI	1.0000
010.1201	N000072	M24X80- TE	M24X80- TE	1.0000
010.7972	N000012	VITE TE 16X60	TE 16 X 60 SCREW	8.0000
010.7895	N000035	VITE TCEI 8 X 30	TCEI 8 X 30 SCREW	12.0000
010.7606	N000015	RONDELLA Ø 12 (010.7606)	Ø 12 WASHER (010.7606)	4.0000
010.8916	N000071	VITE TE 12 X 50	12 X 50 TE SCREW	4.0000
010.7980	N000070	VITE TE 10 X 60	TE 10 X 60 SCREW	6.0000
010.7911	N000008	VITE TCEI 10 X 20 (010.7911)	TCEI 10 X 20 SCREW (010.7911)	2.0000
010.7924	N000034	VITE TCEI 10 X 30 (010.7924)	TCEI 10 X 30 SCREW (010.7924)	2.0000
010.8163	N000069	DADO M16 ALTO	M16 HIGH NUT	1.0000
044.1250	H000026	VALVOLA BLOCCAGGIO PIANO GI- REVOLE V3 AC V. 24	ROTATING TABLE LOCKING VALVE V. 24	1.0000
010.7205	N000025	DADO M10 (010.7205)	M10 SCREW NUT (010.7205)	2.0000
010.9080	N000068	GRANO VCE PUNTA PIANA 10 X 70	10X70 FLAT POINT GRUB SCREW	2.0000
025.0088	R000014	CUSCINETTO 6001 2Z PH 100	BEARING 6001 2Z PH 100	2.0000

Protection group




Code	Ref.	Description	Description	Q.ty
010.7960	N000039	VITE TE 8 X 16	TE 8 X 16 SCREW	12.0000
010.7951	N000030	VITE TE 6 X 20 (010.7951)	TE 6 X 20 SCREW (010.7951)	8.0000
010.7868	N000081	VITE TCEI 6 X 12 (010.7868)	TCEI 6 X 12 SCREW	14.0000
010.7961	N000037	VITE TE 8 X 20 (010.7961)	TE 8 X 20 SCREW (010.7961)	4.0000
	M000111	CARTER- POSTERIORE- PROT- H11-	CARTER- POSTERIORE- PROT- H11-	1.0000
	M000106	TELAIO- SPORTELLLO- POSTER- H12	TELAIO- SPORTELLLO- POSTER- H12	1.0000
	V000061	PLEXIGLASS- SPORTELLLO- POSTER	PLEXIGLASS- SPORTELLLO- POSTER	1.0000

Feeder group




Code	Ref.	Description	Description	Q.ty
019.3407	P000001	MOTORE P/P FL86STH156- 5708AL	FEEDINGMOTOR	1.0000
025.0278	R000032	ANELLO DI PROTEZIONE NILOS 30302 AV	NILOS SEAL RING 30302 AV	4.0000
025.0970	R000001	CUSCINETTO 30302J2	BEARING	2.0000
025.0185	T000003	PULEGGIA DENTATA METR. PASSO 8 22 DENTILARGHEZZA CINGHIA 20	WHEEL 22 8M 20	2.0000
025.0867	A000005	CALETTATORE TLK 110 12X18	KEY TLK 110 SH 652 SXI EVO	2.0000
010.0380	T000052	GHIERA FISSAGGIO VITE RICIRCOLO ALIMENTATORE SH N.T.	FIXING RING NUT FOR FEEDER	1.0000
025.0034	V000045	CINGHIA DENTATA METRICA PASSO 8 LARGH.20SVILUPPO 376	TIMING BELT 8M 20 376	1.0000
025.0921	R000002	CUSCINETTO 6003 2Z	BEARING 6003 2Z	1.0000
010.7972	N000012	VITE TE 16X60	TE 16 X 60 SCREW	4.0000
010.7988	N000036	VITE TE 12 X 60	TE 12 X 60 SCREW	2.0000
010.7895	N000035	VITE TCEI 8 X 30	TCEI 8 X 30 SCREW	22.0000
010.7924	N000034	VITE TCEI 10 X 30 (010.7924)	TCEI 10 X 30 SCREW (010.7924)	4.0000
010.7910	N000033	VITE TCEI 8 X 70	TCEI 8 X 70 SCREW	2.0000
010.7830	N000032	VITE BUTON 5 X 10 (010.7830)	5 X 10 BUTON SCREW (010.7830)	6.0000
010.7964	N000021	VITE TE 8 X 30	TE 8 X 30 SCREW	12.0000
010.9120	N000031	GRANO VCE PUNTA PIANA 8 X 20	8X20 FLAT POINT GRUB SCREW	2.0000
010.7961	N000037	VITE TE 8 X 20 (010.7961)	TE 8 X 20 SCREW (010.7961)	4.0000
	M000066	PROTEZIONE- STEPMOTOR- H12	PROTEZIONE- STEPMOTOR- H13	1.0000
	M000071	STAFFA- POST- AGG- ALIM- H12	STAFFA- POST- AGG- ALIM- H13	2.0000
010.7605	N000029	RONDELLA 0 10 (010.7605)	0 10 WASHER (010.7605)	6.0000
010.7977	N000028	VITE TE 10 X 35	TE 10 X 35 SCREW	4.0000
	M000099	STAFFA- APPOGGIO- FINECORS- BAR- RA	STAFFA- APPOGGIO- FINECORS- BAR- RA	1.0000
010.7922	N000027	VITE TCEI 10 X 15	TCEI 10 X 15 SCREW	1.0000
010.7205	N000025	DADO M10 (010.7205)	M10 SCREW NUT (010.7205)	1.0000
	R000033	HGH35CA	HGH35CA	2.0000
	M000088	GRUP- SUPPO- RULLO- MOBIL- ALIM	GRUP- SUPPO- RULLO- MOBIL- ALIM	1.0000
	M000090	STAFFA- RULLO- MOBILE- ALIM- H12	STAFFA- RULLO- MOBILE- ALIM- H13	2.0000
	M000089	STAFFA- PERNO- MOBILE- ALIM- H12	STAFFA- PERNO- MOBILE- ALIM- H13	2.0000
	M000091	PERNO- TRASCINAMENTO- RULLO- MOB	PERNO- TRASCINAMENTO- RULLO- MOB	2.0000
010.7894	N000022	VITE TCEI 8 X 25 (010.7894)	TCEI 8 X 25 SCREW (010.7894)	2.0000
025.0996	R000003	CUSCINETTO 6306 2Z	BEARING 6306 2Z	2.0000
	M000035	STAFFA- FINEC- PRESENZA- BARRA	STAFFA- FINEC- PRESENZA- BARRA	1.0000
	M000068	STAFFA- FINECORS- A- ROTELLA- ALIM	STAFFA- FINECORS- A- ROTELLA- ALIM	1.0000
022.0543	E000004	FINECORS- A- ROTELLA	LIMIT SWITCH	1.0000
	R000028	GUIDA- FINECORS- PRES- BARRA- H11	GUIDA- FINECORS- PRES- BARRA- H11	1.0000
	R000029	PATTINO- GUIDA- FIN- BARRA- H11	PATTINO- GUIDA- FIN- BARRA- H11	1.0000

Feed carriage unit




Code	Ref.	Description	Description	Q.ty
	M000082	SPESSORE- GANASCIA- ALIM- H12	SPESSORE- GANASCIA- ALIM- H13	1.0000
	T000074	SPESSORE- MORSA- ALIM- H12	SPESSORE- MORSA- ALIM- H13	1.0000
010.3036	R000004	CHIOCCIOLA R2010T2FSI C7A10UC1A1 XALIMENTATORI	FE. SCREW R2010T2FSI C7A10UC1A1 X FEEDER	1.0000
010.7924	N000034	VITE TCEI 10 X 30 (010.7924)	TCEI 10 X 30 SCREW (010.7924)	6.0000
010.7930	N000056	VITE TCEI 10 X 90	TCEI 10 X 90 SCREW	4.0000
010.7967	N000055	VITE TE 8 X 40	TE 8 X 40 SCREW	6.0000
010.7894	N000022	VITE TCEI 8 X 25 (010.7894)	TCEI 8 X 25 SCREW (010.7894)	8.0000
010.7925	N000054	VITE TCEI 10 X 40	TCEI 10 X 40 SCREW	8.0000
010.7871	N000053	VITE TCEI 6 X 20 (010.7871)	TCEI 6 X 20 SCREW (010.7871)	6.0000
010.8161	N000052	DADO M12 ALTO	M12 HIGH NUT	2.0000
010.7942	N000016	VITE TCEI 12 X 40 (010.7942)	TCEI 12 X 40 SCREW	12.0000
	M000070	STAFFA- REGOLAZ- TRAVE- ALIM- H12	STAFFA- REGOLAZ- TRAVE- ALIM- H13	2.0000
	M000083	CARTER- POST- GANASCIA- ALIM- H12	CARTER- POST- GANASCIA- ALIM- H13	1.0000
	M000084	CARTER- ANT- GANASCIA- ALIM- H12	CARTER- ANT- GANASCIA- ALIM- H13	1.0000
	M000068	STAFFA- FINECORS- A- ROTELLA- ALIM	STAFFA- FINECORS- A- ROTELLA- ALIM	1.0000
022.0543	E000004	FINECORS- A- ROTELLA	LIMIT SWITCH	1.0000
	M000098	SUPPORTO- MANIC- SCORR- RULLO	SUPPORTO- MANIC- SCORR- RULLO	2.0000
010.7873	N000051	VITE TCEI 6 X 30 (010.7873)	TCEI 6 X 30 SCREW (010.7873)	4.0000
	M000093	SUPP- CILIND- CARR- ALIM- H12	SUPP- CILIND- CARR- ALIM- H13	2.0000
	M000092	CILIND- CARR- ALIM- H12	CILIND- CARR- ALIM- H13	1.0000
025.0088	R000014	CUSCINETTO 6001 2Z PH 100	BEARING 6001 2Z PH 100	2.0000

Feeder vertical vice




Code	Ref.	Description	Description	Q.ty
010.7894	N000022	TCEI 8 X 25 SCREW (010.7894)	VITE TCEI 8 X 25 (010.7894)	12.0000
010.7871	N000053	TCEI 6 X 20 SCREW (010.7871)	VITE TCEI 6 X 20 (010.7871)	4.0000
010.7853	N000075	TCEI 4 X 20 SCREW (010.7853)	VITE TCEI 4 X 20 (010.7853)	20.0000
010.7854	N000079	TCEI 4 X 25 SCREW	VITE TCEI 4 X 25	16.0000
010.7855	N000074	TCEI 4 X 30 SCREW (010.7855)	VITE TCEI 4 X 30 (010.7855)	4.0000
010.7963	N000078	TE 8 X 25 SCREW (010.7963)	VITE TE 8 X 25 (010.7963)	16.0000
010.7925	N000054	TCEI 10 X 40 SCREW	VITE TCEI 10 X 40	4.0000
010.7853	N000075	TCEI 4 X 20 SCREW (010.7853)	VITE TCEI 4 X 20 (010.7853)	8.0000
010.7830	N000032	5 X 10 BUTON SCREW (010.7830)	VITE BUTON 5 X 10 (010.7830)	10.0000
034.1107	V000028	O 30 M6 X 20 HANDWHEEL	VOLANTINO O 30 M6 X 20	2.0000

Cutting vertical vice




Code	Ref.	Description	Description	Q.ty
010.7231	N000076	DADO AUTOBLOCCANTE M12	M12 SELF- LOCKING SCREW NUT	1.0000
010.7894	N000022	VITE TCEI 8 X 25 (010.7894)	TCEI 8 X 25 SCREW (010.7894)	8.0000
010.7872	N000042	VITE TCEI 6 X 25 (010.7872)	TCEI 6 X 25 SCREW (010.7872)	4.0000
010.7853	N000075	VITE TCEI 4 X 20 (010.7853)	TCEI 4 X 20 SCREW (010.7853)	36.0000
010.7895	N000035	VITE TCEI 8 X 30	TCEI 8 X 30 SCREW	4.0000
010.7964	N000021	VITE TE 8 X 30	TE 8 X 30 SCREW	8.0000
010.7855	N000074	VITE TCEI 4 X 30 (010.7855)	TCEI 4 X 30 SCREW (010.7855)	4.0000
010.7925	N000054	VITE TCEI 10 X 40	TCEI 10 X 40 SCREW	4.0000
010.7853	N000075	VITE TCEI 4 X 20 (010.7853)	TCEI 4 X 20 SCREW (010.7853)	8.0000
010.7830	N000032	VITE BUTON 5 X 10 (010.7830)	5 X 10 BUTON SCREW (010.7830)	10.0000
034.1107	V000028	VOLANTINO O 30 M6 X 20	O 30 M6 X 20 HANDWHEEL	2.0000

Fixed vice group




Code	Ref.	Description	Description	Q.ty
	T000088	MORSA- FISSA- LATO- SCARICO	MORSA- FISSA- LATO- SCARICO	1.0000
010.7972	N000012	VITE TE 16X60	TE 16 X 60 SCREW	2.0000
	T000040	TRASC- TEST- LAMA	TRASC- TEST- LAMA	1.0000
	A000051	PIANO- SCORREVOLE- MORSA	PIANO- SCORREVOLE- MORSA	1.0000
010.7894	N000022	VITE TCEI 8 X 25	TCEI 8 X 25 SCREW	6.0000
010.7606	N000015	RONDELLA 0 12	0 12 WASHER	2.0000
010.8914	N000060	VITE TE 12 X 25	12 X 25 TE SCREW	2.0000
010.7605	N000029	RONDELLA 0 10	0 10 WASHER	7.0000
010.7979	N000059	VITE TE 10 X 50	TE 10 X 50 SCREW	7.0000
010.7607	N000005	RONDELLA 0 16 (010.7607)	0 16 WASHER	1.0000
010.7221	N000058	DADO M16 BASSO	M16 LOW SCREW NUT	2.0000
	T000087	MORSA- FISSA- LATO- CARICO	MORSA- FISSA- LATO- CARICO	1.0000
010.7897	N000057	VITE TCEI 8 X 40	TCEI 8 X 40 SCREW	2.0000
	T000090	SPESSORE- PIANO- SCORREVOLE	SPESSORE- PIANO- SCORREVOLE	1.0000
007.4116	T000036	SUPPORTO GUIDA SCARICA PEZZI	GUIDE SUPPORT	1.0000
025.0047	T000035	MANICOTTO A SFERA KH 3050 LL	BALL SLEEVE 0658.030.00 AL. TI	1.0000
010.9125	N000065	GRANO VCE PUNTA PIANA 8 X 60	8X60 FLAT POINT GRUB SCREW	1.0000
010.7604	N000064	RONDELLA 0 8 (010.7604)	0 8 WASHER (010.7604)	1.0000
034.1001	V000023	LEVA A SCATTO 8 MA PK55	LEVER 8 MA PK55	1.0000
010.7994	N000062	VITE TSPEI 6 X 12	TSPEI 6 X 12 SCREW	3.0000
010.8152	N000023	DADO M6 BASSO	M16 NUT	2.0000
010.7951	N000030	VITE TE 6 X 20	TE 6 X 20 SCREW	2.0000
	M000112	PIANO- SCARICAPEZZI	PIANO- SCARICAPEZZI	1.0000

Vertical rolls group




Code	Ref.	Description	Description	Q.ty
007.5062	T000053	TASSELLO FISSAGGIO RULLO VER- TICALE ALIMENTATORE	FIXING PLATE F.VERT.ROLLER	2.0000
034.1003	V000028	LEVA A SCATTO 12 MA	LEVER 12 MA	2.0000
010.7895	N000035	VITE TCEI 8 X 30	TCEI 8 X 30 SCREW	4.0000
025.0055	R000027	CUSCINETTO 62.05 2Z C3	BEARING 62.05 2Z C3	2.0000

Control board




Code	Ref.	Description	Description	Q.ty
010.7890	N000080	TCEI 8 X 12 SCREW	VITE TCEI 8 X 12	10.0000
010.7832	N000040	BUTON SCREW 6 X 12	VITE BUTON 6 X 12	6.0000
031.2081	V000036	PROGRAMMING CONSOLLE MEP50 TS 7INCH	CONSOLLE DI PROGRAMMAZIONE MEP 50 TOUCH- SCREEN 7 INCH	1.0000
-	-	BASE- VENTOLA- RAFF- CINA	BASE- VENTOLA- RAFF- CINA	1.0000
-	-	FILTRO- VENTOLA- RAFF- CINA	FILTRO- VENTOLA- RAFF- CINA	1.0000
-	-	COP- ALETTATORE- VENT- CINA	COP- ALETTATORE- VENT- CINA	1.0000

Hydraulic unit



Code	Ref.	Description	Description	Q.ty
	A00064	SUB- ASSEMBLY	GRUPPO- CASSETTO- CENTRAL	1
	M000045	PART	PIEDINO- CASSETTO- CENTR	2
025.0060		PART	6000- 2Z	2
010.7925	N000054	PART	M10X40- TCEI	2
010.7205	N000025	PART	DADO- M10	2
	H000002	SUB- ASSEMBLY	CENTRALINA- IDRAULICA	1

Adjustments



This chapter describes the operations required to adjust the electronic, mechanical and the hydraulic systems. By following these instructions, you can “customise” your machine to suit the type of cut required, thereby optimising cutting times.


Displaying and editing the set-up parameters

The machine set-up parameters may be programmed directly from the control console.


- ▶ Power the machine by turning the main switch on the left of the control board.
- ▶ Tap on the box on the touchscreen shown in the figure.




- The password entry box will open. Tap the box to open the keypad. Enter 734533.



- Tap on the box shown in the figure.



- Tap on the box shown in the figure.



- Once inside the SET- UP menu, use the following three keys to navigate through the different menu screens:

Button to go to the next setup page


Button to go back to the previous page

Button to go to the previous setup page

Button to open the troubleshooting menu

Button to refresh the page

Button to save the page



Button to view the parameter groups

Button to view the selected parameter details

Button to close the selected parameter details

Button to scroll down fast

Button for scroll up fast

Button to scroll down

Button to scroll up

Setup parameters

The machine setup parameters divided by topic are shown below.

BLADE MOTOR:

- **Blade Ampere Analogue In Max Integer /P0:** Analogue input counter value corresponding to the maximum ampere(5504.0000).
- **Blade Ampere Analogue In Min Integer /P1:** Analogue input counter value corresponding to the minimum ampere (32,0000).
- **Blade Ampere Analogue In Process Value Max Ampere /P2:** Ampere corresponding to maximum analogue input value (5,5000).
- **Blade Ampere Analogue In Process Value Min Ampere /P3:** Ampere corresponding to minimum analogue input value (0.0000).
- **Blade Ampere Analogue In Process Max Voltage /P4:** Voltage corresponding to maximum analogue input value (10.0).
- **Blade Ampere Analogue In Process Min Voltage /P5:** Voltage corresponding to minimum analogue input value (0,0).
- **Blade Ampere Control Check Time Period sec /P23:** Control execution time (sec) (1).
- **Blade Ampere Control Before Enabling On Delay sec /P24:** Activation delay in seconds (if 0 is off) (3,000).

- **Blade Ampere Control Feed Reduction Step M/min /P25:** Correction step (25,0000).
- **Blade Ampere Control Max Allowed Ampere /P26:** Maximum allowed current (24.0000).
- **Blade Ampere Control Max Ampere Alarm On Delay sec /P27:** Maximum motor current alarm filter (sec) (1.0).
- **Blade Speed Control Max Allowed M/min /P29:** Speed set point maximum value (115,0000).
- **Blade Speed Control Min Allowed M/min /P30:** Speed set point minimum value (15).
- **Blade Speed Control An In Max Integer Value /P31:** Speed reference maximum value (analogue input maximum value) (32767.0).
- **Blade Speed Control An In Min Integer Value /P32:** Speed reference minimum value (analogue input minimum value) (0.0).
- **Blade Speed Control Before Stopping On Delay sec /P33:** Stop delay for cleaning cut (sec) (2).
- **Blade Speed Encoder Counting Direction Inverting /P34:** Blade speed encoder counter inversion (1.0000).
- **Blade Speed Encoder Max Counter Value M/min /P35:** Blade speed maximum value (115,0000).
- **Blade Speed Encoder Min Counter Value M/min /P36:** Blade speed minimum value (15).
- **Blade Speed Encoder Pulse Scaling Resolution MM or INCH/Pulse :** Blade speed encoder resolution scale factor (1).
- **Blade Motor Status On Man Cycle End Motor On = 1.0 /P37:** Blade motor on time at end of manual cycle (1.000).
- **Current treshold for max feed correction /P113:** Max. correction threshold when the blade motor overcurrent intervenes during the cut (3.000).
- **Speed encoder type /P139** (0 = Linear; 1 = logarithmic): Setting the encoder speed as linear or logarithmic (0 = linear; 1 = logarithmic) (0.0000).
- **Speed encoder logarithmic X1 threshold (count) /P140:** X1 correction factor for managing the band speed encoder in logarithmic mode (4.0000).
- **Speed encoder logarithmic X2 threshold (count) /P141:** X2 correction factor for managing the band speed encoder in logarithmic mode (8.000).
- **Speed encoder logarithmic X1 multiplier /P142:** X1 correction multiplier for managing the band speed encoder in logarithmic mode (10,0000).
- **Speed encoder logarithmic X2 multiplier /P143:** X2 correction multiplier for managing the band speed encoder in logarithmic mode (0.0000).

SHUTTLE AXIS:

- **Blade speed monitoring before enabling on delay /P43:** Delay in controlling the min. speed.
- **Blade speed monitoring wheel diameter mm or inch /P44:** Pulley diameter. (530.0000)
- **Blade speed monitoring number of pick-up pulses per round /P45:** Number of impulses/pulley turn. (13)
- **Blade speed monitoring watch dog on delay /P46:** Delay in controlling single impulses. (0.500)

- **Blade speed monitoring min speed watch dog value m or ft/min :** Min. speed in m/min or ft/min. **(10)**
- **X positive software limit (mm - inch) /P116:** Feeder max. stroke. **(450)**
- **X negative software limit (mm - inch) /P117:** Feeder min. stroke. **(0,0000)**
- **X joystick feed slow (mm/min or inch/min) /P118:** Slow feeding. **(800,0000)**
- **X joystick feed fast (mm/min or inch/min) /P119:** Fast feeding. **(1500)**
- **Over stroke x /P120:** Zeroing offset. **(0,3938)**
- **Micro engagement speed mm or in/min /P121:** Speed of search for microswitch while the trolley is zeroed. **(1500)**
- **Micro disengagement speed mm or in/min /P122:** Speed of release from the search while the trolley is zeroed. **(1500)**
- **Speed X on cycle mm/min or inch/min /p133:** **(157.4804).**

BLADE DEVIATION:

- **Blade Deviation Enable /P9** (1 = Enabled): Blade deviation enabling (1 = enabled). **(0)**
- **Blade Deviation count at zero position /P10:** Levels at zero blade deviation **(16320.0000).**
- **Blade Deviation count for division /P11:** Levels for dividing the blade deviation bar **(500.0000).**
- **Blade Deviation for scan time /P12:** Blade deviation reading time **(0.5000).**

HEAD ENCODER:

- **Blade Position Analogue In. Max Integer /P13:** Maximum counter value **(29337,0000).**
- **Blade Position Analogue In. Min Integer /P14:** Minimum counter value **(7205,0000).**
- **Blade Position Analogue In. Process Value Max MM or INCH /P15:** Maximum value in mm or inch **(333,0000).**
- **Blade Position Analogue In. Process Value Min MM or INCH /P16:** Minimum value in mm or inch **(0,0000).**
- **Blade Position Analogue In. Max Voltage Vdc /P17:** Voltage value corresponding to maximum counter value **(10,0000).**
- **Blade Position Analogue In. Min Voltage Vdc /P18:** Voltage value corresponding to minimum counter value **(0.0).**

BLADE TENSION:

- **Blade tension control large pulse width sec./P48:** **(20.0000).**
- **Blade tension control off between pulses awaiting sec./P49** **(0.7000).**
- **Blade tension control small pulse width sec./P50:** **(0.0250).**
- **Blade Tension Control Max Alarm Tension KN /P51:** Maximum voltage allowed to apply adjustment **(3000.0000).**
- **Blade Tension Control Min Alarm Tension KN /P52:** Minimum voltage allowed to apply adjustment **(600,0000).**
- **Blade tension control error large to small pulse changeover/P53:** **(100.0000).**
- **Blade tension control max error tolerance kn/P54:** **(50.0000).**
- **Blade tension control min error tolerance kn/P55:** **(- 50.0000).**

- **Blade tension control setpoint kn/P56: (3700.0000)**
- **Blade Tension Control An. In. Load Cell Max Integer Value /P57: Maximum counter value from load cell analogue input (4912,0000).**
- **Blade Tension Control An. In. Load Cell Min Integer Value /P58: Minimum counter value from load cell analogue input (32,0000).**
- **Blade Tension Control An. In. Load Cell Process Value Max KN /P59: Load cell analogue input maximum value allowed for acquisition (900,0000).**
- **Blade Tension Control An. In. Load Cell Process Value Min KN /P60: Load cell analogue input minimum value allowed for acquisition (0.0000).**
- **Blade Tension Control Enabling /P61: Automatic blade tension adjustment enable (1).**
- **Blade Tension Control An. In. Load Cell Voltage Value Max Vdc: Load cell analogue input voltage maximum value (10.0000).**
- **Blade Tension Control An. In. Load Cell Voltage Value Min Vdc: Load cell analogue input voltage minimum value (0,0000).**

CLAMPS ENCODER:

- **Clamps Locking Status Rises After Specified Secs From Command: Time needed to allow clamp closed (3).**
- **Clamps Unlocking Status Rises After Specified Secs From Command: Time needed to allow clamp open (3).**

VARIUS:

- **Time shuttle vise position setting (short remnant) sec.: (6.0000).**
- **MKS Imperial Unit System Switchover Enabling: Imperial = 0.0: sets measuring system MKS (0) or IMPERIAL (1) (1,0000).**
- **Type machine (0=H14- A; 1=H11- A; 2=H230- A) /P101: (0).**
- **Type logo (0=HYDMECH; 1= ZEPH; 2=S&F) /P146: (0).**

CUT HEAD:

- **Feed Encoder Counting Direction Inverting = 1.0 /P67: (0,0000).**
- **Feed Encoder Max Counter Value M/Min or Inch/Min /P68: (450,0000).**
- **Feed Encoder Min Counter Value M/Min or Inch/Min /P69: (0,0000).**
- **Feed Encoder Pulses Scaling Resolution MM or Inch/Pulse /P70: (2,5).**
- **Feed Encoder Counter Retention Enabling = 1.0 /P75: (1.000).**
- **U Y Feed Axis Full Stroke Width MM or Inch /P82: U axis maximum stroke (mm or inch) (300.0000).**
- **Y Cutting Axis Maximum Position MM or Inch /P86: Y axis maximum limit switch (mm or inch) (330).**
- **Y Cutting Axis Minimum Position MM or Inch /P87: Y axis minimum limit switch (mm or inch) (0.0000).**
- **Y Cutting Axis Auto Cycling Slow Down From Target MM or Inch: Deceleration space (mm or inch): distance from target position at which slow descent is set (10,0000).**
- **Y Cutting Axis Cutting Feed PID Control Error MM or Inch /P90: (2,0000).**
- **Y Cutting Axis Mode Downgoing Feed MM or Inch /P92: Y descent speed in jog mode (mm/min or inch/min) (2000,0000).**

- **Y Cutting Axis Auto Cycling Slow Down Feed MM or Inch /P93:** Slow Y position speed (mm/min or inch/min) **(1000,0000)**.
- **Y Cutting Axis All Mode Upgoing Feed MM or Inch /P94:** Y upward speed (mm/min or inch/min) **(2500,0000)**.
- **Y Cutting Axis U Opening @ Y Feed Curve Bypass = 1.0 /P95:** Descent speed linearizing curve enable (F) **(0,0000)**.
- **Y Cutting Axis Cutting Feed PID Control Increase Correction (degree):** F correction factor **(1.0000)**.
- **Y Cutting Axis Cutting Feed PID Control Time (sec) /P114:** Time between one correction and the next **(0,3000)**.
- **H encoder max counter value % /P123:** Max. displayed value of H **(100.0)**.
- **H encoder min counter value % /P124:** Min. displayed value of H **(0.000)**.
- **H potentiometer analogue input fs max /P125:** Max. levels of the H potentiometer **(32496,0000)**.
- **H potentiometer analogue input fs min /P126:** Min. levels of the H potentiometer **(16.000)**.
- **Feed force current control max (Ampere) /P127:** Max. set current of blade motor **(12)**.
- **Feed force current control min (Ampere) /P128:** Min. set current of blade motor **(5)**.
- **Y joystick feed slow (mm/min or inch/min) /P130:** Slow manual head lowering **(500)**.
- **Y joystick feed fast (mm/min or inch/min) /P131:** Fast manual head lowering **(2400,0000)**.
- **Offset fcti mm or inch /P132:** Offset for rear head limit switch **(0.0552)**.
- **Feed encoder type (0 = linear; 1 = logarithmic):** Setting the encoder feeding as linear or logarithmic (0 = linear; 1 = logarithmic) **(0.000)**.
- **Feed encoder logarithmic X1 threshold (count) /P135:** X1 correction factor for managing the head lowering speed encoder in logarithmic mode **(4.000)**.
- **Feed encoder logarithmic X2 threshold (count) /P136:** X2 correction factor for managing the head lowering speed encoder in logarithmic mode **(0.000)**.
- **Feed encoder logarithmic X1 mulitplier /P137:** X1 correction multiplier for managing the head lowering speed encoder in logarithmic mode **(1000.000)**.
- **Feed encoder logarithmic X2 mulitplier /P138:** X2 correction multiplier for managing the head lowering speed encoder in logarithmic mode **(0.000)**.

OPTIONAL:

- **Minimal Lubrification Enabling = 1.0 /P78:** Minimum lubrication enable **(1.000)**.
- **Y Raise Up On Manual Cycle (1=Enabled) /P103:** Y axis upward stroke enabled at end of manual cycle (1=enabled; 0=disabled). Y axis returns to RHLS at the end of the manual cycle **(1.0000)**.
- **Chip Conveyor Enabled (1=Enabled) /P105:** Chip ejector enable **(1.000)**.
- **Enabled Blade Minimum Speed Control (1=Enabled) /P104:** Blade speed proximity enable **(1.0000)**.
- **Type of blade tensioning (2 = electromechanical, 1 = hydraulics):** Setting the type of blade tensioning **(2.0000)**.
- **Open front vise at manual cycle end (1 = enabled):** Setting the vice opening at cutting cycle end **(1.0000)**.

-
- **Type chipconveyor (0=micro; 1=phonic whell)/P161: (1.0000).**
 - **Enabling debug (1=enabled): (0.0000).**

TIMER:

- **Hydraulic Pump Off Delay Awaited Before Stopping Sec /P96: Hydraulic pump off delay before stopping (seconds) (50.000).**
- **Chip Conveyor Time On In Auto (M in) /P107: (0.500).**
- **Chip Conveyor Time Off In Auto (M in) /P108: (0.500).**
- **Period microchip conveyor (sec) (phonic whell)/P151: (1).**

PASSWORD:

- **User password value /P99: Password value setting (7210721.000).**


Software update procedure through USB - H- 11A

The operations to update the software through a memory card are described here below.

Attention

The operations described below will delete all data of the cutting programs and of the customized settings.

- Take the sawing machine off and insert the USB stick containing the update in the port shown in the figure.




- Switch the machine on and wait for the message informing that the update has been completed. Then switch the machine off and on again to run the update.

N.B.


If the operator wants to keep the customized settings, he needs to make a backup following the operations described below before running the update.

The operations needed for the backup are listed below.

- From the Set- Up main menu select the box “User Setup” shown in the figure.




- Then, insert an empty USB stick in the suitable port: the box “Export settings” becomes green, press to save the settings.




The operations needed for the restore are listed below.

- To restore the settings saved in the backup, after the update access the screen “User Set- Up” from the Set- up menu.



- Insert the USB stick in the suitable port, the boxes “Import Settings” and “Export Settings” become green. Press the box “Import Settings” to import the previously saved settings.




Now the customized settings and the data are again available and the machine is operational.

Hydraulic systems

Machine working pressures


This section describes the procedures for vice tightening pressures by operating on the hydraulic power pack.



N.B. The vice working pressure is tightly bound to the type of material being worked and can be set if the material could be deformed or results unstable during cutting.

Both pressures can be adjusted by intervening on the relief valves of the power pack as indicated in the procedure described here below.

- Loosen the hexagonal lock nut for adjusting the pressure of the cutting and feeding vices and increase (clockwise) or decrease (counter - clockwise) the pressure displayed on the pressure gauge with an Allen wrench.



- This done, tighten the lock nut.

Warning


The power pack pressure gauges are installed on the delivery only; thus, to display the pressure on the return an additional pressure gauge must be connected in the monitoring fitting.

Mechanical systems


Blade tensioner slide play adjustment

To reduce the play which may develop over time between the blade tensioner slide and slide gibs, adjust the grub screws between the gibs and slide as follows:

- ▶ disconnect the machine from the power supply;
- ▶ Open the door on the left side of the machine.




- ▶ slacken the blade tension using the handwheel;



- ▶ Remove the blade from the flywheels;
- ▶ remove the plug connecting the slideway to the cylinder rod;
- ▶ Move the slide back and forwards to locate any friction or excessive play;

- Slacken the nuts, using a tubular nut driver to hold the grub screws firm;




- Finally, tighten the grub screws to take up any play or otherwise, slacken them to reduce any friction.
- tension the blade and power up the machine again.

Cutting head stroke

The stroke of the operating head during the cutting cycle depends on the RHLS (rear head limit switch) and FHLS (forward head limit switch) points set electronically from the control console. The operating head is anyway equipped with a mechanical limit switch determining the stroke lower limit:

- To adjust this stop, use two hex wrenches, one to lock the nut and the other to tighten or slacken the stop screw.



Blade guide components


Band saw blades offer enormous advantages to cutting applications, without requiring any special skills by the operator. A description follows of the blade guide adjustments required to ensure correct operation of the saw.

Blade guide heads

The first blade adjustment involves adjustment of the heads. The blade guide heads comprise the blade guide plates which ensure correct longitudinal alignment, the blade steady buttons which control vertical blade flexure and the coolant delivery cocks.


Blade-pressing tang

The blade-pressing tang prevents the blade from bending upwards due to the vertical component of the cutting force. This device is a component of the front and rear heads and needs no adjustment.



Blade guide plates


The plate contact points feature widia inserts which guide the blade longitudinally. A small amount of play must exist between the plates and blade to ensure that the blade runs smoothly and perpendicular to the work table.




Thanks to the widia inserts, the working life of the guide plates is practically the same as that of the machine itself. However, if due to wear or the assembly of a new blade with a different thickness, the following adjustments must be made:

- Take the head completely up to the mechanical stop.


- ▶ Cut the machine off.
- ▶ slacken the blade tension using the handwheel;
- ▶ Open the front protection cover.
- ▶ Wear protective gloves when changing the blade;
- ▶ Make sure there is a small amount of play between the blade and guide plate inserts.




- ▶ Remove the blade protections from the heads by loosening the fastening screws.



- ▶ If the amount of play is not sufficient for the blade to run smoothly, adjust the locking torque of the two grub screws with a hex wrench.



- ▶ Replace any worn plates by replacing the plate fixing screw.



- ▶ Repeat the above sequence on the front blade guide head;
- ▶ Restore the blade protections of the front and rear heads.
- ▶ close the cutting head guard, correctly tension the blade and power up the machine.


Blade

The adjustments required to ensure correct operation of the blade are described below. For further information regarding band saw blades, refer to Chapter 9 which provides a more detailed description of the different types of blade.


Tool changeover

Optimum working conditions both enhance operator safety and extend the tool service life. The cutting tool should in any case be replaced when poor cutting performance starts to affect productivity. The tool changeover procedure is described as follows:


- ▶ Take the head completely up to the mechanical stop.
- ▶ disconnect the machine from the power supply;
- ▶ slacken the blade tension using the handwheel;
- ▶ open the front protection cover.
- ▶ Wear protective gloves when changing the blade;
- ▶ move the blade cleaning brush away by loosening the knob and pulling it outwards;



- remove the blade protections from the heads by loosening the fastening screws.



- Remove the worn blade by sliding it off the flywheels and front and rear heads;




- fit the new blade into the blade guide heads and make sure there is a minimum amount of play between the blade and the plates;
- restore the blade protections of the front and rear heads and position again the blade- cleaning brush correctly.
- close the cutting head guard, correctly tension the blade and power up the machine.

Blade perpendicularity


The perpendicularity of the blade to the work surface plus the blade tension are vital for achieving straight cuts. This adjustment is carried out with the help of a goniometer and a workshop square which should be placed adjacent to the blade resting on the work surface.

- Open the cutting vice;
- position the head so that the band is above the vice jaws;


- position the square on the well cleaned reference plane and rest it on the blade, close to the movable vice square and head, in a position where teeth do not hinder the contact.



- If the band has the contact point in the upper part of the square: loosen the socket head screws (A and A') fastening the head, loosen the two dowels (B' and B') and tighten the two dowels (B and B). If instead the contact point is in the lower part, loosen the socket head screws (A and A'), loosen the two dowels (B and B) and tighten the dowels (B' and B') until the band is perpendicular to the square.



- Position the square on the working table close to the fixed vice square and head.




- Repeat the squaring operations as for the rear head.

Blade orthogonality


The procedure for correcting and adjusting the blade to 0 degrees in order to make cuts at right angles to the fixed vice jaw.

To make orthogonal adjustments at 0° , use a workshop goniometer or a simple 90° square. Operation sequence:

- ▶ Lay a grounded plate on the feeder rollers;
- ▶ lower the head to HDL;
- ▶ position the square, resting it on the movable vice square, close to the band;



- ▶ loosen the socket head screws (A and B) fastening the head, and adjust the dowels (A', A'', B' and B'') evenly until the band is perpendicular to the piece-supporting shoulder.




- ▶ After adjusting, check and restore blade perpendicularity.


Rotation axis control

Pulleys must be adjusted in their coplanarity. The adjustment is aimed at ensuring the belt rotation, keeping approx. 6 mm (0.24 in) of distance from the point of the belt teeth to the pulley machined surface. This prevents an early wear of the belt.

- ▶ De- tension the band and remove the blade protection;
- ▶ slacken the grub screw and, using a mallet, tap the shaft in or out;
- ▶ Position again the blade protection and make the blade turn;
- ▶ check the distance between the blade and edge of the wheels;



- ▶ if necessary, repeat the operation till getting the correct position. Rear flywheel alignment is closely linked to adjustment of the front flywheel.
- ▶ Adjust by loosening all pulley locking screws and moving the pulley manually inwards or outwards according to the distance of the blade from the pulley machined surface. Tighten the screws again and check the coplanarity making the belt turn a few times.




Feeder


Should the feeder at a later stage in time become misaligned with the cutting table, then use the levelling devices located on the side of the machine and the loading table to restore. Misalignment can be measured using a workshop standard ruler or a straight bar section.

- ▶ In order to facilitate making this adjustment, it is necessary to fully open the jaws and cutting power, then remove the caps on the rear of the machine


shown in the figure, and open the side door.



- Place the ruler on top of the feeder to check that the feeder is parallel to the cutting table.




- The material to be cut should touch and not rub along the machine work table, make sure that the height of the feeder is at least $0,2 \div 0,5$ mm ($0.008 \div 0.020$ in) above the cutting table.




In the case reveal anomalies of coplanarity, proceed before intervening on the fixed roller of the cutting plane and then on the fixed rear of the feeder.

- Put the truck feeder all the way forward;
- positioning a row Workshop on front roller of the carriage and the fixed roller feeder of the cutting plane, in order to evaluate the distance (light) between the line and the cutting plane (the optimum height is from 0,2 to 0,5 mm or from 0.008 to 0.020 in).
- Loosen from both sides of the two screws shown in figure A and A', then raise or lower the roller through the grains B and B' until reaching the optimal share. At the end tighten the fixing screws of A and A'.




Leaving the line workshop on the rollers, proceed with the adjustment of the coplanarity of the entire feeder:

- Put the truck feeder completely backward.
- After having set the height next to the fixed platform, always with the ground ruler, adapt the rest of the feeder adjusting the height of the supporting brackets by the suitable slots.




-
- ▶ Assess the height of the last feed roller through the line to the workshop.



- ▶ In the case where it was necessary to align also this roller must loosen the screws from both sides and adjust the height up to touch the line workshop

Maintenance and choice of consumables



H- 11A is built to be sturdy and long- lasting It has no need of any special maintenance, though, like all other tools, it needs adjusting from time to time, especially if not regularly looked over or used without due care.

This chapter, therefore, is intended as a guide for those who want to look after the machine and get the most out of it for as long as possible.

The role of the operator

The person operating and maintaining the machine must follow these instructions for his own safety, as well as for the safety of other personnel, and in the interests of machine productivity:

- check that his own work and that of the other operators of the machine always complies with the relevant safety standards. Therefore, check that the safety devices are in position and work perfectly and that personal safety requirements are complied with.
- Ensure that the working cycle is efficient and guarantees maximum productivity, checking:
 - ✓ the functions of the main components of the machine;
 - ✓ the sharpness of the blade and coolant flow;
 - ✓ the optimum working parameters for the type of material.
- Check that the quality of the cut is that required and that the final product does not have any machining defects.

Maintenance requirements

- All ordinary and extraordinary maintenance must be carried out with the power switched off and the machine in emergency condition.
- To guarantee perfect operation, all spare parts must be Hyd- Mech originals.
- On completion of maintenance works, ensure that the replaced parts or any tools used have been removed from the machine before starting it up.

-
- Any behaviour not in accordance with the instructions for using the machine may create risks for the operator.
 - Therefore, read and follow all the instructions for use and maintenance of the machine and those on the product itself.

General maintenance

This section lists the various routine maintenance procedures:

Daily

- ▶ remove all swarf from the machine (preferably with a non- fibrous cloth);
- ▶ empty the swarf drawer (this is located on the right side of the base);
- ▶ top up the lubricant/coolant level;
- ▶ check state of blade wear and replace if necessary;
- ▶ Check the blade for wear and, if necessary, replace;
- ▶ control the oil level of the hydraulic unit and top up whenever necessary. Check for oil leaks in the hydraulic couplings and that no pipes have been badly bent by accident;

Weekly

- ▶ Remove all swarf from the machine;
- ▶ Clean the vice and lubricate all the articulated joints and sliding surfaces with a good quality oil.
- ▶ Check the vice sliding; if it is not accurate and shows a cross clearance, adjust as indicated in Chapt. 7.

Monthly

- ▶ Make sure the blade is perpendicular to the work surface and; if necessary, adjust as described in Chapter 7.
- ▶ Make sure the blade is orthogonal to the workpiece rest shoulder and if necessary, adjust as described in Chapter 7.
- ▶ Make sure that the 0° notch on the fixed work table is aligned with the graduated scale on the turntable. If necessary, adjust by regulating the 0° stop; This done, make sure the blade is perpendicular to the work surface and orthogonal to the shoulder.
- ▶ Clean the air duct to the switchboard, remove the fan and clean the air filter with compressed air.
- ▶ Control the plane alignment of the feeder with the cutting table; if it requires adjustment, refer to Chapter 7).
- ▶ Check the state of the widia inserts and the blade steady button, if worn or chipped, replace. Also check their position and, if necessary, adjust (see Chapter 7).

-
- Thoroughly clean the bottom of the water tank and the filter on the electric pump.

Maintenance of working parts

Maintenance personnel working on the **H- 11A** must pay particular attention to operating components such as the blade tensioning cylinder (already dealt with in Chapter 7), loading, the air treatment unit and the pneumatic vice. No maintenance is required for the worm screw reduction gear fitted on the machine.

Consumable materials

It is essential to use specific oils for the pneumatic and lubricant/coolant circuits. The oils suitable for each of these circuits are listed below.

Oils for hydraulic circuit

The machine hydraulic system is supplied with oil FOX YE 32, used by the head cylinder, the vice cylinders and the hydraulic control unit; the compatible oils, or with equivalent features, are indicated here below:

API Cis 32 - ARAL Vitam GF 32 - CASTROL Hyspin AWS 32
ESSO Nuto H 32 / HP 32 - IP Hydrus oil 32 - TOTAL Azolla ZS 32
VALVOLINE Hydraulic HLP 32 - MOBIL DTE 24 / 25 / 26
MOBIL Vacuoline Oil 1405 - FIAT HTF 32 - Q8 Haydn 32
SHELL Tellus oil 32 - BP Energol HLP 32

Hydraulic power pack:
- reservoir capacity litres 36,0

Oils for lubricant/coolant fluid

The lubricant/coolant fluid used by the machine is CASTROL Syntolin TFX. In the absence of specific standards regulating this type of oil, we have selected this product on the basis of its excellent quality- price ratio. The following oils may also be regarded as compatible or having equivalent specifications:

AGIP NB 200 - SHELL Litem TT - IP Utens Fluid- F

Another lubricant/coolant oil guaranteed and distributed by LENOX, a band saw blade manufacturer, is BAND- ADE SAWING FLUID LENOX.

- tank capacity litres 200
- oil concentration 5- 6 %

Oils for worm reduction gear

The machine is equipped with a worm reduction gear which is permanently lubricated and therefore maintenance- free. The unit in fact has no filler cap, level plug or drain plug since it already contains the quantity of synthetic oil required to permanently lubricate the helical worm gear and worm screw. A brief list of synthetic oils for permanent lubrication is given below:

BP Energol SG XP220 - KLUBER Syntheso D220EP
ESSO Glycolube Range 220 - IP CT614 - SHELL Tivela Oil SC 320
FINA Girans.

- reduction gear capacity litres 0,320


Oils for spray mist system (optional)

The oil type used for the machine spray mist system is the cutting oil: Blaser Vascomill F 22.

Though there are no specific standards for these types of oils, Hyd- Mech considers that the above product has the best price/quality rapport. The following oils can also be said to have similar characteristics and are therefore compatible:

SHELL MACROM 401 F22 - AGIP ESTRAMET F20

Cutting speed and choice of tools



The cutting speed is determined by the blade rotation speed and head feed speed. While the latter depends on head movement, the blade rotation speed may be either fixed or variable. This chapter indicates the cutting speeds obtainable on the standard machine version, and also the speeds obtained using the optional electronic speed control (inverter). When using the **H- 11A** the correct blade must always be selected for the type of material being cut. This chapter explains the limitations and specific applications of the different types of blade available.

Cutting speed

Standard machine

The standard version with 4- pole motor, has a speed range from 15 to 115 m/min (49÷377 ft/min). The inverter is an electronic instrument installed on the **H- 11A**, to control the rpm of the spindle motor. This instrument simplifies special cutting jobs by adjusting the blade rotation speed to suit the kind of material being cut. It thus optimises blade usage, since you can adapt a blade not designed for a specific type of material and avoid premature blade wear. The inverter's specifications are set out below as listed earlier in the "*Machine specifications*" table in Chapter 1.

Inverter technical specifications	
Protection rating	IP 54
Vibration and shock resistance (EN50178)	fup to 5.9 m/sec ²
Max. relative humidity	from 20% to 95%
Acceptable Temperature Range (EN 50178)	For working from - 10° C to + 50° C (remove fan cover if temperature exceeds 40 C°)
Max. altitude	1000 mt. (3242.5 ft) without derating
Supply	- single phase: 230V
	- three phase: 400V
Frequency	50/60 Hz
Output voltage	Maximum voltage equal to supply voltage
Output frequency range	from 50 to 400 Hz with increase of 1 Hz
Max. transients	150% of electronic speed control rated current for 60 secs.
Frequency resolution	- Display: 0,1 Hz - Analogue inputs: 0,003 Hz per 100 Hz max.
Switching frequency	Adjustable from 0 to 15 Hz max.

Inverter technical specifications	
Electronic speed control protection and safety devices Motor protections Motor protections	Galvanic insulation between power and control panel
	Short circuit protection: - of available internal supplies; - between U- V- W output phases between phase and earth for calibres from 5.5 to 15Kw
	Thermal protection against overheating and overcurrents
	Mains undervoltage and overvoltage safety devices
	Braking overvoltage safety devices
Motor protections	Built- in electronic speed control protection with I2t calculation

Choice of blade

When using band saws to cut metals, an important factor is the choice of pitch, i.e. the number of teeth per inch (25.4 mm.), which must be suitable for the workpiece material. The following recommendations may be taken as general guidelines:

- thin- walled materials, such as sheet steel, tubes and profiles require a fine pitch frequency. 3 to 6 teeth should be engaged in the breadth of the material at any one time;
- large section cutting requires a coarse pitch to cope with the higher volume of swarf and optimal tooth penetration;
- soft materials (aluminium alloys, soft bronze etc.) also require a coarse tooth pitch.

Saw tooth pitch

The choice of teeth per inch, therefore, depends on various factors:

- the size of the section;
- the hardness of the material;
- workpiece wall breadth.

Very large dimensions require coarse teeth, while small dimensions require finer teeth. Whatever the case, ensure that there are always at least six teeth engaged in the cut, with reference to the thinnest vertical walls positioned transversally to the blade. Concerning the type of H machine, a first broad distinction can be made according to the hardness of materials:

	Mild steels < 61 HRB	Hard steels > 65 HRB
	NR. TEETH/INCH	NR. TEETH/INCH
MINIMUM	3 / 4	5 / 8
OPTIMUM	4 / 6	6 / 10
MAXIMUM	8 / 12	10 / 14


Cutting speed and downstroke speed

The cutting speed (m/min or ft/min) and the downstroke speed (cm²/min or in²/min) are limited by the heat generated around the points of the teeth. If the downstroke speed is too high, the cut will not be straight, either vertically or horizontally. The cutting speed depends, as indicated above, on the tensile


strength of the material (kg/mm^2), its hardness (HRB) and the thickness of largest sections. The downstroke speed depends on the material thickness. Therefore, large- section, solid or thick- walled materials ($s > 5 \text{ mm}$ or 0.20 in), can be cut at high speeds, providing there is sufficient swarf removal from the blade; thin- walled materials, such as slim piping or profiles, must be cut using low and especially constant downstroke speeds. A new blade must be worn in, which in effect means lowering the downstroke speed to about half that of normal (from 60 to $70 \text{ cm}^2/\text{min}$ or 9.3 to $10.85 \text{ in}^2/\text{min}$ on normal steels), equal to a removed surface area of about $300 - 600 \text{ cm}^2$ ($46.50 - 93 \text{ in}^2$).

Types of swarf:


- Very fine or fragmented swarf indicates that the downstroke speed and/or cutting pressure is too low.



- Thick and/or blue swarf indicates that the blade is overloaded.



- Long coils of swarf indicate ideal cutting conditions.



Lubricant/coolant fluid



The lubricant/coolant fluid must ensure so that neither the saw teeth nor the work piece material in the cutting zone overheat. Furthermore, there must be a sufficient quantity and pressure of lubricant/coolant to remove swarf from the cutting zone. The lubricant/coolant fluid must be of the highest quality in order to prevent tooth abrasion and welding of swarf to the teeth themselves (seizing).

Blade structure

The most commonly used blades are the bimetal types, i.e. manufactured with a silicon steel body and having a high fatigue strength, and super high- speed steel teeth; the two parts are welded by electronic or laser- welding.

Standardised teeth types are termed M2 and M42; the difference being that M42 teeth are harder due to the addition of cobalt to the steel used to make the teeth.

Key											
Mo	Molybdenum	Ni	Nickel	Si	Silicon	V	Vanadium	W	Tungsten		
Al	Aluminium	C	Carbon	Co	Cobalt	Cr	Chromium	Mn	Manganese		

TYPE OF BLADE	C	Mn	Si	Cr	W	Mo	V	Ni	Co	Al	HRC
	0,47	0,75	0,22	1,00		1,00	0,12	0,52		0,08	45- 50
HSS M2 HRC 65- 66  HRC 45- 50	0,85	0,25	0,30	4,15	6,37	5,00	1,92				64- 66
HSS M42 HRC 67- 68  HRC 45- 50	1,07	0,25	0,20	3,75	1,50	9,50	1,15		8,00		67- 69

N.B. The numbers in the columns indicate the % content of the element in the steel.


Blade types

The blades fitted on the **H- 11A** , are 4500 x 41 x 1,3 mm. (177.16x1.34x0.04 in); in addition to their size and number of teeth per inch, blades also have other geometric characteristics that vary depending on their particular application:

- tooth cutting angle (rake), can be 0° or positive;
- the tooth pitch can be constant or variable;
- the set, i.e. the various teeth alignments, have many possible configurations.

Conventional rake

Cutting angle 0° , constant pitch.




In general use, for small or medium section cast iron or steels and rolled materials, for straight or angled cuts.



Positive rake

Positive cutting angle $9-10^\circ$, constant pitch.




Can be used for cutting all types of materials, and is particularly suited to low- carbon and non- ferrous steels. Used for cutting very large sections and diameters.



Variable pitch

These blades have groups of teeth having different pitches and, as a consequence, have various tooth dimensions and differing relief angles. These are also available in M2 and M42 types with zero and positive rakes. The alternation of the different types of teeth helps to prevent vibration and noise. Elimination of vibration increases the useful life of the tool and improves the cut surface finish.




A further advantage in using these types of blades lies in the fact that a wide range of different material types and dimensions can be cut with the same blade.



Variable pitch blades with 0° cutting angle


This type of tooth formation is ideal for cutting single pipes or medium size bundles, in accordance with the capacity of the machine.



Pitches available: 3- 4 / 4- 6 / 5- 7 / 5- 8 / 6- 10 / 8- 12 / 10- 14.

Variable pitch with positive rake (from 9 to 10 degrees)

This toothing type is the most suitable for cutting large dimension pipes and profiles, including large sections, as well as for cutting solid sections up to the machine capacity limit.




Pitches available: 3- 4 / 4- 6.

Set:

The term set refers to the section of material removed by the blade during the cutting operation, i.e. relating to width of cut and the offset position of the teeth with respect to the blade back.

Standard or splayed set


This term is used to describe an alternated angling of the teeth: one to the right, one to the left and one straight.



For general use on materials over 5 mm. (0.20 in) thick. Suitable for cutting steels, castings and non-ferrous hard materials.

Undulated set


Used to describe groups of teeth undulating alternatively to the right and left.



This type of set is used with very fine teeth for cutting thin pipe walls and small-section profiles (from 1 to 3 mm or from 0.04 to 0.12 in).

Alternating grouped sets


These are groups of teeth angled to the right, one straight tooth, then a further group angled to the left.



This set is used for very fine teeth for cutting very thin sections (less than 1 mm or 0.04 in).


Alternating set

This set is one tooth to the right followed by one to the left.



This set is used for soft non-ferrous materials, plastics and wood.

Blade selection table relating to cutting speed and downstroke speed

		Dimensions of the cutting section S (mm)															
		Cutting material	Cutting speed mt./min	S<10	10<S<30	30<S<50	50<S<80	80<S<120				120<S<230	Lubrication	sq. mt./min. cut			
Structural steel Casehardened steel Steel for turning Mild steel	50 / 70	14	10 / 14	10	10 / 14	8	6 / 10	6	5 / 8	4	4 / 6	3	3 / 4	Emulsible oil Cutting fluid	60 - 70		
	High-duty cast iron Rolled steel Spring steel	40 / 50	14	10 / 14	10	10 / 14	8	6 / 10	6	5 / 8	4	4 / 6	3	3 / 4	Emulsible oil	50 - 60	
		Alloy steel	30 / 40	14	10 / 14	10	10 / 14	8	6 / 10	6	5 / 8	4	4 / 6	3	3 / 4	Emulsible oil Cutting fluid	15 - 20
		Tool steel Valve steel		14	10 / 14	10	10 / 14	8	6 / 10	6	5 / 8	4	4 / 6	3	3 / 4	Emulsible oil	15 - 20
Stainless steel Nodular cast iron	30 / 40	14	10 / 14	10	10 / 14	8	6 / 10	6	5 / 8	4	4 / 6	3	3 / 4	Emulsible oil	15 - 20		
Copper Soft bronze	90 / 150	14	10 / 14	10	10 / 14	6	5 / 8	4	4 / 6	3	3 / 4	3	3 / 4	Emulsible oil	75 - 90		
Brass	90 / 300	14	10 / 14	10	10 / 14	6	5 / 8	4	4 / 6	3	3 / 4	3	3 / 4	Emulsible oil	80 - 90		
Hard bronze	20 / 40	14	10 / 14	10	10 / 14	6	5 / 8	4	4 / 6	3	3 / 4	3	3 / 4	Emulsible oil	25 - 40		
Aluminium	80 / 800	14	10 / 14	6	10 / 14	4	4 / 6	3	3 / 4	3	3 / 4	3	3 / 4	Emulsible oil	70 - 80		
Plastics	90 / 400	14	10 / 14	6	10 / 14	4	4 / 6	4	4 / 6	3	3 / 4	3	3 / 4	Emulsible oil	80 - 90		
		Blade pitch				Number of teeth per inch											

Classification of steels


This page provides a table giving the user specific information on the cutting materials, in order that they can be classified on the basis of their hardness, and thus the correct tool can be selected for the task in hand.

Types of steel				Hardness		
UNI	DIN	BS	AISI	Brinell HB	HRB	Kg/mm ^q
C 22 - C 35	CK 22 - CK 3	En 2 C - En 6	1022 - 1035	160 - 170	34 - 87	55 - 59
C 45	CK 45	En 8	1040	160 - 180	84 - 89	55 - 61
C 10 - C 15	CK 10 - CK 15	En 32 A - En 328	1010 - 1015	150 - 175	81 - 87	51 - 59
C 60	CK 60	En 9	1060	160 - 180	84 - 89	55 - 61
		4360 - 50 A		160 - 180	84 - 89	55 - 61
	17100	3706 - 1.2.3.	ASTMA - 36/68	160 - 180	84 - 89	55 - 61
45 Cr Si 9	17115	4360		160 - 180	84 - 89	55 - 61
		En 20 A		190 - 215	91 - 97	64 - 73
34 Cr Mo 5	17221	970 - 1955	1065	180 - 205	89 - 94	61 - 69
		En 18 B	5135 - 5145	180 - 200	89 - 93	61 - 67
35 Cr Mo 4	34 Cr Mo	En 19 B	4135	200 - 230	93 - 99	67 - 77
	36 Ni Cr 6	En 111	3135	190 - 230	91 - 99	64 - 77
		En 36	3310 - 3315	200 - 230	93 - 99	67 - 77
20 Nc Cr Mo 2		En 362	4315	200 - 225	93 - 98	67 - 75
		En 100 D	8645	190 - 220	91 - 97	64 - 74
	1880 X C 95	DX	W 1	150 - 190	80 - 91	51 - 64
100 Cr 6	100 Cr 6	En 31	52100	210 - 230	96 - 99	71 - 77
		B 2	L 6	190 - 230	91 - 99	64 - 77
52 Nc Cr Mo KU	56 Ni Cr Mo V 7			217 - 248	97 - 102	73 - 83
	2750 (280W18)	18 % W	T 1	217 - 248	97 - 102	73 - 83
		1507 - 825	1310	160 - 220	84 - 91	55 - 64
		A 2	M 13	200 - 230	93 - 99	67 - 77
	210 Cr 46	A 1	D 3	215 - 240	97 - 101	73 - 81
	4845	En 58 G	309 S	150 - 200	80 - 93	51 - 67
X 12 Cr 13	4001	En 56 A	410	150 - 200	80 - 93	51 - 67
X 6 Cr Ni 1810	4301	En 58 E	304	130 - 170	74 - 86	45 - 58
X Cr Ni 1910						
X 8 Cr Ni Mo 1713	4401	1501 - 845	316	160 - 200	84 - 93	55 - 67
Phosphor bronze				60 - 100	56,5	36
Aluminium bronze				70 - 90	49	32
Manganese bronze				95 - 120	51 - 69	34 - 42
Silicon bronze				70 - 100	56,5	36

Classification of steels



Material	SS Svezia	AISI U.S.A.	DIN Germania	BS Inghilterra	UNI Italia	AFNOR Francia
Carbon steels	1311 1572	1015 - 1035	C 22 - C 35 20 Mn 5 - 28 Mn 6 CK 22 - CK 50	050 A 20 080 M 46 - 50 120 M 19 150 M 28	C 15 - C 35 C 22 Mn C 28 Mn	XC 18 XC 38 H 1 20 M 5
Carbon steels	1650 1880	1040 - 1064 1770 - 1880	CK 60 - CK 101 36 Mn 5 Cm 45 - Cm 55	060 A 40 - 060 A 96 070 M 55 080 A 40 - 080 A 62	C 45 - C 60	XC 60 - XC 75 40 M 5 XC 42 H 1 XC 55 H 1
Alloy steel	2120 2255	1335 - 1345 4130 - 4140	25 Cr Mo 4 - 42 Cr Mo 4	1717 CDS 110 708 A 37 708 M 40	25 Cr Mo 4 - 42 Cr Mo 4	25 CD 4 42 CD 4
Alloy steels	2541 2230 2258	4337 - 4340 50100 - 52100 6145 - 6152 8630 - 8645	40 Ni Cr Mo 6 40 Ni Cr Mo 73 34 Cr Ni Mo 6, 100 Cr 6	735 A 50, 534 A 99 817 M 40 311 tipo 6 e 7	40 Ni Cr Mo 2 - 40 Ni Cr Mo 7 30 Ni Cr Mo 8 - 35 Ni Cr Mo 6 KB 50 Cr V 4, 100 Cr 6	35 NCD 6 50 CV 4 100 C 6
Tool steels	2310 - 12 2754 - 55	D - 2, D - 3	X 210 Cr 12 X 155 Cr V Mo 121	BD 2, BD 3	X 205 Cr 12 KU X 155 Cr V Mo 121 KU	Z 160 CVD 12 Z 200 C 12
Tool steel	2550 2710	S - 1	60 W Cr V 7 55 Ni Cr Mo V 6	BS 1	55 W Cr V 8 Ku 55 Ni Cr Mo V 6	55 NCVD 7
Stainless steels	2324 2333	201, 202 302, 304	X 2 Cr Ni 189 X 5 Cr Ni 189 G - X 2 Cr Ni 189	304 S 15 304 C 12 304 S 12	X 2 Cr Ni 18.11 X 5 Cr Ni 18.10 G - X 2 Cr Ni 19.10	Z 2 CN 18.10 Z 6 CN 18.09 Z 3 CN 19.10
Stainless steel	2343 2353	314, 316 317	X 15 Cr Ni Si 2520 X 5 Cr Ni Mo 1812 X 5 Cr Ni Mo 1713	316 S 16 317 S 16	X 16 Cr Ni Si 2520 X 5 Cr Ni Mo 1713 X 5 Cr Ni Mo 1815	Z 12 CNS 25.20 Z 6 CND 17.12


Troubleshooting






This chapter describes the inspection and troubleshooting procedures for the **H- 11A** . Regular inspections and efficient maintenance are essential to ensure your machine gives you a long, trouble- free service life. The chapter is divided into two sections: the first being dedicated specifically to **TROUBLESHOOTING BLADE AND CUTTING PROBLEMS**, while the second **TROUBLESHOOTING** section concerns troubleshooting general machine operating faults. Taken together they form a comprehensive troubleshooting guide which will enable you to follow a methodical procedure for solving any problem.


Troubleshooting blade and cutting problems






PROBLEM	PROBABLE CAUSE	SOLUTION
Blade scored or scratched 	♦ Widia inserts chipped or worn	☞ Replace
	♦ Widia inserts loose or tight	☞ Adjust
	♦ Widia inserts dirty	☞ Clean and re- adjust correctly
Cutting surfaces scored 	♦ Blade teeth worn	☞ Replace blade
	♦ Head downstroke speed too fast	☞ Reduce downstroke speed
	♦ Cutting speed too slow	☞ Increase cutting speed
	♦ Blade teeth too wide	☞ Change for wider teeth
	♦ Free blade guide head too far away	☞ Move blade guide head closer so as to leave only that part of the blade free which is needed to effect the cut
	♦ Blade tension low	☞ Reset tension to rated tension
	♦ Broken teeth on blade	☞ Check and replace blade

PROBLEM	PROBABLE CAUSE	SOLUTION
Rapid tooth wear 	<p>▶ Teeth pointing in the wrong direction</p>	<p>☞ Set teeth in correct direction</p>
	<p>▶ Blade worn in wrongly</p>	<p>☞ With a new blade cutting should be done at half-speed and with downstroke speed also at half normal speed. After the blade has been worn in (about 300 cm² of work for hard cutting materials and about 1000 cm² for soft cutting materials) the cutting and downstroke speeds can be brought up to rated levels</p>
	<p>▶ Material too hard</p>	<p>☞ Check cutting speed, downstroke speed and blade pressure, as well as type of band saw being used</p>
	<p>▶ Material defective</p>	<p>☞ Surface defects: oxides, sand, surface hardening. Hardened inclusions in section. Reduce cutting and downstroke speeds or clean surface.</p>
	<p>▶ Cutting speed too high</p>	<p>☞ The teeth slide on the material without cutting: reduce cutting speed</p>
	<p>▶ Head downstroke speed too slow</p>	<p>☞ The band saw runs over the material without removing it: increase downstroke speed</p>
	<p>▶ Insufficient coolant</p>	<p>☞ Check coolant level and clean pipes and jets</p>
	<p>▶ Incorrect fluid concentration</p>	<p>☞ Check and use the correct concentration</p>
	<p>▶ New blade inserted into a partially-made cut</p>	<p>☞ The cutting surface might have been subject to a localised heat-induced alteration, making it harder: recommence cut using a slower cutting and downstroke speed. There may be a broken tooth from the old blade lodged in the cut: check and remove before recommencing work</p>
	<p>▶ Flutter</p>	<p>☞ Blade tension too low: tighten. Tooth shape or pitch unacceptable: change type of blade used. Widia blade steady buttons too far from the blade back: adjust guide heads, rotating them slightly to bring them closer to the blade back.</p>

PROBLEM	PROBABLE CAUSE	SOLUTION
Cuts not orthogonal or inclined 	<ul style="list-style-type: none"> Head downstroke speed too fast 	<ul style="list-style-type: none"> Reduce head downstroke speed
	<ul style="list-style-type: none"> Widia inserts worn 	<ul style="list-style-type: none"> Replace
	<ul style="list-style-type: none"> Inserts loose 	<ul style="list-style-type: none"> Adjust width
	<ul style="list-style-type: none"> Blade guide head positioned wrongly 	<ul style="list-style-type: none"> Move mobile head up to the workpiece using the guide plate to leave free only that part of the blade actually needed to make the cut
	<ul style="list-style-type: none"> Orthogonality of blade to workpiece rest shoulder 	<ul style="list-style-type: none"> Check and realign the blade guide heads, then reset the blade orthogonality with the shoulder using the adjustment pin at 0°; then set the stops at 45° right and left by means of the appropriate screws
	<ul style="list-style-type: none"> Perpendicularity of the blade to the work surface 	<ul style="list-style-type: none"> Check and realign the blade guide heads then adjust the blade using the appropriate screws so that it is perpendicular to the work surface
	<ul style="list-style-type: none"> Blade tension incorrect 	<ul style="list-style-type: none"> Bring pressure up to 60 Bar
	<ul style="list-style-type: none"> Blade worn 	<ul style="list-style-type: none"> Replace blade
	<ul style="list-style-type: none"> Tooth pitch unsuitable 	<ul style="list-style-type: none"> Probably a blade with too many teeth per inch is being used; change for a coarser blade
	<ul style="list-style-type: none"> Cutting speed too slow 	<ul style="list-style-type: none"> Increase the cutting speed
	<ul style="list-style-type: none"> Wrong coolant 	<ul style="list-style-type: none"> Check the water and oil emulsion; check that none of the holes or hoses are blocked; direct the jets correctly
	<ul style="list-style-type: none"> Broken teeth 	<ul style="list-style-type: none"> Check the hardness of the material being cut
Broken teeth 	<ul style="list-style-type: none"> Cutting speed too high 	<ul style="list-style-type: none"> Reduce cutting speed
	<ul style="list-style-type: none"> Downstroke speed too high 	<ul style="list-style-type: none"> Reduce downstroke speed

PROBLEM	PROBABLE CAUSE	SOLUTION
Broken teeth 	<p>▶ Cutting pressure too high</p>	<p>☞ Check and set to correct pressure</p>
	<p>▶ Tooth pitch unsuitable</p>	<p>☞ Teeth too close together: change blade for one with a coarser tooth pitch</p>
	<p>▶ Tooth gullets full of swarf</p>	<p>☞ Check blade- cleaning brush</p>
	<p>▶ Swarf welded to teeth and gullets</p>	<p>☞ Check blade- cleaning fluid jets. Check blade- cleaning brush. If the swarf is not removed from the blade it will be drawn back into the cut and weld to the teeth, causing the teeth to break.</p>
	<p>▶ Material defects</p>	<p>☞ The material may have altered surface areas, such as oxides or sand, or subcooled inclusions in the section. These areas are much harder than the blade and will cause the teeth to break: scrap or clean these materials.</p>
	<p>▶ Workpiece not clamped</p>	<p>☞ The blade may break if the workpiece moves during cutting: check the vice, jaws and clamping pressure</p>
	<p>▶ The blade stops in the cut</p>	<p>☞ Cutting pressure too high: check and restore to rated pressure. Downstroke speed too fast: reduce speed. Cutting speed too slow: increase. The blade slips on the flywheels: either the wheels are worn and need to be replaced or the blade tension is incorrect (too low) and must be re-adjusted.</p>
	<p>▶ New blade inserted in a partially made cut</p>	<p>☞ The cutting surface may have been subjected to a localised heat- induced alteration, making it harder: recommence cut using a slower cutting and downstroke speed. A tooth from the old blade may be left in the cut: check and remove before re-starting work.</p>

PROBLEM	PROBABLE CAUSE	SOLUTION
Broken teeth 	<p>◆ Widia inserts positioned incorrectly</p>	<p>☞ Adjust the position of the inserts, especially the width, since blade thicknesses can exceed the manufacturer's declared tolerance ratings</p>
	<p>◆ Widia blade steady buttons</p>	<p>☞ Two widia blade steady buttons are located in the top of the blade guide heads which press on the back of the blade to transmit cutting pressure. If these buttons are too far from the blade, the blade may be prone to an up and down undulating action or abnormal vibrations, liable to cause the teeth to break: adjust the position of the heads by rotating them downwards so as to bring the blade steady buttons up against the back of the blade</p>
	<p>◆ Sections with large thickness variations</p>	<p>☞ The cutting speed and downstroke speed must be chosen to suit the most critical part of the cut</p>
	<p>◆ Teeth angled in the wrong direction</p>	<p>☞ Fit blade so that teeth point in the right direction</p>
	<p>◆ Blade run in wrongly</p>	<p>☞ When using a new blade, the cutting and downstroke speeds must be reduced to half the normal operating speed. After the blade has been worn in (about 300 cm² for hard materials and about 1000 cm² for soft materials) the cutting and downstroke speeds may be returned to their rated levels</p>
	<p>◆ Insufficient coolant</p>	<p>☞ Check coolant level and clean fluid lines and jets</p>
	<p>◆ Incorrect fluid concentration</p>	<p>☞ Check and use the correct concentration</p>
	<p>◆ Blade tension too high or too low</p>	<p>☞ Check and reset to rated tension</p>

PROBLEM	PROBABLE CAUSE	SOLUTION
Blade path fault 	♦ Front flywheel position incorrect	☞ Check that the band saw is correctly positioned on the flywheel. Adjust the position of the flywheel under the blade, moving the shaft of the flywheel
	♦ Flywheels worn	☞ Replace
	♦ Gaps full of swarf	☞ Clean inside machine using blown air.
	♦ Blade guide head alignment	☞ Check and adjust
Blade broken    	♦ Cutting speed too high	☞ Reduce cutting speed
	♦ Head downstroke too fast	☞ Reduce head downstroke speed
	♦ Cutting pressure too high	☞ Check and set to correct pressure
	♦ Tooth pitch unsuitable	☞ Teeth too close together: change the blade for one with coarser tooth spacings
	♦ Workpiece not clamped properly	☞ The blade may break if the workpiece moves during cutting: check the vice, jaws and clamping pressure.
	♦ Widia inserts positioned incorrectly	☞ Adjust inserts position, especially the width, since blade thickness can exceed the manufacturer's declared tolerance ratings
	♦ Widia blade steady buttons	☞ Can have a milling action on the back of the blade if worn or chipped, causing cracks from the back towards the teeth.
	♦ Position of blade on flywheels incorrect	☞ The blade may be scraping on the edges of the flywheels: this problem is generally caused by blades which are deformed or wrongly welded (conical) Adjust the position of the front flywheel by moving the pin, or change the blade
	♦ Blade tension incorrect	☞ If the blade tension is too high or too low, the blade will be subjected to abnormal stress: set the tension back to the rated value.

PROBLEM	PROBABLE CAUSE	SOLUTION
	◆ Blade weld fault	✍ The point at which a blade is welded is its most critical point; problems could be caused by welds which are not aligned perfectly or have inclusions or blowholes
	◆ Free blade guide head	✍ The head is too far away from the workpiece: move the head closer, leaving free only that part of the blade actually needed to make the cut
	◆ Teeth in contact with the material before starting the cut	✍ Always check the position of the blade before starting a new job, especially for the semi-automatic cycle
	◆ Widia inserts	✍ If worn, the inserts can score the blade, weakening it even to breaking point. If the inserts are too far apart, the blade will whip, striking both the inserts and the material. Replace or adjust
	◆ Insufficient coolant	✍ Check coolant fluid level; clean pipes and jets
	◆ Incorrect fluid concentration	✍ Check and use the correct concentration
	◆ The blade stops in the cut	✍ Cutting pressure too high: check pressure and reset to rated pressure. Head downstroke speed too fast: reduce. Head downstroke speed too slow: increase. The blade slips on the flywheels: incorrect or low blade tension; readjust or increase.


Troubleshooting

This section deals with the problems which may occur during machine operation. The M50 controller allows you to test all the machine's electric and electronic devices by checking the status of the input and output signals on the IUD/IUV card (see Chapter 6).


The board IUD/IUV is inside the electric board.

Displaying the diagnostics menu


- ▶ Power the machine by turning the main switch on the left of the control board.
- ▶ Tap on the box on the touchscreen shown in the figure.




- ▶ The password entry box will open. Tap the box to open the keypad. Enter 734533.




- ▶ Tap on the box shown in the figure.



- ▶ Tap on the box shown in the figure.



- In the Troubleshooting menu, select the type of input/output to be checked by tapping on the corresponding box:



Digital Input

This page can be used to check the state of digital inputs. Information is organised in a table:

Box to go back to the initial list of all inputs and outputs

The icon indicates whether the respective output is on (green) or off (red)

EVOLUTION TS 50

← Input

v1

	Name				
●	I_THERMAL_KO	0	0	1	▲
●	I_EME_PB	0	0	2	▲
●	I_LS_BLD_COVER_CLSD	0	0	3	▲
●	I_BLD_DRV_FAULT	0	0	4	▲
●	I_FOOT_START_PB	0	0	5	▲
●	I_LS_MIN_LUB_MIN_OIL	0	0	6	▲
●	I_CHIP_CONVEYOR_BLOCKED	0	0	7	▲
●	I_RESET_KEY_PRESSED	0	0	8	▲
●	I_ENABLE_KEY_PRESSED	0	0	9	▲
●	I_XB_JStckMinus	0	0	12	▼
●	I_Y_JStckMinus	0	0	13	▼
●	I_Y_JStckPlus	0	0	14	▼

Digital INPUT list


CN13- ALL	+ 24 VDC
CN15- ALL	0 VDC
CN14- 1 INP 0	SPARE
CN14- 2 INP 1	THERMAL SWITCHES TRIPPED
CN14- 3 INP 2	EMERGENCY STOP BUTTON OK
CN14- 4 INP 3	BLADE GUARD CLOSED LIMIT SWITCH
CN14- 5 INP 4	ALARM INVERTER
CN14- 6 INP 5	START FROM PEDAL BOARD
CN14- 7 INP 6	LOW OIL LEVEL
CN14- 8 INP 7	EVTR BLOCKED
CN16- ALL	+ 24 VDC
CN19- ALL	0 VDC
CN17- 1 INP 8	RESET BUTTON
CN17- 2 INP 9	ENABLE BUTTON
CN17- 3 INP 10	SPARE
CN17- 4 INP 11	SPARE
CN17- 5 INP 12	JOYSTICK X-
CN17- 6 INP 13	JOYSTICK Y-
CN17- 7 INP 14	JOYSTICK Y+
CN17- 8 INP 15	OYSTICK Y+

Digital Output

This page can be used to check the state of digital outputs. Information is organised in a table:

Box to go back to the initial list of all in-puts and outputs

The icon indicates whether the respective output is on (green) or off (red)



Name			
O_BLD_DRIVE_EN	0	0	1
O_FCTA	0	0	2
O_FCTI	0	0	3
O_KM_HYDR_PUMP	0	0	4
O_KM_WATER_PUMP	0	0	5
O_KM_TRIM_HNDLR_FW	0	0	6
O_EV_MIN_LUB	0	0	7
O_KM_BLD_TENS_PLUS	0	0	8
O_KM_BLD_TENS_MINUS	0	0	9
O_EV_LOAD_ROLL_UP	0	0	10
O_UNLOAD_ROLL_UP	0	0	11
O_HL_LASER_TRIM	0	0	14


Digital OUTPUT list

CN21- 1 OUT 0	START INVERTER
CN21- 2 COM	+24 VDC
CN21- 3 OUT 1	RHLS
CN21- 4 COM	+24 VDC
CN21- 5 OUT 2	FHLS
CN21- 6 COM	+24 VDC
CN21- 7 OUT 3	SPARE
CN21- 8 COM	+24 VDC
CN22- 1 OUT 4	UNIT START KM
CN22- 2 OUT 5	WATER PUMP START KM
CN22- 3 OUT 6	EVTR FORWARD KM
CN22- 4 OUT 7	LOW LUBRICATION SOLENOID VALVE
CN22- 5 COM	+24 VDC
CN23- 1 OUT 8	TENSIONING + KM
CN23- 2 OUT 9	TENSIONING - KM
CN23- 3 OUT 10	LOADING ROLLER UP SOLENOID VALVE
CN23- 4 OUT 11	UNLOADING ROLLER UP SOLENOID VALVE
CN23- 5 COM	+24 VDC
CN24- 1 OUT 12	SPARE
CN24- 2 OUT 13	SPARE
CN24- 3 OUT 14	LASER PROJECTOR
CN24- 4 OUT 15	CUTTING ZONE LIGHT
CN24- 5 COM	+24 VDC

Analog Input

This page can be used to check the state of analogue inputs. Information is organised in a table:

Box to go back to the initial list of all inputs and outputs




Analog INPUT list

CN26 INP 1 (16B)	HEAD POSITIONING POTENTIOMETER
CN27 INP 2	BLADE MOTOR CONSUMPTION
CN28 INP 3	SPARE
CN29 INP 4	SPARE
CN30 INP 5	SPARE

Analog Output

This page can be used to check the state of analogue outputs. Information is organised in a table:

Box to go back to the initial list of all inputs and outputs




Analogue output list

CN25 OUT 1	BLADE SPEED REFERENCE
CN25 OUT 2	SPARE

Machine alarms and warning messages

Alarms

The machine's controller notifies the operator of any alarm or emergency condition which may occur during production by way of acoustic and visual signals. This section lists the messages shown on the display.




AL1: EMERGENCY: ONE OR MORE ALARMS HAVE TRIPPED	This appears in case of a generic emergency. A specific message follows
AL2: BLADE TENSIONING OUT OF MIN-MAX LIMITS	It is displayed when a mechanical problem occurs in the blade tensioning
AL3: BLADE MOTOR OVERCURRENT	It is displayed during the cutting when the value of the motor absorption is too high
AL4: INSUFFICIENT BLADE REVOLUTION SPEED	<p>This appears when the blade jams in the cut or breaks</p> <ul style="list-style-type: none"> ► Check blade integrity ► Check cutting parameters
AL5: HMI EMERGENCY - LOGO OR RESERVED PAGE	This appears in case of controller malfunction
AL6: EMERGENCY STOP BUTTON OR UNIT OPERATED	It is displayed when the emergency mushroom button is pressed
AL7: U AXIS NOT AVAILABLE OR FAULTY OR NOT REFERENCED: CLOSE THE LOGO PAGE AND GO BACK TO THE OPERATIVE PAGE	This appears when the head descent speed adjustment valve is not reset
AL8: XB AXIS NOT AVAILABLE OR FAULTY	<p>This is shown when the pop- up rollers interfere with head revolution</p> <ul style="list-style-type: none"> ► Position the pop- up rollers correctly as shown in Chapter 5
AL9: U AXIS DRIVE FAULTY	This appears in case of head descent adjustment valve malfunction
AL10: XB AXIS DRIVE FAULTY	This appears when there is a head revolution drive malfunction

AL11: LOW MINIMUM LUBRICATION	It is displayed when the oil level in the min. lubrication system lowers. ► Top the oil up in the tray till restoring the level.
AL12: BLADE GUARD OPEN @ BLADE CHANGE SEQUENCE DEACTIVATED	This message is displayed if the blade guard is opened, for example, to change the blade. ► Make sure the blade guard is closed. ► Check the safety limit switch. ► Check the connections.
AL13: XB AXIS ENCODER REVOLUTION BLOCKED	This appears in case of head revolution problem
AL14: BLADE DRIVE OR MOTOR FAULTY	This is shown when the blade motor inverter does not work correctly
AL15: CUTTING HEAD VICE VERTICAL INTERFERENCE LIMIT SWITCH	This appears when an attempt is made to close the vice must be head is not all up ► Take the head all up This appears when an attempt is made to move the head down and the vice is not all up ► Open the vices completely
AL16: FORWARD SOFTWARE LIMIT SWITCH UNDER STARTING POSITION (RHLS < YPOS)	This message is displayed when the cutting start position is lower than the previous position saved for the cutting end position. ► Save both the RHLS and FHLS positions again.
AL17: PARAMETER LOADING FAILED: RESTART THE MACHINE	This appears when the parameter reading procedure is not successful
AL18: BLADE POSITION ERROR: CHECK ANALOGUE INPUT	This appears when the potentiometer is broken or sends a message which is not compatible with the machine
AL19: LASER ENGAGED AT START OF CYCLE	This is shown when the cutting cycle is started and the fast approach laser is busy

Warning messages

Tap on the box shown on the figure to see warning messages:



WR1: MANUAL CUTTING UNDERWAY	This appears when the manual cycle is underway
WR2: SEMI-AUTOMATIC CUTTING UNDERWAY	This appears when the semi- automatic cycle is underway
WR3: POSITIONING UNDERWAY	This appears when the head positioning is underway
WR4: MINIMUM LUBRICATION: MINIMUM OIL LEVEL REACHED	This appears when there is no oil for minimum lubrication
WR5: SOFTWARE LIMIT SWITCH FORWARD UNDER REVERSE POSITION (RHLS > RHLS)	This appears when the RHLS and RHLS are not coherent
WR6: HYDRAULIC PUMP AUTO-OFF	This appears when the machine switches to power save mode after a given time
WR7: COMMAND INHIBITED	This appears when an incorrect operation is attempted
WR8: CHECK START CUT CONDITIONS: NO ALARMS, BLADE ENABLED, BENCH BRAKED, VICES CLOSED, RHLS < RHLS	This appears when an attempt is made to start the cutting cycle without having checked that the cutting conditions are correct
WR9: AUTOMATIC DESCENT SPEED REDUCTION FOR HIGH CURRENT	This appears when the blade motor current exceeds the setting and correction is applied
WR10: BLADE AT ZERO CUTTING FEED SPEED: CANNOT CUT	This appears when the blade setting is too low
WR11: THERMAL SWITCHES NOK	This appears when a thermal switch trips in the control panel
WR12: CHIP EJECTOR BLOCKED	This appears when the chip ejector is blocked

Accessory Installation



This chapter provides a list of the available accessories that can be fitted to this machine, along with assembly instructions.


Blade

The blades that can be used on this machine include:

- 4500 x 34 x 1,1 mm (177.16x1.34x0.04 in) bimetal blade M42 for solid and section materials;
- Blade with electro-welded hard metal teeth 4500 x 34 x 1,1 mm (177.16x1.34x0.04 in).

Roller table


- roller table module for feed/discharge side, 1500 mm (59.05 in);



Installation of the roller plane, loading side

To fit the roller table on the loading side, carry out the following operations:

- put the roller table close to the unloading adapter.




- Position the roller table making the fixing holes coincide with the adapter slots.
- Align the roller table with the machine working table using the supporting feet of the roller table.
- Fit the screws in the slots and tighten the nuts to lock the roller table in the obtained position.

Installation of the roller plane, unloading side

The installation operations are given below:

- put the roller table close to the unloading adapter.



- Position the roller table making the fixing holes coincide with the adapter slots.
- Align the roller table with the machine working table using the supporting feet of the roller table.
- Fit the screws in the slots and tighten the nuts to lock the roller table in the obtained position.

Installation of couple of vertical rollers for roller plane

For installing the vertical rollers operate as follows:

- Remove the shaped sheet covering the plane by removing the 4 fastening screws.
- Fit the couple of vertical rollers in the arranged slots and fasten them with the supplied socket head screws.
- Adjust the distance of the vertical rollers according to the dimensions of the material being machined.

Installation of the hydraulic vertical vices

For installing the hydraulic vertical vices follow the instructions enclosed to the installation kit.

For installing the hydraulic vertical vices follow the instructions enclosed to the installation kit.

Can of emulsible oil

5 l can of emulsible oil.

Minimal lubrication system

This device was designed to improve lubrication of the tool during cutting.

- ▶ An instruction book is supplied with the kit to explain how to install this optional unit.

Warranty

Hydmech Group warrants each new sawing machine to be free from failure resulting from defective material and workmanship under proper use and service for a period of one year following the date of shipment to the user.

Hydmech's sole obligation under this warranty is limited to the repair or replacement without charge, at Hydmech's factory, warehouse, or approved repair shop, of any part or parts which Hydmech's inspection shall disclose to be defective. Return freight must be prepaid by the user.

This warranty, in its entirety, does not cover maintenance items, including but not limited to lubricating grease and oils, filters, V- belts, saw blades, etc, nor any items herein which show sign of neglect, overloading, abuse, accident, inadequate maintenance or unauthorized altering.

Liability or obligation on the part of Hydmech for damages, whether general, special or for negligence and expressly including any incidental and consequential damages is hereby disclaimed. Hydmech's obligation to repair or replace shall be the limit of its liability under this warranty and the sole and exclusive right and remedy of the user.

THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, WRITTEN OR ORAL, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

This warranty may be not changed, altered, or modified in any way except in writing by Hydmech Group.

HYDMECH GROUP LIMITED

1079 Parkinson Road

P.O. BOX 1030

Woodstock, Ontario

N4S 8A4

Sales Toll Free: 1- 877- 276- SAWS (7297)

Phone: (519) 539- 6341

Fax: (519) 539- 5126

Website: www.hydmech.com

e- mail: info@hydmech.com



The Rock Solid Solution

Through its twinned distribution channel of authorized dealers and factory representatives, HYD- MECH services worldwide network of customers from its two state-of-the-art manufacturing facilities in Houston, Texas, USA and Woodstock, Ontario, Canada. Check out the full range of Rock Solid Sawing Solutions at www.hydmech.com

HYD- MECH GROUP LIMITED
1079 Parkinson Road, P.O. BOX 1030
Woodstock, Ontario, Canada N4S 8A4
Sales toll free: 1-877-276-SAWS (7297)
Telephone: (519) 539-6341
Fax: (519) 539-5126

Customer service toll free: 1-877-237-0914 - PARTS FAX:(519) 539-5099 - WEBSITE: www.hydmech.com - E-MAIL: info@hydmech.com